


GCAN PLC入门应用指南



Document Name: GCANPLC Getting Started Application Guide					
document name	version number	Version update instructions	change date	changed by	release date
Getting Started with GCANPLC Application Guide	v0.1	Create documentation	2021.09.16	Ponschi	2021.11.05

directory

one, Product Basic Information	1
1. GCAN-PLC Series Product Introduction	1
1.1 Feature Overview	1
1.2 Interface description	1
1.2.1 Ethernet interface Ethernet RJ45	1
1.2.2 serial port RS232/485 RJ45 interface	3
1.2.3 CAN interface	3
1.2.4 Power supply interface	4
1.3 Technical parameters	5
2. GC-IO Module Product Brief	7
2.1 IO Module classification	7
2.2 IO Module selection table	8
3. Programming software (OpenPCS) installation, configuration	9
3.1 OpenPCS install	9
3.2 Install TARGET Component	13
3.3 OpenPCS Online configuration	13
3.4 Hardware connection, download program	16
3.4.1 Device Wiring	16
3.4.2 Revise PLC connected to computer network IP address	17
3.4.3 Download Program	18
two, Introductory Programming Fundamentals	22
1. OpenPCS Function Introduction	22
1.1 interface structure	22
1.2 Basic software functions	23
1.3 New construction	28
1.4 New file	29
1.4.1 New program	29
1.4.2 Create a new declaration file	30
2. Getting Started with Simple Programming Statements	31
2.1 variable declaration	32
2.2 Programming Syntax	33
2.2.1 Math Operators	34
2.2.2 comparison directive	34
2.2.3 Logical Operators	34
2.2.4 IF Statement	34
2.2.5 CASE Statement	35
2.2.6 function block call	36
3. IO Introduction to Module Configuration	36
three, Getting Started with Function Blocks	38
1. Basic Instruction Set	38
3.1.1 CTU	39
3.1.2 CTD	40
3.1.3 CTUD	40
3.1.4 TON	41
3.1.5 DT_CLOCK	42

3.1.6 F_TRIG	42
3.1.7 R_TRIG	43
3.1.8 SR	43
3.1.9 RS	43
3.1.10 PID	44
3.1.11 TOF	45
3.1.12 TP	46
3.1.13 CONCAT_STRING	47
3.1.14 MOD	47
3.2.1 ABS	47
3.2.2 ACOS	47
3.2.3 ADD	48
3.2.4 ASIN	48
3.2.5 ATAN	48
3.2.6 COS	48
3.2.7 DELETE	48
3.2.7 EQ(ST cannot be used in)	49
3.2.9 EXP	49
3.2.10 FIND.....	49
3.2.11 GE.....	50
3.2.12 GT.....	50
3.2.13 INSERT.....	50
3.2.14 LE.....	51
3.2.15 LT.....	51
3.2.16 LEFT.....	51
3.2.17 LEN.....	52
3.2.18 LIMIT.....	52
3.2.19 LN.....	52
3.2.20 LOG.....	53
3.2.21 MAX.....	53
3.2.22 MIN.....	53
3.2.23 MOD.....	53
3.2.24 NE	53
3.2.25 POINTER	53
3.2.26 RIGHT	54
3.2.27 ROL	54
3.2.28 ROR	55
3.2.29 SHL	55
3.2.30 SHR	55
3.2.31 SIN	56
3.2.32 SQRT	56
3.2.33 TAN	56
3.2.24 XOR	56
2. Extended function blocks	57
3.3.1 USART_INIT	59
3.3.2 USART_STATE	62
3.3.3 USART_READ_BIN	66
3.3.4 USART_WRITE_BIN	68

3.3.5 USART_READ_CHR.....	72
3.3.6 USART_WRITE_CHR.....	73
3.3.7 USART_READ_STR.....	75
3.3.8 USART_WRITE_STR.....	77
3.3.9 EXT_USART_INIT.....	80
3.3.10 EXT_USART_READ_BIN.....	83
3.3.11 EXT_USART_WRITE_BIN.....	84
3.3.12 CAN_INIT.....	87
3.3.13 CAN_MESSAGE_READ8.....	90
3.3.14 CAN_MESSAGE_WRITE8.....	92
3.3.15 CAN_NMT.....	96
3.3.16 CAN_GET_STATE.....	96
3.3.17 CAN_REGISTER_COBID.....	97
3.3.18 CAN_PDO_READ8.....	98
3.3.19 CAN_PDO_WRITE8.....	100
3.3.20 CAN_SDO_READ8.....	101
3.3.21 CAN_SDO_WRITE8.....	102
3.3.22 CAN_SDO_READ_STR.....	103
3.3.23 CAN_SDO_WRITE_STR.....	104
3.2.24 CAN_SDO_READ_BIN.....	106
3.3.25 CAN_SDO_WRITE_BIN.....	107
3.3.26 CAN_RECV_EMCY.....	109
3.3.27 CAN_RECV_EMCY_DEV.....	110
3.3.28 CAN_WRITE_EMCY.....	110
3.3.29 CAN_ENABLE_CYCLIC_SYNC.....	111
3.3.30 CAN_SEND_SYNC.....	112
3.3.31 CAN_ENABLE_CYCLIC_NODE_GUARD.....	113
3.3.32 CAN_SEND_NODE_GUARD.....	113
3.3.33 CAN_RECV_BOOTUP_DEV.....	114
3.3.34 CAN_RECV_BOOTUP.....	114
3.3.35 CAN_FILTER.....	115
3.3.36 LAN_INIT.....	115
3.3.37 LAN_GET_TCPCONNECT_SOCKET.....	117
3.3.38 LAN_TCP_SERVER_CREATE.....	118
3.3.39 LAN_TCP_CLIENT_CONNECT.....	118
3.3.40 LAN_TCP_CLIENT_CLOSE.....	119
3.3.41 LAN_TCP_RECV_BIN.....	120
3.3.42 LAN_TCP_SEND_BIN.....	120
3.3.43 LAN_UDP_CREATE_SOCKET.....	123
3.3.44 LAN_UDP_CLOSE_SOCKET.....	124
3.3.45 LAN_UDP_RECVFROM_BIN.....	124
3.3.46 LAN_UDP_SENDTO_BIN.....	126
3.3.47 LAN_UDP_RECVFROM_STR.....	127
3.3.48 LAN_UDP_SENDTO_STR.....	128
3.3.49 EXT_GPRS_INIT.....	129
3.3.50 EXT_GPRS_STATUC.....	130
3.3.51 EXT_GPRS_READ_BIN.....	130
3.3.52 EXT_GPRS_WRITE_BIN.....	131

3.3.53 MQTT_INIT.....	132
3.3.54 MQTT_STATUS.....	133
3.3.55 MQTT_SEND.....	133
3.3.56 MODBUS_SLAVE_INIT.....	134
3.3.57 MODBUS_SLAVE_CTRL.....	136
3.3.58 MODBUS_MASTER_INIT.....	138
3.3.59 MODBUS_MASTER_CTRL.....	139
3.3.60 MODBUS_TCP_SLAVE_INIT.....	140
3.3.61 MODBUS_TCP_SLAVE_CTRL.....	141
3.3.62 MODBUS_TCP_MASTER_INIT.....	144
3.3.63 MODBUS_TCP_MASTER_CTRL.....	144
3.3.64 DT_CLOCK.....	145
3.3.65 RTC.....	148
3.3.66 GETSYSTEMDATEANDTIME.....	148
3.3.67 SETSYSTEMDATEANDTIME.....	148
3.3.68 GETDATESTRUCT.....	149
3.3.69 NVDATA_BIT.....	150
3.3.70 NVDATA_BIN.....	151
3.3.71 NVDATA_STR.....	152
3.3.72 EXT_MOTOR_PWM_INIT.....	156
3.3.73 EXT_MOTOR_EN.....	157
3.3.74 CTU.....	158
3.3.75 CTD.....	158
3.3.76 CTUD.....	159
3.3.77 INIT_TBL.....	160
3.3.78 FIFO_TBL.....	161
3.3.79 LIFO_TBL	161
3.3.80 ADD_TBL	162
3.3.81 COUNT_TBL	163
3.3.82 PID1	163
3.3.83 SYS_PLC_RESET	165
3.3.84 PTO_PWM	166
3.3.85 PTO	173
3.3.86 GETVARDATA	174
3.3.87 GETVARFLATADDRESS	175
3.3.88 GETTASKINFO	175
Four, Basic Function Application Routine Explanation	177
1. Marquee Experiment Routine Explained	177
2. I/O Experiment	178
3. CAN Send and receive data experiment ST	178
4. serial port RS232 , 485 experiment ST	180
5. TCP SERVER Communication Lab	180

1. Basic product information

1.1 GCAN-PLC Series product introduction

1.1.1 Functional Overview

GCAN-PLC series products (GCAN-PLC-400, GCAN-PLC-510, GCAN-PLC-511, etc.) are programmable logic controllers (PLCs) integrated with bus control functions. It not only has the characteristics of simple appearance and high cost performance, but also can be easily connected to the CAN bus system and Modbus system, etc., and can be expanded through the module insert type.

GCAN-PLC series products consist of a programmable main control module (GCAN-PLC-510, etc.), several GC series IO modules and a terminal terminal module (GC-0001). GCAN-PLC series modules can be connected to all GC series IO modules. Users can choose to expand IO modules according to the actual needs of the site. In the case of sufficient power supply, the number of IO modules can be expanded to 32 at most. GCAN-PLC series can be inserted according to the front and rear positions of the IO module are automatically assigned hardware addresses to realize automatic configuration. Users do not need to create a configuration interface and set parameters on the PC. The detailed description of the hardware configuration will be shown in Chapter 2, Section 3 of this book, and will not be explained in detail in this chapter.

GCAN-PLC series products can be programmed with OpenPCS software, which supports five standard programming languages specified in the IEC-61131-3 standard, which makes the program highly portable and reusable, and the software also With a variety of debugging functions (breakpoints, single-step, etc.), it is more convenient to debug programs.

GCAN-PLC-510 can not only complete various digital / analog input / output, but also integrates a variety of common industrial field bus interfaces, such as CANbus, RS232/485 bus, Ethernet bus, and supports common Communication protocols such as: CANopen, Modbus RTU, Modbus TCP, etc.

GC series IO modules include: switch input and output modules, analog input and output modules, pulse input and output modules, communication port expansion modules (RS232/485 , 4G , Bluetooth, WiFi , Zigbee , GPRS , etc.) detailed selection list See Section 2 of this chapter .

1.2 Interface description

1.2.1 Ethernet interfaceE thernet RJ45

The Ethernet interface can be programmed through OpenPCS , and can be used as TCP SERVER , TCP CLIENT , UDP , modbus TCP . In the delivery state, Ethernet can be used to connect with OpenPCS and download programs.




Figure 1.1 : Ethernet Interface

The speed of the Ethernet interface is all **100 Mbit**. An LED on the left side of the interface indicates the connection status. The upper LED (**LINK / ACT**) indicates whether the interface is connected to the network.

If connected to the network, the **LED** is green.

The lower **LED** (**SPEED**) is yellow. Speed blinks when data transfer is in progress .




Figure 1.2 : Ethernet Interface, Pin Numbering

pin	Signal	desc ribe
1	T2+	Pair 2
2	T2 -	
3	T3+	Pair 3
4	T1+	
5	T1 -	Pair 1
6	T3 -	
7	T4+	Pair 4
8	T4 -	

Table 1.1 : Ethernet Interface Pin Assignments

1.2.2 Serial RS232/485 RJ45 interface

RS232 communication is RJ45, which can be programmed through OpenPCS. As RS232 communication, modbus RTU communication is used. We come with a free RJ45 to DB9 cable, the specific pins are shown in the table below.




Figure 1.3 pin definition of the patch cord

terminal	RJ45 terminal serial number	DB9 terminal serial number	meaning
RS232_TX	3	2	RS232 data transmission
RS232_RX	6	3	RS232 data reception
GND	4	5	signal ground
RS485_A+	8	7	RS485 signal A+
RS485_B-	1	8	RS485 signal B-

Table 1.2 : Serial RS232/485 RJ45 interface pin assignment

1.2.3 CAN interface

CAN communication is the **OPEN** terminal, which can be programmed through **OpenPCS**. As CAN communication, **CANOPEN** communication is used. The specific pins are shown in the figure below.




Figure 1.4 CAN pin assignment

1.2.4 Power supply interface

The power terminals require an external voltage source that provides 24V DC (-15% /+20%). The power terminals must provide 1A at 24V to ensure that the PLC will function properly in all conditions.

The cable connection of the PLC in the control cabinet must comply with the standard EN 60204-1 : 2006 PELV = extra low voltage protection:

- Basic CPU "PE" and "0" of the module's voltage source The V" conductors must be at the same potential (connected in the control cabinet).
- Standard EN 60204-1 : 2006 6.4.1 : b_ Section states that one side of a circuit or the energy source of that circuit must be connected to a protective earth system.
- PLC Separate power supply from the rear expansion module when necessary.
- The voltage of the power supply for the expansion module is 24V DC (-15% / + 20%), and the minimum power provided by this power supply is calculated according to the current consumption of the expansion module.




Figure 1.5 Schematic diagram of power supply wiring

seri al numb er	describe
1	The spring loaded terminals labeled " 24V " and " 0V " power the PLC .
2	The spring terminals identify " + ", " - " and supply power to the IO bus terminals via the power contacts .

Table 1.3 Power supply terminal pin assignment

1.3 technical parameter

	GCAN-PLC-510
Size (L * W * H)	47mm × 68mm × 97mm
weight	180g

surface 1.4 Technical data, dimensions and weights

technical parameter	GCAN-PLC-510
processor	ARM Cortex-M series
Flash (Program Memory)	32M bytes
SRAM (variable memory)	16M bytes
user data store	2k bytes
Power supply	24 V DC (-15 %/+20 %)
Maximum energy consumption	12W

受控

CAN/485 isolation class	1500V
-------------------------	-------

PC software	OpenPCS
Diagnostic Lights	One power light, one system light, one running light, one fault light, one IO bus light, one IO bus fault light
clock	Internal battery backed clock for time and date
Certification	CE

Table 1.5 technical data, general data

technical parameter	describe
Native I/O	No, need to expand GC series IO module
Configuration method	via IO bus
Number of expansion terminal modules	32 _
Digital I/O Signals	Supports up to 32×8 input / output
Analog I/O signals	Supports up to 32×4 inputs, 32×2 outputs

Table 1.6 technical data, I/O terminal

technical parameter	describe
Operating temperature	-40 ° C to +85 ° C
Working humidity	95%RH, no condensation

受控

Vibration resistance	10 frequency sweeps on 3 axes $6 \text{ Hz} < f < 58.1 \text{ Hz}$ displacement 0.15 mm, constant amplitude
----------------------	--

	58.1 Hz < f < 500 Hz acceleration 5 g, constant amplitude Complies with EN 60068-2-6
impact resistance	1000 shocks in each direction on 3 axes 15g, 11ms _ Complies with EN 60068-2-27

Table 1.7 Technical data, environmental conditions

Supported Communications	Interface form
CAN,CANOPEN	OPEN4 terminal
RS232, RS485, MODBUS RTU	RJ45
TCP,UDP,MODBUS TCP	RJ45

Table 1.8 Technical data, interface

2. GC-IO Module Product Introduction

2.1 IO Module classification

Digital Input Modules: GC-1008, GC-1018, GC-1502

Digital output modules: GC-2008, GC-2018, GC-2204, GC-2302

Analog Input Modules: GC-3604, GC-3624, GC-3644, GC-3654, GC-3664,

GC-3674 Temperature Acquisition Input Modules: GC-3804, GC-3822,

GC-3844, GC-3854, GC-3864

Analog output module: GC-4602, GC-4622, GC-4642, GC-4652, GC-4662, GC-4672,

GC-4674 Communication expansion module: GC-6101, GC-6221, GC-6501

2.2 IO Module selection table

type	model	characteristic	Signal	number of channe ls
digital input	GC-1008	basic digital	24V DC	8 channels
	GC-1502	Counter (200kHz max)	-	2 channels
digital output	GC-2008	basic digital	24V DC	8 channels
	GC-2204	relay on	-	4 channels
	GC-2302	PWM (20Hz~200kHz)	-	2 channels
Analog input	GC-3604	Voltage input, 16 bit	-5V~+5V	4 channels
	GC-3624	Voltage input, 16 bit	-10V~+10V	4 channels
	GC-3644	Current input, 16 bit	0-20mA	4 channels
	GC-3654	Current input, 16 bit	4-20mA	4 channels
	GC-3664	Voltage input, 16 bit	0~+5V	4 channels
	GC-3674	Voltage input, 16 bit	0~+10V	4 channels
	GC-3804	2-wire PT100, 16 bit	Thermal resistanc e	4 channels
	GC-3822	3-wire PT100, 16 bit	Thermal resistanc e	2 channels
	GC-3844/385 4/3864	Type K / Type S / Type T Thermocouples	Thermocou ple	4 channels
	GC-4602	Voltage output, 16 bit	-5V~+5V	2 channels

受控

Analog output	GC-4622	Voltage output, 16 bit	-10V~+10V	2 channels
	GC-4642	Current output, 16 bit	0-20mA	2 channels
	GC-4652	Current output, 16 bit	4-20mA	2 channels
	GC-4662	Voltage output, 16 bit	0~5V	2 channels
	GC-4672	Voltage output, 16 bit	0~10V	2 channels
Special Expansion Module	GC-6101	RS232/RS485 expansion	-	-
	GC-6201	GPRS extension	-	-
	GC-6221	4G extension	-	-
	GC-6501	WiFi extension	-	-


3. Programming software (OpenPCS) installation and configuration

3.1 OpenPCS Install


(1) Open the folder ① in the network disk data, OpenPCS Installation package

名称	修改日期	类型	大小
①OpenPCS安装包	2019-06-19 9:31	文件夹	
②Target安装	2019-06-19 9:31	文件夹	
③GC主控模块说明书	2020-03-02 11:34	文件夹	
④GC-IO模块说明书	2020-02-21 10:49	文件夹	
⑤OpenPCS用户手册	2019-12-25 10:12	文件夹	
⑥PLC例程	2020-02-21 10:25	文件夹	
⑦功能块说明书	2020-02-21 10:40	文件夹	
⑧调试实用软件	2019-06-19 9:30	文件夹	
⑨USB串口驱动	2020-02-24 12:10	文件夹	
⑩基础资料及宣传册	2020-02-20 11:12	文件夹	
⑪常见问题解答	2020-02-21 10:51	文件夹	
光盘说明-请先读我.txt	2020-02-21 11:14	文本文档	2 KB


(2) Select the English version or the Chinese version to decompress and double-click the .exe File installation, this article only introduces the English version, the Chinese version installation process is the same as the English version.




(3) The installation interface appears, click Install



(4) The following prompts may appear during the installation process, click Yes (Y)




(5) Click Next to continue the installation




(6) Choose to accept the license and click Next




(7) Fill in the user name, here it is recommended to use the default and click Next




(8) Select the installation path, select it and click Next



(9) For the next steps, just click Next, start the installation, and wait for the installation progress bar until the Add Driver appears, click here to exit.



(10) The installation is complete




3.2 Install TARGET components

Open the folder ② in the network disk data, TARGET installation, choose the Chinese version and the English version, there is no difference, just choose the language of the installation wizard, select the .exe file inside, double-click, and click Install, the installation process only takes a few seconds , almost in a flash.




3.3 OpenPCS Online configuration

- ① Select PLC connection of drop-down list Go to connection settings.




- ② Click **New** Create a new connection configuration.




- ③ Name the new connection configuration, and name it according to user preferences. In this article, it is named **TCPtest**. After filling in the name, click **Select**.


Select the driver for the connection configuration.



- ④ **TCP432** in the pop-up driver selection box drive, and click **OK**.



- ⑤ After selecting the driver, **Settings** The button will become clickable, click **Settings** Button is **TCP432** The driver sets properties.




- ⑥ Set the port number **Port** is **23042** (*port number is a fixed value and cannot be changed*) , IP Address is PLC device IP address

(* The factory default IP of GCANPLC is **192.168.1.30** , when the user just got the device, the device IP is the default IP*) Note: Please do not check the following **PLC using big endian**




mode. After setting, click the **OK** button on the right.


- ⑦ After editing the connection settings, click **OK**, click **OK** After that, the edit box disappears, click Close in the connection settings.



(8) Click on the menu bar PLC Resource property Resource in drop down list Properties .



(9) hardware module selects GCANPLC , and the network connection selects the one just set. In this article, it is TCPtest . The user can select the connection configuration set



by himself according to the actual situation.

3.4 Hardware connection, download program


3.4.1 Equipment wiring

(1) The 24V switching power supply supplies power to the PLC . The PLC needs two groups of power supplies. The first group is connected to 24V through hole 1 , and connected to 0V through hole 2 to supply power to the controller ; 6 holes are connected to 0V to supply power to the IO module connected later, among which holes 3 and 4 are short-circuited inside, and

holes 5 and 6 are short-circuited inside.

So when wiring, connect 1 hole with 3 holes, 2 holes with 5 holes, 4 holes with 24V power supply, 6 holes with power supply 0V,

You can use one power supply to supply power to the controller and the IO module at the same time. Note: GC0001 should be installed after the last IO module. If there is no IO module, it should be directly installed on the controller to form a loop, otherwise the IO ERR red light will be always on.



(2) Use a network cable to connect the computer and the PLC. The IP address of the PLC is 192.168.1.30. The IP address of the computer needs to be modified to be the same as the first three IP addresses, namely 192.168.1.XX, where XX is other than 30, which is After the PLC is powered on, the indicator PWR is always on, SYS is flashing slowly, RUN is flashing quickly, IO RUN is flashing quickly, and ERR and IO ERR are off.

3.4.2 Modify PLC IP connected to the computer network address

- ① Open Network and Internet Settings, select Ethernet option

以太网

以太网 3
未连接

AAAAA
已连接

相关设置


[更改适配器选项](#)

[更改高级共享设置](#)

[网络和共享中心](#)

[Windows 防火墙](#)

② Click on the right to change the adapter option, right-click the network connection between the PLC and the computer, click Properties, select Internet Protocol Version 4 (TCP4/IPv4), select it and click Properties, and set the IP to the same network segment as the PLC , as shown in the figure.



3.4.3 Downloader

- ① Open the ⑥ folder PLC in the network disk file routine.

名称	修改日期	类型	大小
①OpenPCS安装包	2020-07-06 14:47	文件夹	
②Target安装	2019-06-19 9:31	文件夹	
③GC主控模块说明书	2020-08-17 10:08	文件夹	
④GC-IO模块说明书	2021-03-31 11:16	文件夹	
⑤OpenPCS用户手册	2021-03-08 16:31	文件夹	
⑥PLC例程	2021-03-23 9:05	文件夹	
⑦功能块说明书	2020-02-21 10:40	文件夹	
⑧调试实用软件	2021-07-24 15:33	文件夹	
⑨USB串口驱动	2021-08-20 17:34	文件夹	
⑩基础资料及宣传册	2020-02-20 11:12	文件夹	
⑪常见问题解答	2020-02-21 10:51	文件夹	
⑫GCAN_PLCSolution1.4.8	2021-09-10 11:41	文件夹	
⑬快速使用手册---read me.pdf	2021-03-08 16:23	WPS PDF 文档	3,677 KB

- ② LED in the folder folder.

名称	修改日期	类型	大小
1.跑马灯实验ST	2020-09-02 15:44	文件夹	
2.输入输出实验ST	2020-02-21 10:25	文件夹	
3.CAN收发数据实验ST	2020-02-21 10:25	文件夹	
4.CAN收发数据实验LD	2020-02-21 10:25	文件夹	
5. CanOpenMaster实验ST	2020-02-21 10:25	文件夹	
6.串口RS232、485实验LD	2020-02-21 10:25	文件夹	
7.串口RS232、485实验ST	2020-02-21 10:25	文件夹	
8.TCP SERVER实验ST	2020-02-21 10:25	文件夹	


名称	修改日期	类型	大小
LED	2020-09-02 15:44	文件夹	

③ Double click on .VAR program file, open program


名称	修改日期	类型	大小
\$ENV\$	2020-02-21 10:25	文件夹	
\$GEN\$	2020-09-02 14:59	文件夹	
cfcxref.xsl	2018-12-26 13:14	XSL 样式表	4 KB
inputFileList	2020-06-29 10:07	文件	1 KB
LED.bak	2019-06-04 15:12	BAK 文件	1 KB
LED.GEN	2021-04-06 9:06	GEN 文件	1 KB
LED.INI	2018-12-26 13:14	配置设置	0 KB
LED.POE	2019-06-05 17:25	POE 文件	2 KB
LED.ST	2019-06-05 17:25	ST 文件	1 KB
LED.VAR	2021-04-26 14:26	VAR Project	1 KB
Resource.WL	2021-04-26 14:30	WL 文件	1 KB
USERTYPE.TYP	2018-12-26 13:14	TYP 文件	1 KB

(*** Note: After opening the program, be sure to check the OpenPCS connection configuration! This is very important! For the check and setting steps, refer to the OpenPCS connection configuration in Chapter 1, Section 3.3 in this article !***)


④ After opening the program, click on the menu bar PLC Online in drop down list



- ⑤ Before downloading the program, it will pop up: PLC If the program is not the latest, if you want to download the current program, click Yes.



⑥ Wait for the download progress bar.



⑦ After the download is complete, click the Run button to run the program.

```

1 VAR_EXTERNAL
2
3 END_VAR
4
5 VAR_GLOBAL
6
7
8
9
10
11
12
13
14
15
16

```

```

1
2
3 IF v1<1000 THEN      (*如果v1<1000,则自加1*)
4     v1:=v1+1;
5
6 ELSE                   (*如果v1=1000,则把v1赋值为0*)
7     v1:=0;
8     v2:=v2+1;
9     if v2>=255 then   (*如果v2加到255,则把v2赋值为0*)
10        v2:=0;
11    end_if;
12    oled:=int_to_byte(v2); (*将数据类型为int的v2转化为byte赋值给oled*)
13
14 end_if;
15
16

```

- ⑧ Click the stop button to stop the program from running.

```

1 VAR_EXTERNAL
2
3 END_VAR
4
5 VAR_GLOBAL
6
7
8
9
10
11
12
13
14
15
16


```

```

1
2
3 IF v1<1000 THEN      (*如果v1<1000,则自加1*)
4     v1:=v1+1;
5
6 ELSE                   (*如果v1=1000,则把v1赋值
7     v1:=0;
8     v2:=v2+1;

```


- ⑨ Click PLC again Online in drop down list The online state can be closed, i.e. PLC Offline with the computer.



Second, the basics of programming

1. OpenPCS Function introduction


1.1 interface structure



①Menu bar ②Project file box ③Information display window

④Debug window ⑤Function block window Double-click the program


file in the project box, the following window will be displayed:




⑥Variable declaration area ⑦Program editing area

1.2 Basic software functions


(1) Project file rename: menu bar - project - rename.



(2) Program file renaming: Select the file to be renamed, click the menu bar - File - Rename.




- (3) Delete project file: Select the file to be deleted and click delete on the keyboard key.
- (4) Grammar check: Click this icon. The purpose of syntax checking is to check whether the program is written for syntax errors.



- (5) Add variables to the variable monitoring area: click the resource in the project box, select the variable to be monitored and double-click.




- (6) The data display format of the manipulated variable monitoring area: menu bar - view - number format.



- (7) Compile: Click the Compile button in the menu bar.



(8) Regenerate the current resource: Click the Regenerate button in the menu bar.




(9) Breakpoint debugging: ①Set breakpoint ②Toggle breakpoint ③Delete breakpoint
④Step forward ⑤Step over ⑥Step out.




Note: The function of setting breakpoints is to let the program execute line by line, which is convenient to find out the problem.

(10) Display the number of lines of code: Menu bar - Other - Options - Browser, select other settings in the pop-up window, and check "Show line numbers in text editor". Then click Apply, OK.



(11) Adjust code font, color, background color: menu bar - other - font / color.

Here you can choose font, font size, foreground color, background color.



- (12) Project backup and recovery; **1.** Menu bar - Project - Backup **2.** Menu bar - Project - Recovery

Backup will save the current project as a **.BAK** file, and restore can open the previously saved **.BAK** file. This can be backed up at any time when the program is written, which is convenient for comparison with the final version of the program. At the same time, when sending a project to others, it is not necessary to send the entire project folder, only the **.BAK** file needs to be sent.



- (13) Syntax error check: When an error is reported in compilation or syntax check, double-click the error message, and the cursor will jump to the wrong place. It may be this line, or it may be the previous line or the next line.

The screenshot shows the Infotech OpenPCS software interface with a ladder logic program for a motor driver. The code uses the `inst2_EXT_MOTOR_PWM_INIT` instruction to initialize two motors. A red box highlights the first instance of this instruction at line 18. The status bar at the bottom shows error messages related to syntax errors in the highlighted line.

```
VAR_EXTERNAL
END_VAR
VAR GLOBAL
    ...
17    if stp=0 then
18        inst2_EXT_MOTOR_PWM_INIT(EN_IN := true , NETNUMBER := 1, MOTOR_CH :=1 , MOTOR_MODE :=motor_mode , MOTOR_PULSE :=1000 , ACCTIME :=5 , DECTIME :=5);
19        stp:=stp+1;
20    elseif stp=1 then
21        inst2_EXT_MOTOR_PWM_INIT(EN_IN := true , NETNUMBER := 1, MOTOR_CH :=2 , MOTOR_MODE :=motor_mode , MOTOR_PULSE :=1000 , ACCTIME :=5 , DECTIME :=5);
22        stp:=stp+1;
23    elseif stp=2 then
24        inst2_EXT_MOTOR_PWM_INIT(EN_IN := true , NETNUMBER := 2, MOTOR_CH :=1 , MOTOR_MODE :=motor_mode , MOTOR_PULSE :=1000 , ACCTIME :=5 , DECTIME :=5);
25        stp:=stp+1;
26    end_if;
27
28
29
30
31    if xF0 and equt=true and stp=4 then
32        xInitOk :=TRUE;
33    end_if;
34
35
36end_if;
37
38
39
```

1.3 New Construction

New project: Click the menu bar - project - new - name



1.4 create a new file


There are two types of new files, one is to create a new program **POU**, and the other is to create a new declaration file. There are 5 languages that can be selected for the new program file , namely , the 5 standard programming languages of IEC61131-3 . There are two types that can be selected: program and function block.

The newly created declaration file is divided into global variables and direct global variables. When the same variable is shared among multiple program files, the variable needs to be declared in the global variable; when the variable with direct physical address (AT%...) is shared among multiple program files, then the variable needs to be declared directly in the direct physical address. declared in a global variable.

When naming, the name of the file cannot start with a number, and the name cannot contain Chinese characters.

1.4.1 new program

Click the white page icon in the upper left corner to create a new program page, select **POU** for the file type, select the language of the program page in the IEC language area, select the program type on the **POU** type page, and name the new program page.




After the creation is complete, click OK, and the following dialog box will appear:

Click Yes, and a green check mark will appear on the icon of the program file, indicating that the program file has been linked to the resource.



At the same time, if you want to cancel the link to the resource, right-click the program file and cancel the link to the active resource, so that the program



file will not be compiled and downloaded.


1.4.2 New declaration file

Click the white page icon in the upper left corner to create a new program page, and select the declaration file for the file type to create a global variable declaration page.



2. Getting Started with Simple Programming Statements

OpenPCS project can have multiple program files, and the program execution mechanism is simultaneous execution. There is no concept of main program subroutines. A program file is called a task in OpenPCS, and the task types are divided into Cyclic and Timer. When the task type is Cyclic, the loop period below 1000 lines of code is 1ms ; when the task type is Timer, the loop time can be set freely, but it cannot be lower than the fastest loop period that the program can execute, that is, 1ms . The specific modification method is as follows:



2.1 variable declaration

Note: All symbols used in **OpenPCS** must be

English symbols. local variable in

VAR

END_VAR

statement in. All variables, basic instructions, function blocks are case-insensitive.

(1) Intermediate variable declaration: **variable name** : data type; Example: **GCANPLC :BYTE;**

(2) Initial value of variable setting: **variable name** : data type: =value;
example: **GCANPLC :BYTE:=0;**

(3) Variable declaration with direct address:

Variable name AT%I0.0: data type; (represents the actual address

of the variable as I0.0, I represents input) Example: **GCANPLC**

AT%I0.0:BYTE;

Variable name AT%Q0.0: data type; (represents the actual address

of the variable as Q0.0, Q Representative output) Example:

GCANPLC AT%Q0.0:BYTE;

(4) Array declaration:

array name : array[0..9] of byte ; (represents that there are in the array 10

elements 0~9 , the type of the elements in the array is byte) Example:

GCANPLC :array[0..9] of BYTE; the first element is **GCANPLC[0]** .

(5) Function block declaration:

- **defined name** :function block name ;(If a function block is to be used multiple times in a program , it must be declared multiple times in the declaration area)

Example: **inst0_ton** :TON; **Inst1_ton** :TON;

The table of data types is shown in the following table:

type of data	meaning	Data length
BOOL	boolean	1 bit
BYTE	byte	8 bits
WORD	Character	16 bit
DWORD	double word	32 bit
SINT	short	8 bits
USINT	unsigned short	8 bits
INT	Integer	16 bit
UINT	unsigned int	16 bit
DINT	double integer	32 bit
UDINT	unsigned double integer	32 bit
REAL	real numbers	32 bit
CHAR	character	
STRING	string	
TIME	time	
DATE_AND_TIME	time and date	

2.2 programming syntax

All the statements in the example programs in this section have no actual meaning or function, but are only examples of the usage of the statements. If you need to use the statements, you can write your own programs according to the usage of the syntax examples in this section.


2.2.1 math operator

`:=` assignment operator `+` Addition `-`

Subtraction `*` multiplication `/` Division example:

`a := b + c;` means that the **b** add **c** The result is assigned to **a**.

Note: A semicolon needs to be added after the end of the statement, and the data type of the variable to be operated and the variable to be assigned must be consistent (**BYTE** cannot be directly operated, and needs to be converted to data types such as **INT**, **UINT**, **SINT**, **USINT**, etc.).



2.2.2 comparison directive

`<` less than `>` greater than `=` equal `<=` less than or equal to `>=` greater than or equal to `<>` not equal to 2.2.4 middle IF Statement display.

2.2.3 Logical Operators

`or` or `and`, `&` and `not` non- `orn` or `not andn`

NAND example: `a := b and c;` means to **b** and **c** The result of the AND operation of each bit is assigned to **a**.

Note: A semicolon needs to be added after the end of the statement, and the data type of the variable to be operated and the variable to be assigned must be consistent.

```
9VAR  
10a, b, c:byte;  
11END_VAR  
  
1a:=b and c;  
2  
2
```

2.2.4 IF statement

- (1) **IF** XXX Condition **THEN** execute XXX command **END_IF**;

Example: IF $a < b$ THEN $c := c + 1$; END_IF; means if a less than b , then c Execute self-add 1 operate.

TIPS : Although **BYTE** variables cannot perform mathematical operations, they can do mathematical comparisons.

```
8
9VAR
10a,b:byte;
11c:int;
12END_VAR
```

(2) IF XXX Condition THEN execute XXX Command ELSE execute XXX command END IF;

Example: IF $a < b$ THEN $c := c + 1;$ ELSE $c := 0;$ END_IF ; means if a less than b , then c Execute self-add 1 operation , otherwise the execution will c

```
9VAR  
10a,b:byte;  
11c:int;  
12END_VAR
```



```
1if a<b then  
2    c:=c+1;  
3else  
4    c:=0;  
5end_if;
```

assign as 0 operate.

2.2.5 CASE statement

CASE statement can choose to execute different commands depending on the value of the variable being checked, although **ELSEIF** is nested with **IF**

It can also be implemented, but when there are too many values for the variable being checked, it is more concise and convenient to use the **CASE** statement.

CASE xxvariable **OF** 1: execute XXX command ; 2: execute XXXOrder
N: execute XXX Command **FND CASE**:

例: case a of 1: b:=a; 2: c:=a; 3: x:=a; end case;

means to check the value of variable **a** , when **a=1** , assign **a** to **b** ; when **a=2** , assign **a** to

c ; when a is equal to 3 , assign a to x .

```

9VAR
10a, b, c, x:byte;
11END_VAR

1case a of
21:
3b:=a;
42:
5c:=a;
63:
7x:=a;
8end_case;
9

```

2.2.6 function block call

2.1 of this chapter . When programming, you need to call this function block according to the name of the function block declaration, for example:

`inst0_GPRS345G_STATUS(EN_IN := , NETNUMBER := | := STATUS, := EN_OUT);`

`inst0_GPRS345G_STATUS` outside the brackets is the name of the function block when it is declared; inside the brackets, the vertical bar | in front is an input variable, and the right side of := can be filled with data or variables; the vertical bar | behind is an output variable, and the left side of := must be filled in the intermediate variable to accept the output value of the function block. For the types and meanings of specific function blocks, please refer to Chapter 3.

3. IO Introduction to module configuration

IO module of GCAN-PLC series products is an automatic configuration method, which does not require manual configuration. The extended IO is inserted into the back of the PLC and automatically has an address. It is only necessary to create a variable with the actual address in the program declaration section, then this variable can represent the actual input and output points.

For example: `A10 AT% I0.0:INT;`

That is to say, the variable `A10` represents the input point whose starting address is `I0.0`, and the data length is `16` bits. Analog IO of GCAN series

The data length occupied by each channel is `16` bits, so `A10` can represent exactly one channel of analog quantity.

GCAN series extended IO is related to the sequence of matching to the back of the PLC . Start with the IO closest to the PLC , address I0.0

Or Q0.0 , the ones at the back go to the back in turn. The input does not affect the address of the output, and the output does not affect the address of the input .

For example, the IOs behind the GCAN-PLC are 1008 , 2008 , 3654 , and 4652 in sequence . Then the first addresses of these 4 modules are I0.0 , Q0.0 , I1.0 , Q1.0 respectively. Among them , the 8 channel addresses of 1008 are I0.0~I0.7 , which can be defined as DI0 AT%I0.0:BOOL; to I0.7:BOOL; , or DI1008 AT%I0.0:BYTE; , the whole piece of 1008 The length is 1 byte, so the first channel address of 3654 is I1.0 , the range is I1.0~I3.0 , and so on; the output is the same , just replace I with Q.

The number of channels of each module and the length occupied by each channel are shown in the following table, which is convenient for calculating the IO address.

product signal	Function	number of channels	The data length occupied by each channel
GC1008	Digital input (PNP)	8	1 bit
GC1018	Digital input (NPN)	8	1 bit
GC2008	Digital output (PNP)	8	1 bit
GC2018	Digital output (NPN)	8	1 bit
GC1502	Pulse counter input	2	32 bits for count , 32 bits for frequency
GC2302	Pulse output (5V)	2	16 bits for speed , 32 bits for position
GC2204	relay output	4	1 bit (1 2204 module occupies 8 bits, the last 4 bits occupy null)
GC3604	Analog input (-5V~+5V)	4	16 bit
GC3624	Analog input (-10V~+10V)	4	16 bit
GC3644	Analog input (0~20mA)	4	16 bit
GC3654	Analog input (4~20mA)	4	16 bit
GC3664	Analog input (0V~+5V)	4	16 bit
GC3674	Analog input (0V~+10V)	4	16 bit
GC3804	PT100 temperature acquisition (two-wire system)	4	16 bit
GC3844	K-type thermocouple acquisition	4	16 bit
GC3822	PT100 temperature acquisition (three-wire system)	2	16 bit
GC3854	J-type thermocouple acquisition	4	16 bit
GC3864	T-type thermocouple acquisition	4	16 bit
GC4602	Analog output (-5V~+5V)	2	16 bit
GC4622	Analog output (-10V~+10V)	2	16 bit

GC4642	Analog output (0~20mA)	2	16 bit
GC4652	Analog output (4~20mA)	2	16 bit
GC4662	Analog output (0V~+5V)	2	16 bit
GC4672	Analog output (0V~+10V)	2	16 bit
GC4674	Analog output (0V~+10V)	4	12 bits (16 bits per channel , upper 4 bits are occupied)

3. Getting Started with Function Blocks

1. basic instruction set

Basic function block index table

name	Function	Chapter Index
CTU	the number of pulses of the input CD by addition	3.1.1
CTD	the number of pulses input to CU by subtraction	3.1.2
CTUD	Function block CTUD Count rising and falling edges pulse.	3.1.3
TON	timing function block	3.1.4
DT_CLOCK	clock function block	3.1.5
F_TRIG	Function block F_TRIG detects input operation CLK the state of the falling edge.	3.1.6
R_TRIG	function block R_TRIG detects the input operation CLK State change on rising edge.	3.1.7
SR	Function block SR statically converts a data element (output Q1) is a boolean 1 or 0 .	3.1.8
RS	Function block RS dynamically switches a data element (output Q1) is a boolean 1 or 0 .	3.1.9
PID	PID control	3.1.10
TOF	timing function block	3.1.11
TP	timing function block	3.1.12
CONCAT_STRING	Concatenation of two strings	3.1.13
MOD	remainder	3.1.14


Basic function index table

Function name	Function	Chapter Index
ABS (temporarily unavailable)	absolute value	3.2.1
ACOS	arc cosine	3.2.2
ADD	Sum of two numbers (+ in ST)	3.2.3
ASIN	arcsine	3.2.4
ATAN	arctangent	3.2.5
COS	cosine	3.2.6

DELETE	subcharacters of length L starting at position P string	3.2.7
EQ (not available in ST)	true if the inputs are equal	3.2.8
EXP	Exponential power function	3.2.9
FIND	string lookup	3.2.10
GE (not available in ST)	comparison function (>=)	3.2.11
GT (not available in ST)	comparison function (>)	3.2.12

INSERT	insert string	3.2.13
LE	comparison function (\leq)	3.2.14
LT	comparison function ($<$)	3.2.15
LEFT	L characters from the left of the string	3.2.16
LEN	string length	3.2.17
LIMIT	Limit	3.2.18
LN	logarithm to base e	3.2.19
LOG	base 10 logarithm	3.2.20
MAX	Maximum value of all input values	3.2.21
MID (temporarily unavailable)	N characters in the middle of the string	3.2.22
MIN	Minimum of all input values	3.2.23
NE (not available in ST)	not equal (\neq)	3.2.24
POINTER (data type)	pointer	3.2.25
RIGHT	Take the L characters from the right of the string	3.2.26
ROL	Rotate the string to the left	3.2.27
ROR	Rotate the string to the right	3.2.28
SHL	shift string left	3.2.29
SHR	right shift string	3.2.30
SIN	Sine	3.2.31
SQRT	square root	3.2.32
TAN	Tangent	3.2.33
XOR	XOR	3.2.34

Note: a lot of content in this chapter will involve the rising edge and falling edge, so it is explained here uniformly, the rising edge is from 0 to 1 process, the next falling edge is from 1 to 0 process, a function block is enabled by the rising edge trigger, indicating that the effective enable of the function block is neither 0 nor 1, but the transition of the enable bit from 0 to 1 is detected. The upward arrow in the figure is the rising edge, and the downward arrow is the falling edge.



3.1.1 CTU

```
inst1_Ctu(CU := , RESET := , PV := | := Q, := CV);
```

function block **CTU** calculates the number of pulses input to **CU** by addition. During

initialization, the counter is set to 0; if **RESET** receives a value of 1, the count value will be reset; each rising edge of the input **CU** causes the counter to increase by 1; the output **CV** is the current count value . If the count value is less than the **PV** upper limit, the output **Q** will be a Boolean 0, and if it is greater than or equal to the **PV** value, **Q** will be set to 1.

enter:

CU : Boolean counter

pulse **RESET** : Boolean

restart counter **PV** :

Integer count upper

limit

output:

Q : Whether the boolean

counter has reached the upper

limit value **CV** : Integer

current counter value

3.1.2 CTD

```
inst0_CTD(CD := , LOAD := , PV := | := Q, := CV);
```

function block **CTD** calculates the number of pulses input to **CD** by subtraction . During initialization, the counter is set to **0** ; if **LOAD** is set to **1**, the **PV** value will be the initial value of the counter. Each rising edge of input **CD** will decrement the counter by **1** ; output **CV** is the current value of the counter. If the counter value is positive, output **Q** will be set to **0** ; if the counter value is **0** or negative, output **Q** will be set to **1** .

enter:

CD : Boolean count pulse,

rising edge **LOAD** : Boolean

setting condition

PV : Integer

initial value

output:

Q : Boolean signal (whether
the count value reaches 0) **CV** :

Integer count value

3.1.3 CTUD

```
inst2_CTUD(CU := , CD := , RESET := , LOAD := , PV := | := QU, := QD, := CV);
```

function block **CTUD** counts rising and falling pulses. During initialization, the counter is set to 0. Input each rising edge of **CD**; the counter will be incremented by 1; and each falling edge of **CD**, the counter will be decremented by 1; if **LOAD** is 1, the **PV** value will be preset to the counter; if the **RESET** value is 1, the count

The counter will reset; if the count value is less than the **PV** preset value, the output **Q** will display a boolean value of **0**; if the count value reaches or exceeds the preset value, the output **Q** will be set to **1**; if the count value is positive, the output **QD** will be a boolean value **Value 0**; if the count value is **0** or negative, output **QD** will be set to **1**.

enter:

CU : Boolean calculation of

rising and falling pulses **CD** :

Boolean calculation of

rising and falling pulses

RESET : Boolean reset

condition **LOAD** : Boolean

download condition

PV : Integer

download value

output:

QU : Boolean signal (whether the

count value reaches the **PV** value) **QD** :

Boolean signal (whether the count

status is **0**) **CV** : Integer count

status

3.1.4 TON

```
|inst3_TON(IN := , PT := | := Q, := ET);
```

input **IN** has a rising edge, the timer **TON** will be started , and the delay time is specified by **PT** ; when the timer is running, the output **Q** will be set to 0 , if the time is up, the **Q** state will become 1 , and its value will be maintained until **IN** becomes 0 ; If the **PT** value changes after the timer runs , it is only valid when the next rising edge **IN** is generated ; the output **ET** is the current timer value. If the time is up, **ET** will keep its value as long as the input **IN** value is 1 ; if **IN** becomes 0 , the **ET** value will be 0 ; if the input **IN** is on, the output **Q** will turn on after the specified delay time.

enter:

IN : Start

condition **PT** :

time Initial time

value Output:

Q : bool timer state

ET : time current time value

3.1.5 DT_CLOCK

```
inst4_DT_CLOCK(SET_YEAR := ,  
                SET_MONTH := ,  
                SET_DAY := ,  
                SET_HOUR := ,  
                SET_MINUTE := ,  
                SET_SECOND := ,  
                SET :=  
                := YEAR,  
                := MONTH,  
                := DAY,  
                := HOUR,  
                := MINUTE,  
                := SECOND,  
                := RELTIME,  
                := ERROR);
```

This function block is to set the system clock function block, **SET_YEAR**, **SET_MONTH**, **SET_DAY**, **SET_HOUR**, **SET_MINUTE**, **SET_SECOND**, respectively set the initial year, month, day, hour, minute, second; **SET** is set, this parameter is set to **1** and then reset **0**, the function block is valid; **YEAR**, **MONTH**, **DAY**, **HOUR**, **MINUTE**, **SECOND** are the current time year, month, day, hour, minute and second respectively. **RELTIME** represents the number of seconds from the computer epoch (January 1, 1970 0:00) to the current time.

ERROR indicates the display of error messages.

3.1.6 F_TRIG

```
inst5_F_TRIG(CLK := | := Q);
```

function block **F_TRIG** detects the state of the input operation **CLK**; detects the change of the state from **1** to **0** in the processing cycle by outputting **Q**; in one processing cycle, that is, when **CLK** is detected and indicated by the falling edge, the output is **1**.

enter:

CLK : Boolean operation input, only

for falling edge detection output:

Q : Boolean operation output, only set when **CLK** has a falling edge.

3.1.7 R_TRIG

```
inst6_R_TRIG(CLK := | := Q);
```

function block **R_TRIG** detects the state change of the input operation **CLK** ; if the state changes from **0** in the processing cycle, it is detected and indicated by the output **Q** being **1** ; only when the change of the **CLK** state within one cycle is detected and a rising edge is generated , the output state is **1**.

enter:

CLK : Boolean input active

on rising edge Output:

Q : Boolean output ; indicates rising edge of **CLK**

3.1.8 SR

```
inst1_SR(SET1 := , RESET := | := Q1);
```

function block **SR** statically converts a data element (output **Q1**) to a Boolean value of **1** or **0** ; the conversion between **0** and **1** is based on the Boolean input operations **SET1** and **RESET** ; at the beginning of the process, the output **Q1** is initialized to **0** , if the value of **SET1** is **1** , Function block action, output **Q1** will be set to **1** ; after that, **SET1** changes will not change output **Q1** ; input **RESET** is always set to **0** when **Q1** is **1** , if it can be reset; if both inputs have the value **1** , the set will Dominance, that is, **Q1** will be set.

enter:

Set1 : bool set

condition **Reset** :

bool reset

condition output:

Q1 : output state of bool bistable element

3.1.9 RS

```
inst0_RS(SET := , RESET1 := | := Q1);
```

The function block **RS** dynamically switches a data element (output **Q1**) to a Boolean value of **1** or **0**. Switching between **0** and **1** is based on the Boolean input operation

SET and **RESET1** ; before processing, the output **Q1** is initialized to **0**, if the **SET** value is **1**, the function block is active, and the output **Q1** will be set to **1** ; after that, the **SET** change does not change the output **Q1** ; when the input **RESET1** is **1**, always set **Q1** to **0** ; For example, it can reset the output; if both inputs have a value of **1**, the reset will dominate. That is, **Q1** will reset.

enter:

Set : bool set

condition **Reset1** :

bool reset condition

output:

Q1 : output state of bool bistable element

3.1.10 PID

```
inst2_PID1(ENABLE := , SPV := , APV := , KP := , KI := , KD := | := READY, := CO, := ERROR);
```

This function block is used to implement **PID** control, if a rising edge is detected at the input **ENABLE**, the function block receives the control parameters **KR**, **TO**, **TD**, **TI** and **BIAS** and starts the controller. In the first operation, the setpoint and the last actual value are set to the current actual value. The first time the correction variable is calculated, the initial deviation value is usually present, because the proportional gain, integral gain and derivative gain all default to **0** for the first time . The performance of the controller will be affected by the control parameters. If **TI=t#0ms**, the integral gain of the controller will not be calculated and will be assigned a value of **0**. If **TD=t#0ms**, the value of the differential gain will be assigned to **0**. If the gain of the parameter **KR** is **0**, the proportional gain is not needed. Since the **KR** gain is related to both the proportional gain and the derivative gain, the integral and derivative gains are set to **1** here. **P** controller: **TI=TD=0**, **KR ≠ 0**, integral and differential gains are **1**. **PI** controller: **TD=0**, **KR**, **TI ≠ 0**. **PID** controller: **KR**, **TI**, **TD**

$\neq 0$. There are many ways to determine control parameters (tangent to inflection point, oscillation test) , and parameters can also be determined by simulation tools. However, it is necessary that the complete control system be described as a model in terms of frequency and phase response . Models of the relevant transfer parameters of the control system can be built from known values and states and used to determine the parameters during the simulation. The set value, actual value, deviation value and correction variable are used as standard variables. The value of these standard variables varies from 0.0 to 1.0. When the function block starts to execute, the valid range of the deviation will be checked. When the deviation value exceeds the valid range Outputting ERROR will report an error. Setpoints and actual values are not checked during program run. The function block limits the value of the correction variable and the integral sum, and if the result of the calculation is negative, the variable value is set to 0. If the value exceeds 1, the variable value is set to 1. In addition, the integral sum is affected by the correction variable, also following the following rules:

If the value of the correction variable is

greater than 1, the integral sum is calculated

as follows: Integral sum = 1 - (proportional gain

+ derivative gain)

If the value of the correction variable is

greater than 0, the integral sum is calculated

as follows: Integral gain = 1- (proportional

gain + derivative gain)

ENABLE : If the input rising edge is detected, the control factors KR, T0, TI, TD will be received by the system, and the accounting

Calculate the integral sum of the deviation from the initial value. The outputs READY, ERROR and CO are reset by setting ENABLE=0. The function block checks the valid area and, if necessary, displays an overflow error at the output ERROR during the transmission of parameters T0 and BIAS;

SPV : controller standard setting value (control variable), valid range is 0.0~1.0, the function block will automatically detect the parameters (but will not detect overflow errors)

APV : controller standard actual value (process variable), valid range is 0.0~1.0, the controller will automatically detect the parameter (but will not detect overflow error)

KP :

proportional

coefficient;

KI : integral

coefficient;

KD :

differential

coefficient;

READY : Output state of the PID controller TRUE = the function blocks of the controller are fully parameterized and have entered the pre-operational state. FALSE= The function block of the controller is not fully parameterized or incorrectly parameterized (the control parameter is outside the valid value range) , the controller does not enter pre- operational mode.

CO : the output of the controller, calculate the correction variable of the controller (value range 0.0~1.0)

ERROR : The error code indicates the information of the execution

result of the function block, the possible error codes are

defined as follows: **0** : No error occurred during the execution

of the function block

8 : The value of the specified parameter BIAS is invalid (less than 0 or greater than 1)

16 : The specified value of parameter T0 is invalid (time equals 0)

3.1.11 TOF

```
inst3_TOF(IN := , PT := | := Q, := ET);
```

If the input state IN is 1, it will transfer to the output Q without delay ; if there is a falling edge, a timing function will start, and the delay time

There is **PT** decision in between; when the timer overflows, the operand **Q** changes to state **0**; if the **PT** value changes after startup, it will take effect after the next rising edge **IN**; **ET** contains the current time value, if the time is up, **ET** will Hold its value until the **IN** value is **0**. If the **IN** state changes to **1**. The **ET** value also becomes **0**; if the input **IN** is off, the output **Q** will also be off after a specified delay.

enter:

IN : Start

condition **PT** :

time Initial time

value Output:

Q : **bool** timer

state **ET** : **time**

current time

value

3.1.12 TP

```
|inst4_TP(IN := , PT := | := Q, := ET);
```

A rising edge of the input **IN** will start the time function **TP**, and the running time is determined by **PT**; when the timing is running, the output **Q** is set to **1**, and any change of the input **IN** will be invalid; if it is started, the **PT** value will change to the next rising edge. **IN** takes effect; output **ET** is the current time value. If the time elapses when the **IN** value is **1**, **ET** will hold its value; any rising (falling) edge occurs without the timer running, and a command time pulse will be generated at output **Q**.

enter:

IN : Start

condition **PT** : time

Initial time value

output:

Q : bool timer state

ET : time current time value

3.1.13 CONCAT_STRING

```
ADC:=inst1_CONCAT_STRING(EN := , IN1 := , IN2 := | := EN0, := OUT);
```

Strings **IN1** and **IN2** are concatenated into a new string and loaded into the working register. Strings **IN1** and **IN2** are concatenated in ascending order from left to right.

enter:

In1 : STRING first

string **In2** : STRING

second string Returns:

OUT : STRING two strings concatenated

3.1.14 MOD

```
inst0_MOD_USINT(EN := 1, IN1 :=122 , IN2 :=3 | ENEN := EN0, YUE := OUT);
```

MOD is the remainder, as shown in the figure, the remainder of **122** divided by **3** is **2**, and the result of **yue** is **2**.

3.2.1 ABS

```
RI:=abs(YUE);
```

figure, **RI** is the absolute value of **YUE**. The data types of **RI** and **YUE** must be the same.

3.2.2 ACOS

```
mama:=acos(mc);
```

figure, **mama** is the arc cosine of **mc**. Among them, the data types of **mama** and **mc** must be real .

3.2.3 ADD

The sum of two numbers is equivalent to +

3.2.4 ASIN

```
| MC:=asin(6.0);
```

Arcsine: As shown in the figure, MC and 6.0 must be **real** types.

3.2.5 ATAN

```
| MC:=atan(6.0);
```

Arctangent: As shown in the figure, MC and 6.0 must be **real** types.

3.2.6 COS

```
| MC:=cos(6.0);
```

Cosine: As shown in the figure, MC and 6.0 must be **real** types.

3.2.7 DELETE

```
| ADC:=DELETE(MB, 1, 2);
```

enter:

IN1 : The basic string of the STRING part that needs to be removed

L : ANY_INT (according to support)to delete the length

of the partial substring. L<0 is invalid. **P** : ANY_INT

(as supported)substring start position. P<0 is

invalid.


return:

STRING A shortened string. **IN1** parameter is invalid.

DELETE function deletes a substring of length L in the given string

IN1 starting at position **P**. As shown in the figure, delete the character string **MB** starting from the second character and having a length of **1**.

3.2.7 EQ (cannot be used in ST)



in the figure, if **IN1=IN2**, output **1**, otherwise output **0**.

3.2.9 EXP

```
MC:=exp(6.0);
```

The exponent of **e**: As shown in the figure, the value of **MC** is the **6th** power of **e**.

3.2.10 FIND

```
LS:=FIND(MB,wfe);
```

Find a string within another

string. enter:


IN1: String sequence of base strings to look for ; make this string valid via working register **IN2**: String String to look for from the **IN1** base string .

return:

The position of the first occurrence of **INT**


from the **IN1** base string. If found, the first character position of the sequence goes into the working register, otherwise, **0** goes into the working register. If more than one is found, the character position found first goes into the working register.

3.2.11 GE



in the figure, if **IN1>=IN2**, output 1, otherwise output 0.

3.2.12 GT



in the figure, if **IN1>IN2**, output 1, otherwise output 0.

3.2.13 INSERT

```
ADC:=INSERT(MB,wfe,2);
```

enter:

IN1 : STRING string **IN2 :**

STRING string to be

inserted


P : ANY_INT (as supported) starting position.

P<0 and **P>LEN(IN1)** are invalid and return:

STRING Combination of strings. **IN1** invalid parameter


INSERT function inserts the string **IN2** into the string **IN1**. The concatenated string consists of the first **P** characters of **IN1**, the complete **IN2** and the remaining **IN1**.

3.2.14 LE



in the figure, if **IN1<=IN2**, output 1, otherwise output 0.

3.2.15 LT



in the figure, if **IN1<IN2**, output 1, otherwise output 0.

3.2.16 LEFT

ADC:=LEFT(MB, 2);

LEFT function gets the left **L** characters of the current string and puts them into the working register. The input operand **L** defines the number of input characters.

enter:

IN : string type string

L : ANY_INT (according to support)

number of characters to get

returns:

L characters to the left of **STRINGIN**, **IN** if the parameter is invalid

3.2.17 LEN

```
LS:=LEN(MB);
```

function **LEN** calculates the length of the string (input operand type is **STRING**)

and puts the length value in the working register as an **INT number**. enter:

In:STRING

string returns:

INT IN length

3.2.18 LIMIT

```
SHI:=LIMIT(56,YUE,89);
```

MN and **MX** values define upper and lower limits. The function compares the **IN** value with the **MN** and **MX** sizes. If **IN** is between the two limits , it will be loaded into the working register. If **IN** is less than **MN**, output **MN** value .If **IN** is greater than **MX**, output **MX** value.

Input: **MN** :

Any_Num lower

limit **IN** :

Any_Num test

value **MX** :

Any_Num upper

limit Return:

Any_Num one of the input values

3.2.19 LN

```
mama:=LN(6.0);
```

logarithm to base e

in the figure, where mama and 6.0 must be real types

3.2.20 LOG

```
mama:=LOG(6.0);
```

Logarithm with base 10: As shown in the figure, where mama and 6.0 must be real types.

3.2.21 MAX

```
NIAN:=MAX(1,2,3,4,5,6,9,8);
```

Take the maximum value of all numbers: as shown, the final output value is 9.

3.2.22 MIN


```
NIAN:=MIN(1,2,3,4,5,6,9,8);
```

Take the minimum value of all numbers: as shown, the final output value is 1.

3.2.23 MOD

See 3.1.14 for details

3.2.24 NE



equal: As shown in the figure, if IN1<>IN2, output 1, otherwise output 0.

3.2.25 POINTER

Pointer: **POINTER** is a data type that is a pointer. In ST, the role of a pointer is to point to an array. E.g:

```
PLT:=&ABUFER;
```

Among them, PLT is a variable of pointer type, and ABUFER is an array variable. In some function blocks, pointer-type variables are required to call arrays, read or write data.

3.2.26 RIGHT

```
adc:=right(wfe, 2);
```

enter:

IN:STRING string

L:ANY_INT (according to support)

the number of characters to get

returns:

STRING the rightmost character of the string L, IN if the argument is invalid

RIGHT function loads the right part of the current string into the working register . The input operand L defines the number of characters to be entered.

3.2.27 ROL

```
b:=rol(a, 2);
```

Rotate

left:

Enter:

IN : ANY_BIT bit

form N : UINT left

shifted by the

number of bits

Returns:

ANY_BITIN, rotate left by **N** bits

Bits shifted out to the left are rotated to the right.

3.2.28 ROR

```
b:=ror(a,2);
```

Rotate

right:

Enter:

IN : ANY_BIT bit

form N : UINT

right shift

number Returns:

ANY_BITIN, rotate right by N bits

Bits shifted out to the right are rotated to the left.

3.2.29 SHL

```
b:=shl(a,2);
```

Shift

left:

Enter:

IN : ANY_BIT bit

form N : UINT

left shift

number Returns:

ANY_BITIN, shift left by N bits

The rightmost bit is filled with zeros

3.2.30 SHR

```
b:=shr(a,2);
```

Shift right:

Input: IN :

ANY_BIT bit form

N : UINT right

shift number

Return:

ANY_BITIN, shift right by N bits

Leftmost bits are zero-padded

3.2.31 SIN

```
mc:=sin(5.0);
```

Sine: As shown in the figure, the data types of mc and 5.0 are real.

3.2.32 SQRT

```
mc:=sqrt(5.0);
```

Square root: As shown in the figure, the data types of mc and 5.0 are real. The value of mc is .

3.2.33 TAN

```
mc:=tan(5.0);
```

Tangent: As shown in the figure, the data types of mc and 5.0 are real.

3.2.24 XOR

```
b:=235 xor 119;
```

XOR: As shown, the result of b is 99.

2. Extended function block

name	Function	Chapter Index
Serial function block		
USART_INIT	Serial port initialization	3.3.1
USART_STATE	Serial port status	3.3.2
USART_READ_BIN	Serial read (binary character stream)	3.3.3
USART_WRITE_BIN	Serial write (binary character stream)	3.3.4
USART_READ_CHR	Serial read (character)	3.3.5
USART_WRITE_CHR	Serial write (character)	3.3.6
USART_READ_STR	Serial read (string)	3.3.7
USART_WRITE_STR	Serial write (string)	3.3.8
EXT_USART_INIT	Initialize the extended serial interface	3.3.9
EXT_USART_READ_BIN	Extended serial interface to read binary character stream	3.3.10
EXT_USART_WRITE_BIN	Extended serial interface to write binary character stream	3.3.11
CAN function block		
CAN_INIT	CAN initialization	3.3.12
CAN_MESSAGE_READ8	CAN read	3.3.13
CAN_MESSAGE_WRITE8	CAN write	3.3.14
CAN_NMT	Send NMT management commands	3.3.15
CAN_GET_STATE	Used to request device node status	3.3.16
CAN_REGISTER_COBID	Used to register or delete PDOs and CAN Layer 2 Messages	3.3.17
CAN_PDO_READ8	Function block for reading PDO data	3.3.18
CAN_PDO_WRITE8	Function block for sending PDO data	3.3.19
CAN_SDO_READ8	Read Object Dictionary via SDO	3.3.20
CAN_SDO_WRITE8	Write object dictionary through SDO	3.3.21
CAN_SDO_READ_STR	Read string information in object dictionary through SDO	3.3.22
CAN_SDO_WRITE_STR	Write string information in object dictionary through SDO	3.3.23
CAN_SDO_READ_BIN	Read the binary data of the object dictionary through SDO	3.3.24
CAN_SDO_WRITE_BIN	Write the binary data of the object dictionary through SDO	3.3.25
CAN_RECV_EMCY	Read urgent messages from any node	3.3.26
CAN_RECV_EMCY_DEV	Read urgent messages of a specific node	3.3.27
CAN_WRITE_EMCY	Send application-specific emergency messages	3.3.28
CAN_ENABLE_CYCLIC_SYNC	Activate SYNC cycle synchronization	3.3.29
CAN_SEND_SYNC	Send sync frame (single frame)	3.3.30
CAN_ENABLE_CYCLIC_NODE_GUARD	Cyclic Send Node Protection	3.3.31

CAN_SEND_NODE_GUARD	Sending Node Protection (Single Frame)	3.3.32
CAN_RECV_BOOTUP_DEV	Read specific node bootup messages	3.3.33
CAN_RECV_BOOTUP	Read all node bootup messages	3.3.34
CAN_FILTER	CAN bus filtering	3.3.35
Ethernet, GPRS and MQTT function blocks		
LAN_INIT	Initialize the Ethernet interface	3.3.36
LAN_GET_TCPCONNECT_SOCKET	Used to establish a socket connection on the TCP side	3.3.37

LAN_TCP_SERVER_CREATE	Create a TCP SERVER connection	3.3.38
LAN_TCP_CLIENT_CONNECT	Create a TCP CLIENT connection	3.3.39
LAN_TCP_CLIENT_CLOSE	Close the TCP Client connection	3.3.40
LAN_TCP_RECV_BIN	Read binary character stream from TCP port	3.3.41
LAN_TCP_SEND_BIN	Speak binary character stream to TCP port	3.3.42
LAN_UDP_CREATE_SOCKET	Create UDPsocket connection	3.3.43
LAN_UDP_CLOSE_SOCKET	Close UDP SOCKET connection	3.3.44
LAN_UDP_RECVFROM_BIN	read UDP data	3.3.45
LAN_UDP_SENTO_BIN	send UDP data	3.3.46
LAN_UDP_RECVFROM_STR	read UDP data (string)	3.3.47
LAN_UDP_SENTO_STR	send UDP data (string)	3.3.48
EXT_GPRS_INIT	Extended 4G functional block	3.3.49
EXT_GPRS_STATUC	Extended 4G Status	3.3.50
EXT_GPRS_READ_BIN	Extended 4G read	3.3.51
EXT_GPRS_WRITE_BIN	Extended 4G write	3.3.52
MQTT_INIT		3.3.53
MQTT_STATUS		3.3.54
MQTT_SEND		3.3.55

Modbus function block

MODBUS_SLAVE_INIT	Initialize modbus-RTU slave interface	3.3.56
MODBUS_SLAVE_CTRL	Execute Modbus-RTU slave control commands	3.3.57
MODBUS_MASTER_INIT	Initialize the modbus-RTU master interface	3.3.58
MODBUS_MASTER_CTRL	Execute Modbus-RTU master control commands	3.3.59
MODBUS_TCP_SLAVE_INIT	Initialize MODBUS_TCP slave interface	3.3.60
MODBUS_TCP_SLAVE_CTRL	Execute the MODBUS_TCP slave control instruction	3.3.61
MODBUS_TCP_MASTER_INIT	Initialize MODBUS_TCP U master interface	3.3.62
MODBUS_TCP_MASTER_CTRL	Execute the MODBUS_TCP master control command	3.3.63


Clock, parameter storage function block

DT_CLOCK	Used to set the real-time clock and read time information	3.3.64
RTC	system time function block	3.3.65
GETSYSTEMDATEANDTIME	Get system time	3.3.66
SETSYSTEMDATEANDTIME	set system time	3.3.67
GETDATESTRUCT	convert date to struct	3.3.68
NVDATA_BIT	Read or write data to EEPROM	3.3.69
NVDATA_BIN	Read or write data to EEPROM (binary stream)	3.3.70
NVDATA_STR	Read or write data (string) to EEPROM	3.3.71

Pulse output, counting function block		
EXT_MOTOR_PWM_INIT	GC2302 initialization function block	3.3.72
EXT_MOTOR_EN	GC2302 enable motor function block	3.3.73
CTU	addition count	3.3.74
CTD	Subtraction count	3.3.75
CTUD	double count	3.3.76
INIT_TBL	Initialization list storage function block	3.3.77
FIFO_TBL	List members first in first out	3.3.78

LIFO_TBL	List members first in last out	3.3.79
ADD_TBL	Add list members	3.3.80
COUNT_TBL	list member count	3.3.81
other function blocks		
PID1	PID control	3.3.82
SYS_PLA_RESET	System reset restart function block	3.3.83
PTO_PWM	Pulse output PTO function block	3.3.84
PTO	Execute pulse timer	3.3.85
GETVARDATA	Get variable information	3.3.86
GETVARFLATADDRESS	Get memory space address	3.3.87
GETTASKINFO	Get the execution time of each task cycle	3.3.88

3.3.1 USART_INIT



用于初始化串行接口

Definition of Operands

BAUD: Set the baud rate used in serial communication, which can be set to the following values: 1200, 2400, 9600, 19200, 38400, 57600 ,**115200** ;

DATABITS: Set the number of data bits to be used, for example: **7** : data bits ; **8:8** data bits;

PARITY: Set parity for secure data transfer, for example: **0**: no parity

1: odd check

2: even check;

STOPBITS : Set the number of stop bits to be used, for example: 1:1 stop bit; 2:2 stop bits;

PROTOCOL: Set the handshake protocol rules to use, for example:

0: no protocol

1: XON/XOFF

2: hardware handshake (RTS/CTS

flow control); **ENABLE** : enable

or disable serial interface:

true: enable serial interface

false: close the serial interface;

PORT: Serial interface definition number to be used, 1 is RS232 , 2 is RS485 ;

ERROR : The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0 : No error occurred while executing the function block

1 : A hardware error occurred while executing the function block

2 : The selected interface (**PORT**) does not support

4 : The selected baud rate (**BAUD**) is not supported

8 : The selected number of data bits (**DATABITS**) are not supported

16 : The selected parity (**PARITY**) is not supported

32 : The selected stop number is not supported

64 : The selected

handshake protocol does

not support Description:

The function block initializes the serial interface with the specified parameters. Errors that may occur during execution are shown in **ERROR** . Different error codes will be superimposed and need to be split (for example, 6=2+4 means the selected

interface is not supported and the selected baud rate is not supported). The following routine uses the function block **USART_INIT** to initialize the serial interface, and sets the following parameters: serial port number is **RS485**, 9600 baud rate, 8 data bits, no parity, 1 stop bit, no protocol.

Sample program:

VAR

```
mPORT:USINT;  
  
xInitOk : BOOL := FALSE; inst0_USART_INIT:USART_INIT;  
  
xE:usint;  
  
END_VAR  
  
  
  
mPORT:=2;  
  
if xInitOk=false then  
  
    inst0_USART_INIT(BAUD :=9600 , DATABITS :=8 , PARITY :=0 , STOPBITS :=1 , PROTOCOL :=0 ,  
ENABLE :=1 , PORT :=mPORT| xE := ERROR);  
  
    if xE=0 then xInitOk :=TRUE  
  
end_if;  
end_if;
```

3.3.2 USART_STATE

INST0_USART_STATE	
EN	USART_STATE
sint	RTS
sint	DTR
sint	CLR
usint	PORT
	CTS
	DSR
	DCD
	RI
	SORXQ
	CBRXQ
	SOTXQ
	CBTXQ
	SIOSTAT
	ERROR

用于设置和检索串行接口的状态信息

Definition of Operands

RTS : RTS signal state to set

-1 : Does not

affect the current

state 0 :

Deasserts the

signal

1 : Set the signal to be valid

DTR : DTR signal state to be set

-1 : Does not

affect the current

state 0 :

Deasserts the

signal

1 : Set the signal to be valid

CLR : clear send and receive buffers

-1 : does not affect the current state

1 : Clear the receive buffer

2 : Clear the send buffer

3 : Clear transmit and

receive buffers **PORT** :

Serial interface definition

number to be used **CTS** :

Determine **CTS** signal state

-1 : Signal is

not supported **0** :

Signal is set to

invalid

1 : Signal set to valid

DSR : Determined **DSR** signal state

-1 : Signal is

not supported **0** :

Signal is set to

invalid

1 : Signal set to valid

DCD : Determined **DCD** signal state

-1 : Signal is

not supported **0** :

Signal is set to

invalid

1 : Signal set to valid

RI : Determined **RI** signal state

-1 : Signal is

not supported **0** :

Signal is set to

invalid

1 : Signal set to valid

SORXQ : Determines the overall size of the receive

buffer (size of the Rx queue) **CBRXQ** : Current number of

characters in the receive buffer (number of bytes in

the Rx queue)

SOTXQ : Determines the overall size of the transmit buffer (Tx queue size) **CBTXQ** : Current number of characters in the transmit buffer (Tx

bytes in the queue)

SIOSTAT: USART specific status register (eg: overrun, framing

error, etc .; see respective controls) **ERROR**: Error code

information describing the result of function block execution.

Possible error codes are defined as follows: **0**: No error occurred

while executing the function block

1: A hardware error occurred while executing the function block

2: The selected interface (**PORT**) is not supported

8: If hardware handshake is active, the **RTS** signal is not affected (**USART_INIT**),
PROTOCOL : =2

16: If hardware handshake is active, **DTR** signal is not affected (**USART_INIT**),
PROTOCOL : =2

32: Direct setting of **RTS** signal is not supported

64: Direct setting of **DTR** signal is not supported

128: Clearing send and receive buffers is not supported

255: The selected interface

(**PORT**) is not initialized

Description:

The function block is used to set and retrieve the status information of the serial interface. Actual availability or support of parameters depends on the corresponding hardware properties of the interface. Please see each control manual for more detailed information. Possible block errors during execution are displayed at output **ERROR**, several errors can be signaled simultaneously (eg **24=16+8=> DTR and RTS signals are not affected during active hardware handshake**).

The following sample program shows how the application function

block **USART_STAT** determines the current state of the serial interface. Sample program:

VAR

FB_USARTState : USART_STATE;

xStatOk : BOOL := FALSE;

siCts : SINT;

siDsr : SINT;

siDcd : SINT;

```
siRi : SINT;  
  
udiSoRrQ : UDINT;  
  
udiCbRxQ : UDINT;  
  
udiSoTxQ : UDINT;  
  
udiCbTxQ : UDINT;  
  
iUSARTStat : INT;  
  
END_VAR
```

(* ----- Check USART State-----*)

CheckState:

(* read current state from serial interface *)

```
CAL FB_USARTState (RTS := USART_STAT_DO_NOT_CHANGE,  
DTR := USART_STAT_DO_NOT_CHANGE,CLR := USART_STAT_DO_NOT_CHANGE,PORT := PORTNUM  
|siCts := CTS,siDsr := DSR,siDcd := DCD,siRi := RI,udiSoRrQ := SORXQ,udiCbRxQ := CBRXQ,udiSoTxQ :=  
SOTXQ,udiCbTxQ := CBTXQ,iUSARTStat := USARTSTAT)
```


LD FB_USARTState.ERROR

EQ USART_STAT_ERR_SUCCESS

ST xStatOk

... RET

3.3.3 USART_READ_BIN



用于从串行接口读取二进制字符流

Definition of Operands

ENABLE : enable or disable the input of the

function block ; **PTR_RXDATA** : address used to

receive the read data byte object ;

MAXLENGTH : the maximum number of bytes to read, if it is 0, the number

of bytes to be read is determined by **PTR_RXDATA** ; **ETXCHR** : the end delimiter

of the binary character stream (only check if **CHECKBOX=TRUE**) ;

CHKETX : enable / disable end delimiter character check, **FALSE=**end delimiter character is not checked ,**TRUE=**check end delimiter character is active ;

PTR_RXDATA : The serial interface definition number to be used, 1 is RS232 , 2 is RS485;

CONFIRM : Displays the completion of the function block, **FALSE=**reception is not successfully completed or terminated after an error ,**TRUE=**reception is completed successfully, characters of length RXLENGTH are available in the object addressed by **PTR_RXDATA** ;

RXLENGTH : Number of characters read (if **ERROR: =0**) ;**ERROR** : Error code describing information about the result of function block execution. Possible error codes are defined as follows:

0: No error occurred while executing the function block

- 1:** A hardware error occurred while executing the function block
- 2:** The selected interface (**PORT**) is not supported
- 8:** The character of the terminal separator is not received, and the character of the length of **MAXLENGTH** is received and terminated
- 128:** pointer to object of unsupported data type

255: The selected interface

(PORT) is not initialized

Description:

The function block reads the binary data stream from the serial interface. The read character is stored in the object addressed by the input PTR_RXDATA. If input CHKETX is set to TRUE, check if the end delimiter defined at input EOTCHR is present in the read stream object. After the defined end delimiter is recognized, the read operation is completed and the output CONFIRM is set to TRUE. If the input CHKETX is set to FALSE or not present in the read binary stream

The defined end delimiter, the function block stops receiving after receiving the maximum number of bytes, (the internal size of the data object is determined by the address pointed to by PTR_RXDATA or the maximum number of characters defined by MAXLENGTH), in this case if the function block returns The function is normal, the CONFIRM of the output is also set to TRUE.

output RXLENGTH shows the number of characters stored in the data object addressed by PTR_RXDATA. if output

ERROR:=0, the end delimiter defined by the input ETXCHR has been received. If ERROR:=8 is output, reception is terminated after receiving the maximum number of characters.

detection of a rising edge at input ENABLE, the block starts character reception. The function block is repeatedly called by the PLC program until the end delimiter or MAXLENGTH characters are received and terminated. To do this, the input must be set

ENABLE is TRUE to enable character reception. The function block will set the output CONFIRM to

TRUE . After finishing the process of receiving the string, the PLC program must call the function block with ENABLE:=FALSE to reset the inside of the function block to the initial state. Reception can then be continued after a successful rising edge by resetting the input ENABLE to TRUE. Active reception can be terminated at any time with ENABLE:=FALSE .


Possible errors during the execution of the function block are displayed at the output **ERROR**. Due to the simultaneous setting of various bits, multiple errors can be displayed at the same time. The working process of the function block **USART_READ_BIN** reading the serial interface character stream can be understood through the sample program .

Sample program:

In the sample program, the binary character stream is read by calling **the USART_READ_BIN** function block first. After the character stream is completely read, pass

The **USART_WRITE_BIN** function block rewrites it to the interface (refer to the sample program in Section 3.3.4).

3.3.4 USART_WRITE_BIN



用于从串行接口读取单个字符

Definition of Operands

ENABLE : enable or disable the input of the

function block; **PTR_TXDATA** : address of the

binary data object to be sent;

TXLENGTH : The number of data bytes to send, if the number is 0, the length of the object is determined internally by **PTR_TXDATA** as a pointer;

PORT : The serial interface definition number to be used, 1 is RS232 , 2 is RS485 ;

CONFIRM : The result after the processing of the function block, FALSE indicates that the transfer was not successfully completed or terminated after an error, TRUE indicates that the transfer was successfully completed;

ERROR : The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0: No error occurred while executing the function block

1: A hardware error occurred while executing the function block

2: The selected interface (**PORT**) is not supported

8: Pointer refers to an object of an unsupported data type

128: The selected interface

(**PORT**) is not initialized

Description:

The function block writes a stream of binary characters to the serial interface. The address of the binary data to be written must be passed to the input

PTR_TXDATA. Input **TXLENGTH** specifies the number of valid bytes, if the value is **0**, it is determined internally by **PTR_TXDATA**. After a rising edge is detected at input **ENABLE**, the block starts writing the character stream. The function block is called repeatedly through the PLC program until

Character transfer is complete. To do this, the input **ENABLE** must be set to **TRUE** to enable character transfer. The function block passes the output

CONFIRM:=TRUE automatically shows that its transfer was successful. In more complex processes, the **PLC** program must reset its internal state via **ENABLE:=FALSE**. More data can then be transferred by setting the input **ENABLE** to **TRUE** and detecting a rising edge. Active transfers can be terminated at any time with **ENABLE:=FALSE**.

Possible errors during the execution of the function block are displayed at the output **ERROR**. Due to the simultaneous setting of various bits, multiple errors can be displayed at the same time.

The following sample program shows the combined application of the function blocks **USART_READ_BIN** and **USART_WRITE_BIN**. First, call the block

USART_READ_BIN to read a binary character stream. After the character stream is completely read, call the block

USART_WRITE_BIN rewrites it on the interface. The sample program also adds initialization of the serial interface and flow control of program execution.

Sample program :

VAR

mPORT:USINT;

xInitOk : BOOL := FALSE;

inst0_USART_INIT:USART_INIT;

inst1_USART_INIT:USART_INIT;

xRdBinConfirm : BOOL := FALSE;

xWaitForReceipt : BOOL := true;

abDataBuffer : ARRAY[0..256] OF BYTE;

pDataObject : POINTER;

inst0_USART_WRITE_BIN:USART_WRITE_BIN;

xWrBinConfirm : BOOL := FALSE;

xTransmitting : BOOL := FALSE;

iRxDataSize : INT;

xReadStart:bool:=true;

```

xWriteStart:bool:=FALSE;

xEERROR:usint;

xE:usint;

END_VAR

mPORT:=2;

if xInitOk=false then

inst0_USART_INIT(BAUD :=115200 , DATABITS :=8 , PARITY :=0 , STOPBITS :=1 , PROTOCOL :=0 ,
ENABLE :=1 , PORT :=mPORT| xE := ERROR);

if xE=0 then

xInitOk :=TRUE;

end_if;

end_if;

(* test USART_READ_BIN    USART_WRITE_BIN*)

pDataObject:=&abDataBuffer;

if xInitOk then

if xReadStart then

inst0_USART_READ_BIN(ENABLE :=0 ,    PORT :=mPORT  |  xERROR:= ERROR);

xWaitForReceipt:=true;

xWrBinConfirm:=false;

xReadStart:=false;

end_if;

```

```

if xWaitForReceipt then

inst0_USART_READ_BIN(ENABLE :=1 , PTR_RXDATA :=pDataObject ,

MAXLENGTH :=0 , ETXCHR :=6, CHKETX :=0, PORT :=mPORT | xRdBinConfirm:= CONFIRM,
iRxDataSize:= RXLENGTH, xERROR:= ERROR);

if xRdBinConfirm then xWaitForReceipt:=false; xWriteStart:=true;

end_if;

end_if;

if xWriteStart then

inst0_USART_WRITE_BIN(ENABLE :=0 , PORT :=mPORT | xERROR:= ERROR);

xRdBinConfirm:=false;

xWrBinConfirm:=false;

xTransmitting:=true;

xWriteStart:=false;

end_if;

if xTransmitting then

inst0_USART_WRITE_BIN(ENABLE :=1 ,PTR_TXDATA :=pDataObject ,TXLENGTH :=iRxDataSize,
PORT :=mPORT | xWrBinConfirm := CONFIRM, xERROR:= ERROR);

if xWrBinConfirm then

xTransmitting :=false;

xReadStart:=true;


end_if;

end_if;

end_if;

```

3.3.5 USART_READ_CHR



用于从串行接口读取单个字符

操作数的定义

ECHO : character echo on / off , FALSE : no echo ,

TRUE : echo ; **PORT** : serial interface definition

number to be used ;

RXDATA : received character (if **ERROR** : =0) ;

ERROR : The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0: No error occurred while executing the function block

1: A hardware error occurred while executing the function block

2: The selected interface (**PORT**) is not supported

8: No characters are available in the receive buffer

16: Character echo is not supported

255: The selected interface

(**PORT**) is not initialized

Description:

The function block reads a single character from the serial interface. If **ERROR** : =8 is output , there are no characters available in the receive buffer. If **ERROR** : =0 , the characters read are visible at output **RXDATA**. In this case, if you enter **ECHO** : =TRUE , the received character will be echoed back by the function block. Function


block errors that may occur during execution are displayed at the output **ERROR**. Due to the simultaneous setting of various bits, multiple errors can be displayed simultaneously.

Sample program :

function block **USART_READ_CHR** is used in conjunction with the function block **USART_WRITE_CHR**. First, call the function block in the program **USART_READ_CHR** to read characters from the interface, after successful reading, call the function block **USART_WRITE_CHR** to write characters on the interface

(see Section 3.3.6).

3.3.6 USART_WRITE_CHR



用于将单个字符写入串行接口

Definition of Operands

TXDATA : Enter the

character to be sent;

EXPANDCR : Auto-expand

carriage return on / off

FALSE : No auto-expand

carriage-return **TRUE** : Auto-

expand carriage-return

CR ('\$R'=13) automatically expands to CR+LF ('\$R\$L'=13+10)

EXPANDLF : auto-expand

newline on / off **FALSE** : no

auto-expand newline **TRUE** :

auto-expand newline

LF ('\$L'=10) expands to CR+LF ('\$R\$L'=13+10)

PORT : the serial interface definition number to be used;

ERROR : The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0 : No error when executing the function block

1 : A hardware error occurred while executing the function block

2 : The selected interface (**PORT**) is not supported

8 : No space available in send buffer, characters have been lost

16 : Auto-expansion of carriage return is not supported

32 : Automatic expansion of newlines is not supported

255 : The selected interface

(PORT) is not initialized

Description:

This function block writes a single character to the serial interface. If **ERROR : =1** is output , no space is available in the send buffer. If **ERROR : =0** , output TXDATA successfully writes characters to the interface. If **EXPANDCR : =TRUE** is entered , the function block will automatically expand the character to a string with a carriage return. Similarly, if you enter **EXPANDLF : =TRUE** , the function block automatically expands the character to a string with a newline.

Errors that may occur during the execution of the function block are displayed as a bitmask in the output **ERROR**. Due to the simultaneous setting of various bits, multiple errors can be displayed at the same time. The following routine shows the function blocks **USART_READ_CHR** and

USART_WRITE_CHR is used in combination to implement serial interface read and write characters. First, the sample program calls the function block **USART_READ_CHR** to read a character from the interface, and then calls the function block **USART_WRITE_CHR** to write a character on the interface after success. Sample program:

VAR

xEcho : BOOL := FALSE; FB_USARTReadChr : USART_READ_CHR;

**usiRxData : USINT; xRdCharSuccess : BOOL := FALSE; xExpandCR : BOOL := FALSE; xExpandLF :
BOOL := FALSE;**

FB_USARTWriteChr : USART_WRITE_CHR; xWrCharOk : BOOL := FALSE;

END_VAR

(* ----- Read Char-----*)

CAL FB_USARTReadChr (ECHO := xEcho,PORT := PORTNUM|usiRxData := RXDATA)

(* check receive result *)

```

LD FB_USARTReadChr.ERROR (* character received ? *)

EQ USART_RCHR_ERR_SUCCESS

ST xRdCharSuccess RETCN

(* ----- Write Char-----*)

CAL FB_USARTWriteChr (TXDATA := usiRxData, EXPANDCR :=
xExpandCR, EXPANDLF := xExpandLF, PORT := PORTNUM)

LD FB_USARTWriteChr.ERROR EQ USART_WCHR_ERR_SUCCESS


ST xWrCharOk

...

RET

```

3.3.7 USART_READ_STR



用于从串行接口读取一个字符串

操作数的定义：

RXDATA : String variable used to receive read

characters; **ENABLE** : Enable or disable the

input of the function block;

MAXLENGTH : limit the number of characters to read, if the number is 0, the buffer

pass is determined internally

the length of the string and use as the number of characters to read for that delimiter (note: standard buffer size for strings in **OpenPCS**)

is 32 characters).

EOTCHR: character for end-of-string delimiter (default: 10='\$L') , eg: 0 (NUL), 10 ('\$L'=newline), 13 ('\$R'= carriage return) ;

ECHO: character echo on / off, FALSE : no echo, TRUE : return echo;

EDIT: edit mode on / off, FALSE:BS (8) are stored as normal characters in the receive string, TRUE:BS (8) are interpreted as correction characters;

PORT: the serial interface definition number to be used;

CONFIRM: output completed message through the function block, FALSE : receive unsuccessfully completed or terminated after an error, TRUE : receive successfully completed, **RXLENGTH** characters available, receive buffer **RXDATA** ;

RXLENGTH: read length of string (if **ERROR** : =0);

ERROR: The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0: No error occurred while executing the function block

1: A hardware error occurred while executing the function block

2: The selected interface (**PORT**) is not supported

8: No terminal delimiter characters are received, terminate after receiving **MAXLENGTH** characters

16: Character echo is not supported

32: Edit mode is not supported

255: The selected interface

(**PORT**) is not initialized

Description:

The function block reads a string from the serial interface. The read string is passed into the input **RXDATA**. The string terminates reception after reading the

trailing delimiter defined as the input **EOTCHR**, or if the string is full with the number of characters set to **MAXLENGTH** (taking into account **EDIT**, if **MAXLENGTH : =0**, the buffer length of the passed string determined internally and used as a delimiter) . In both cases, the returned block shows that reception is complete and the string is passed to output **RXDATA**, while output **CONFIRM** is set to **TRUE** to indicate that the string has been read. The output **RXLENGTH** shows the number of characters in the receive buffer (equal to **LEN (RXDATA)**) . If the output **ERROR : =0**, it means that the end delimiter defined by the input **EOTCHR** has been received. If false: **=8**, read the set

After the number of characters, the reception terminates the maximum length. After detection of a positive edge at input **ENABLE**, the block starts character reception (first pass **ENABLE : =TRUE**). The function block is called repeatedly through the PLC program until the character reception (end delimiter or **MAXLENGTH** characters) is complete. To do this, the input **ENABLE** must be set to **TRUE** to enable character reception. The function block sets **CONFIRM** to **TRUE** after successful termination of reception . After processing the received string, the PLC program must call the function block with **ENABLE : =FALSE** to reset the block internally to the initial state. Operation can then continue by setting the input **ENABLE** to **TRUE** and detecting the rising edge of the received signal . Active reception can be terminated at any time by setting **ENABLE : =FALSE** .

If you enter **ECHO : =TRUE** , the function block automatically returns each received character as an echo. The character backspace (**BS=8**) is not stored as a normal character, but as a correction character, if **EDIT : =TRUE** is entered , then in the receive buffer, the last received character is deleted and the **RXLENGTH** reported received Character count decreased.

Possible errors during the execution of the function block are displayed at the output **ERROR** . Due to the simultaneous setting of various bits, several errors can be signaled.

The example program shows the working process of the function block

USART_READ_STR reading the string of the serial interface. Sample

program:

The sample program shows the combined working process of the function block **USART_READ_STR** and the function block **USART_WRITE_STR**. First, the routine reads the string by calling the function block **USART_READ_STR**. After the string is completely read, it is rewritten to the interface via the function block **USART_WRITE_STR** . (Refer to the sample program in Section 3.3.8)

3.3.8 USART_WRITE_STR

INSTO_USART_WRITE_STR		
int	ENABLE	CONFIRM
	USART_WRITE_STR	
	TXLENGTH	ERROR
bool	EXPANDCR	
bool	EXPANDLF	
bool	APPENDLF	
usint	PORT	
string	TXDATA	TXDATA

用于将字符串写入串行接口

Definition of operands:

TXDATA : String to write; **ENABLE** :

Enable or disable the input of the function block;

TXLENGTH : the number of characters to write, if the number is 0, the length of the characters and the characters TXDATA contained in the string are determined internally (equal to LEN (TXDATA));

EXPANDCR : Auto-expand

carriage return on / off

FALSE : No auto-expand

carriage-return; **TRUE** :

Auto-expand carriage-return;

CR ('\$R'=13) automatically expands to CR+LF ('\$R\$L'=13+10);

EXPANDLF : auto-expand

newline on / off **FALSE** : no

auto-expand newline; **TRUE** :

auto-expand newline;

LF ('\$L'=10) automatically expands to CR+LF ('\$R\$L'=13+10);

APPENDLF : auto append newline on / off

FALSE : no newline is appended

automatically, LF ('\$L'=10); **TRUE** : newline

is appended automatically, CR+LF

('\$R\$L'=13+10); **PORT** : the serial

interface definition number to use;

CONFIRM : message completed via function block output, **FALSE** : transfer was not completed successfully or terminated after an error,

TRUE : the transfer completed successfully;

ERROR : The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0 : No error occurred while executing the function block

1 : A hardware error occurred while executing the function block

2 : The selected interface (**PORT**) is not supported

16 : Auto-expansion of carriage return is not supported

32 : Auto-expansion of newlines is not supported

64 : Automatic appending of newlines is not supported

255 : The selected interface

(PORT) is not initialized

Description:

The function block writes a string to the serial interface. The string to transmit is passed at input **TXDATA**. enter

TXLENGTH specifies the number of valid characters. If the value is 0, the length of the string contained in the string is determined internally by **TXDATA**

(equal to **LEN (TXDATA)**), and as the number of characters to process. In this case,

the entire occupied string content is written. After a rising edge is detected at

input **ENABLE** (by calling first), the block starts writing the string

(**ENABLE** : =TRUE) . The function block is repeatedly called by the PLC program until the character transfer has been completed. To do this, the input **ENABLE** must be set to TRUE to enable character transfer. This block automatically signals successful completion by making the output **CONFIRM** TRUE . The PLC program must reset its initial state internally by calling the block with **ENABLE** : =FALSE . Further character transfers can then be initiated by detecting a rising edge at input **ENABLE** . Active transfers can be terminated at any time with **ENABLE** : =FALSE .

If you enter **EXPANDCR** : =TRUE , the block will automatically expand the string with ASCII + carriage return. Similarly, blocks also automatically add newlines to strings, which expand to strings if **EXPANDLF** : =TRUE is entered

+ line break. If the input **APPENDLF** : =TRUE , the block is passed to the output **TXDATA** with an internal newline appended after the complete transfer of the string . Depending on the input **APPENDLF** , this newline will be transferred as a string consisting of carriage return + newline, if needed.

Possible errors during the execution of the function block are displayed as a

bitmask at output **ERROR**. Due to the simultaneous setting of various bits, several errors can be signaled.

The following sample program shows the application of the function block **USART_WRITE_STR**. First, the block **USART_READ_STR** is called to read the string from the interface. After the string is completely read, the block **USART_WRITE_STR** rewrites it on the interface. The sample program integrates flow control for initializing the serial interface and program execution.

Sample program :

```
(* ----- Init USART ----- *) USARTInit:  
CAL FB_USARTInit (BAUD := 9600,DATABITS := 8,PARITY := USART_INIT_PARITY_NO,STOPBITS :=  
1,PROTOCOL := USART_INIT_PROTOCOL_NO,ENABLE := TRUE,PORT := PORTNUM)
```

```

(* ----- Read String-----*) ReadStringStart:

CAL FB_USARTReadStr (ENABLE := FALSE, (* Step 1: Reset FB *)RXDATA := strRxText, PORT :=
PORTNUM)

CAL FB_USARTReadStr (ENABLE := TRUE, (* Step 2: Start FB *)RXDATA := strRxText, MAXLENGTH := 0,
(* no limit, use whole string length *)EOTCHR := usiEotChr, ECHO := xEcho, EDIT := xEdit, PORT :=
PORTNUM | xRdStrConfirm := CONFIRM, iRxDataSize := RXLENGTH)

(* ----- Write String-----*) WriteStringStart:

CAL FB_USARTWriteStr (ENABLE := FALSE, (* Step 1: Reset FB *)TXDATA := strTxText, PORT :=
PORTNUM)

WriteStringCont:

CAL FB_USARTWriteStr (ENABLE := TRUE, (* Step 2: Start FB *)TXDATA := strTxText, TXLENGTH := 0, (*
no limit, transmit whole string *)EXPANDCR := xExpandCR, EXPANDLF := xExpandLF, APPENDLF := xAppendLF, PORT :=
PORTNUM | xWrStrConfirm := CONFIRM)


(* ----- Reset Flow Control Logic-----*) LD FALSE

ST xTransmitting ST xWrStrConfirm ST xWaitForReceipt ST xRdStrConfirm RET

END_PROGRAM

```

3.3.9 EXT_USART_INIT



用于初始化扩展串行接口

Definition of operands:

EN_IN : Enable or disable the serial interface:

true: enable serial

interface; false:

disable serial

interface;

NUMBER : the serial number of the GC-6101 module used to expand the serial port, the serial number of the first GC-6101 module after the main control module is 1, the second is 2, and so on;

EN485 : Set the serial communication mode, 1 is RS485 communication, 2 is RS232 communication:

BAUD : Set the baud rate used in serial communication, which can be set to the following values: 1200, 2400, 9600, 19200, 38400, 57600 ,**115200** ;

DATABITS : Set the number of data bits to use, for example: **7:7** data bits
8:8 data bits;

PARITY : Set parity for secure data transfer, for example: **0**: no parity
1: odd check
2: even check;

STOPBITS : Set the number of stop bits to use, for example:

1:1 stop bit

2:2 stop bits;

PROTOCOL : Set the handshake protocol rules to use, for example:
0: no protocol
1: XON/XOFF

2: Hardware handshake (RTS/CTS flow control);

EN_OUT: function block enable output;

ERROR: The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows :

0: No error occurred while executing the function block

1: A hardware error occurred while executing the function block

2: The selected interface (**PORT**) does not support

4: The selected baud rate (**BAUD**) is not supported

8: The selected number of data bits (**DATABITS**) is not supported

16: The selected parity (**PARITY**) is not supported

32: The selected stop number is not supported

64: The selected

handshake protocol

does not support the

description:

The function block initializes the serial interface with the specified parameters. Possible errors during execution are shown in the output **ERROR**. Different error codes will be superimposed and need to be split (for example, **6=2+4** means the selected interface is not supported and the selected baud rate is not supported). The following routine uses the function block **USART_INIT** to initialize the serial interface, and sets the following parameters: serial port number is **RS485**, **9600** baud rate, **8** data bits, no parity, **1** stop bit, no protocol.

Sample program:

```
VAR mPORT:USINT;
```

```
xInitOk : BOOL := FALSE; inst0_EXT_USART_INIT:USART_INIT;
```


```
xE:usint; END_VAR
```

```
mPORT:=2;
```

```
if xInitOk=false then
```

```
inst0_EXT_USART_INIT(BAUD :=9600 , DATABITS :=8 , PARITY :=0 , STOPBITS :=1 , PROTOCOL :=0 ,  
ENABLE :=1 , PORT :=mPORT| xE := ERROR);  
  
if xE=0 then xInitOk :=TRUE; end_if;  
  
end_if;
```

3.3.10 EXT_USART_READ_BIN



用于从扩展串行接口读取2进制字符流

Definition of operands:

EN_IN : Enable or disable the input of the function block ;

NUMBER : the serial number of the GC-6101 module used to expand the serial port, the serial number of the first GC-6101 module after the main control module is 1, the second is 2, and so on ;

PTR_RXDATA : the address used to receive the read data byte object ;

MAXLENGTH : the maximum number of bytes to read, if it is 0, the number of bytes to be read is determined by **PTR_RXDATA** ; **EN_OUT** : function block enable output ;

RXLENGTH : number of characters read (if **ERROR** : =0) ;

ERROR : The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0: No error occurred while executing the function block

1: A hardware error occurred while executing the function block

2: The selected interface (PORT) is not supported

8: The character of the terminal separator is not received, and the character of the length of **MAXLENGTH** is received and terminated

128: pointer to object of unsupported data type

255: The selected interface

(PORT) is not initialized

Description:

The function block reads the binary data stream from the serial interface. The read character is stored in the object addressed by the input PTR_RXDATA. The function block stops receiving after receiving the maximum number of bytes, (the internal size of the data object is given by

`PTR_RXDATA` or the maximum number of characters defined by `MAXLENGTH`), in this case if the function block feedback function is normal, the output `EN_OUT` will also be set to `TRUE`.

output `RXLENGTH` shows the number of characters stored in the data object addressed by `PTR_RXDATA`. input detected

`ENABLE`, the block starts character reception. The function block is repeatedly called by the **PLC** program until the end delimiter or `MAXLENGTH` characters are received and terminated. To do this, input `ENABLE` must be set to `TRUE` to enable character reception. The function block will set the output `CONFIRM` to `TRUE` after successful termination of reception . After finishing the process of receiving the string, the **PLC** program must call the function block with `ENABLE:=FALSE` to reset the inside of the function block to the initial state. A rising edge can then successfully enable the successor by resetting the input `ENABLE` to `TRUE`


continue to receive. Active reception can be terminated at any time with `ENABLE:=FALSE` .

Possible errors during the execution of the function block are displayed at the output `ERROR`. Due to the simultaneous setting of various bits, multiple errors can be displayed at the same time. The working process of the function block `EXT_USART_READ_BIN` reading the serial interface character stream can be understood through the sample program .

Sample program:

In the sample program, the binary character stream is read by calling the `EXT_USART_READ_BIN` function block first. After the character stream is completely read, it is rewritten to the interface via the `EXT_USART_WRITE_BIN` function block (see Section 3.3.10).

3.3.11 EXT_USART_WRITE_BIN



Definition of operands:

EN_IN : Enable or disable the input of the function block;

NUMBER : the serial number of the GC-6101 module used to expand the serial port, the serial number of the first GC-6101 module after the main control module is 1, the second is 2, and so on;

PTR_TXDATA : the address of the binary data object to be sent;

TXLENGTH : The number of bytes of data to send, if the number is 0, the length of the object is passed as a pointer in **PTR_TXDATA**

Internal addressing is determined;

EN_OUT: The result after the function block processing, **FALSE** indicates that the transfer was not completed successfully or terminated after an error,

TRUE indicates that the transfer has completed successfully;

ERROR: The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0: No error occurred while executing the function block

1: A hardware error occurred while executing the function block

2: The selected interface (**PORT**) is not supported

8: Pointer refers to an object of an unsupported data type

128: The selected interface

(**PORT**) is not initialized

Description:

The function block writes a stream of binary characters to the serial interface. The address of the binary data to be written must be passed to the input

PTR_TXDATA. Input **TXLENGTH** specifies the number of valid bytes, if the value is **0**,

it is determined internally by **PTR_TXDATA**. After a rising edge is detected at

input **EN_IN**, the block starts writing the character stream. The function block is called

repeatedly through the PLC program until the word

Symbol transmission is complete. To do this, the input **EN_IN** must be set to **TRUE** to enable character transfer. The function block automatically indicates that its transfer was successful with the output **EN_OUT:=TRUE**. In more complex processes, the PLC program must reset its internal state via **EN_IN:=FALSE**. More data can then be transferred by setting the input **EN_IN** to **TRUE** and detecting a rising edge. Active transfers can be terminated at any time with **EN_IN:=FALSE**.

Possible errors during the execution of the function block are displayed at the

output **ERROR**. Due to the simultaneous setting of various bits, multiple errors can be displayed at the same time.

The following sample program shows the combined application of the function blocks **EXT_USART_READ_BIN** and **EXT_USART_WRITE_BIN**. First, the block **EXT_USART_READ_BIN** is called to read the binary character stream. After the character stream is completely read, the block **EXT_USART_WRITE_BIN** is called to rewrite it onto the interface. The sample program also adds initialization of the serial interface and flow control of program execution.

Sample program :

VAR

```
xInitOk : BOOL := FALSE; inst0_EXT_USART_INIT:EXT_USART_INIT;
```

```

xRdBinConfirm : BOOL := FALSE; xWaitForReceipt : BOOL := true;
inst0_EXT_USART_READ_BIN:EXT_USART_READ_BIN;

abDataBuffer : ARRAY[0..256] OF BYTE; pDataObject : POINTER;
inst0_EXT_USART_WRITE_BIN:EXT_USART_WRITE_BIN;

xWrBinConfirm : BOOL := FALSE; xTransmitting : BOOL := FALSE; iRxDataSize : INT;
xReadStart:bool:=true; xERROR:usint;

xE:usint; var4:INT; eout:bool;

END_VAR

if xInitOk=false then

inst0_EXT_USART_INIT(EN_IN :=TRUE , NUMBER :=1 , EN485 :=0, BAUD :=115200 , DATABITS :=8 ,
PARITY :=0 , STOPBITS :=1 , PROTOCOL :=0      | eout := EN_OUT,    xE:=
ERROR);

if xE=0 and eout=true then xInitOk :=TRUE;

end_if; end_if;

(* test USART_READ_BIN USART_WRITE_BIN*)

pDataObject:=&abDataBuffer; if xInitOk then

if xReadStart then

inst0_EXT_USART_READ_BIN(EN_IN :=0 , NUMBER :=1      |    xERROR := ERROR);

xWaitForReceipt:=true; xRdBinConfirm:=false; xReadStart:=false;

end_if;

if xWaitForReceipt then inst0_EXT_USART_READ_BIN(EN_IN := 1, NUMBER := 1 ,
PTR_RXDATA :=pDataObject , MAXLENGTH := 0 | xRdBinConfirm := EN_OUT, iRxDataSize :=
RXLENGTH,xERROR:= ERROR);

if xRdBinConfirm then var4:=iRxDataSize; xWaitForReceipt:=false;

```

```

end_if; END_if;

if xRdBinConfirm then

inst0_EXT_USART_WRITE_BIN(EN_IN :=0 , NUMBER :=1 | xERROR:= ERROR);

xRdBinConfirm:=false; xTransmitting:=true;

end_if;

if xTransmitting then abDataBuffer[0]:=49;

(* abDataBuffer[1]:=1; abDataBuffer[2]:=2; iRxDataSize:=3;*)

inst0_EXT_USART_WRITE_BIN(EN_IN := 1, NUMBER :=1 ,

PTR_TXDATA :=pDataObject, TXLENGTH :=iRxDataSize | xWrBinConfirm := EN_OUT, xERROR :=

ERROR);

if xWrBinConfirm then


xTransmitting :=false; xReadStart:=true;

end_if; end_if;

end_if;

```

3.3.12 CAN_INIT



用于初始化CAN接口

操作数的定义：

BITRATE : The baud rate is in bits / second, classified as follows:

BITRATE : =0 means 1MBit/s BITRATE : =1 means 840kBit/s

BITRATE : =2 means 700kBit/s

BITRATE : =3 means 500kBit/s

BITRATE : =4 means 400kBit/s

BITRATE : =5 means 250kBit/s

BITRATE : =6 means 200kBit/s

BITRATE : =7 means 125kBit/s

BITRATE : =8 means 100kBit/s ;

BITRATE : =9 means 80kBit/s

BITRATE : =10 means 50kBit/s

BITRATE : =11 means 40kBit/s

BITRATE : =12 means 20kBit/s

BITRATE : =13 means 10kBit/s AMR : Configuration value of CAN controller receive mask register (AMR);

Perform hardware filtering (standard value for all CAN message processing: AMR : =16# FFFFFFFF); ACR : The configuration value of the CAN controller receive code register (ACR), allowing the CAN identifier in the CAN controller

Perform hardware filtering (standard value for all CAN message processing: ACR : =16# 00000000); NETNUMBER : network number;

ENABLE : enable or disable the input

of the function block; **CONFIRM** :

the output of the message done by

the function block;

ERROR : The error code refers to the data type " CAN_ERROR ", the possible error codes are defined as follows:

0: no error

1: Other errors

2: Invalid network number

3: invalid parameter

4: No message

5: Unsupported baud rate

6: Initialization failed

7: The device is busy

8: TX buffer overflow

9: No free passage

10: COBID has been registered

11: Pointer type

does not support

description:

function block **CAN_INIT** is used to initialize the **CAN** interface. This requires deactivating the **CANopen** functionality of this interface. If the **PLC supports configuration via WEBFrontend**, it is usually possible to set the "Enable Status" of the relevant interface to "Disabled". Therefore, the interface is not automatically initialized for **CANopen**, and the function can be implemented by calling the function block in the program through the **PLC**.

When entering **BITRATE**, the value of **Bitrate** must be specified in **Bit/s**, for example, **125000** is **125**

kBit/s. The combination of the two values after the input **AMR** (mask register) and **ACR** (code register) are transferred to the **AMR or ACR register of the CAN controller** is an acceptance filter that can only pass **CAN** identifiers that meet the filter conditions

CAN message. With proper settings of **AMR** and **ACR**, all irrelevant interfering messages can be excluded from reception in the **CAN controller**, reducing the **CPU load** of the controller and preventing overflow of the receive buffer. Each **CAN** controller can obtain the **AMR** and **ACR** correlations and implemented filter values from their respective associated control tables . Normally, the filter receives all **CAN** messages as a **CAN-Controller**. For this, **AMR** and **ACR** must be set as follows: **AMR:=16 # FFFFFFFF;ACR:=16 #**

00000000;

Sample program:

```
VAR canCH:USINT;  
inst0_CAN_INIT:CAN_INIT;  
  
mCanConfirm:BOOL; mCanInit:BOOL:=false; xERROR:USINT;  
  
END_VAR  
  
canCH:=2;  
  
if not mCanInit then
```

```

inst0_CAN_INIT(BITRATE :=0 , AMR :=0 , ACR :=0 , NETNUMBER :=canCH ,
ENABLE :=true | mCanConfirm:= CONFIRM, xERROR :=ERROR);

if xERROR=0 then

    mCanInit:=true;

end_if;

end_if ;

```

3.3.13 CAN_MESSAGE_READ8

INST0_CAN_MESSAGE_READ8		
EN_IN	EN_OUT	
CAN_MESSAGE_READ8	CANID	udint
NETNUMBER		
	EXT_FRAME	bool
	RTR_FRAME	bool
	DATALENGTH	usint
	DATA0	byte
	DATA1	byte
	DATA2	byte
	DATA3	byte
	DATA4	byte
	DATA5	byte
	DATA6	byte
	DATA7	byte
	ERROR	usint

用于读取接收的CAN消息（在功能块输出端传输数据）

Definition of operands:

NETNUMBER : network number;

ENABLE : Enable or disable the input of the function block; **CANID** : CAN identifier

EXT_FRAME : TRUE : send CAN extended frame (29-bit frame ID); FALSE : send CAN standard frame (11-bit frame ID); **RTR_FRAME** : TRUE : send remote frame; FALSE :

```
send data frame;
```

DATA0-DATA7 : Data bytes received by CAN-Message; **DATALENGTH**:Length received by CAN-Message ;

CONFIRM : message output done by function block;

ERROR : Error code of data type "CAN_ERROR", possible error codes are defined as follows:

0: no error

1: Other errors

2: Invalid network number

3: invalid parameter

4: No message

5: Unsupported baud rate

6: Initialization failed

7: The device is busy

8: TX buffer overflow

9: No free passage

10: COBID has been registered

11: Pointer type

does not support

description:

function block **CAN_MESSAGE_READ8** is used to read received CAN messages from the receive buffer of the CAN interface. Data is transferred byte by byte at the output of the function block. The displayed value of the output **DATALENGTH** is the number of valid data bytes (starting from **DATA0**).

CONFIRM is set to **TRUE** during a function block return , data 0 to data 7 contain a single byte of the message, and the output data length shows the number of valid bytes


(starting at data 0), although **CONFIRM** has now been reset to **FALSE**, but the CAN interface does not contain messages, with the help of **CONFIRM**, it is possible to distinguish whether a valid message of length 0 bytes is received, and if no message is available, it is displayed by the error code at the output **ERROR**.

Sample program:

The sample program shows the combined working process of the function block **CAN_MESSAGE_READ8** and the function block **CAN_MESSAGE_WRITE8**.

First, the routine reads CAN interface messages by calling the function block **CAN_MESSAGE_READ8**. After the message is completely read, it is rewritten to the interface via the function block **CAN_MESSAGE_WRITE8** (refer to Section 3.3.13).

3.3.14 CAN_MESSAGE_WRITE8



用于将需要发送的CAN信息写到CAN总线上

Definition of operands:

CANID : the identifier of the CAN message to be sent ;

EXT_FRAME : TRUE : CAN identifier marks extended frame (29 bits) ; FALSE : CAN identifier marks standard frame (11 bits) ; **RTR_FRAME** : TRUE : CAN object is passed as RTR-Frame ; FALSE : CAN object is not passed as RTR-Frame ; **CHANNEL** If the CAN object has been defined by the function block **CAN_DEFINE_CANID**, the channel number returned by this function block is CAN object passing. If the CAN object has function defined by **CAN_DEFINE_CANID_RANGE**, then 0 must be passed (note: objects defined by **CAN_DEFINE_CANID_RANGE** cannot be used for RTR-messages) ;

DATA0-DATA7 : The data bytes of the CAN message

to be sent ; **DATALENGTH** : The length of the CAN

message to be sent ; **NETNUMBER** : The network

number;

ENABLE : Enable or disable the input of the function block;

CONFIRM : message output done by function block;

ERROR : Error code of data type "CAN_ERROR", possible error codes are defined as follows:

0: no error

1: Other errors

2: Invalid network number

3: invalid parameter

4: No message

5: Unsupported baud rate

6: Initialization failed

7: The device is busy

8: TX buffer overflow

9: No free passage

10: COBID has been registered

11: Pointer type

does not support

description:

function block **CAN_MESSAGE_WRITE8** is used to send CAN data. The data to be sent appears byte by byte at the input of the function block and is written in **DATA0** to **DATA7** as a single byte. The input **DATALENGTH** specifies the number of valid data bytes (starting at **DATA0**). When the function block **CAN_MESSAGE_WRITE8** is called, the message to be sent is stored in the send buffer of the **CAN interface**. If no error has occurred (the message is correctly stored in the send buffer), the function block output **CONFIRM** is **TRUE**.

The following sample program shows the application of the function block **CAN_MESSAGE_WRITE8**. First, call the block

CAN_MESSAGE_READ8 reads data from the CAN interface. After the data is completely read, **CAN_MESSAGE_WRITE8** rewrites it on the interface. The sample program integrates the process control of initializing the CAN interface and the program.

Sample program:

```
VAR canCH:USINT;
```

```

inst0_CAN_INIT:CAN_INIT;

mCanConfirm:BOOL; mCanInit:BOOL:=false; xERROR:USINT;

inst1_CAN_MESSAGE_READ8:CAN_MESSAGE_READ8;

inst2_CAN_MESSAGE_WRITE8:CAN_MESSAGE_WRITE8; mCANID:UDINT;

mEXT_FRAME:BOOL; mRTR_FRAME:BOOL; mDATA0:BYTE;

mDATA1:BYTE; mDATA2:BYTE; mDATA3:BYTE; mDATA4:BYTE; mDATA5:BYTE; mDATA6:BYTE;

mDATA7:BYTE; mDATALENGTH:USINT; mCONFIRM:BOOL; canID:UDINT;

canDAT0:Byte; canDAT1:Byte; canDAT2:Byte; canDAT3:Byte; canDAT4:Byte; canDAT5:Byte;

canDAT6:Byte; canDAT7:Byte; RecCount:INT; first:bool:=true; END_VAR

canCH:=2;

if not mCanInit then

inst0_CAN_INIT(BITRATE :=0 , AMR :=0 , ACR :=0 , NETNUMBER :=canCH ,

ENABLE :=true | mCanConfirm:= CONFIRM, xERROR := ERROR); if xERROR=0 then

mCanInit:=true; end_if;

else

inst1_CAN_MESSAGE_READ8(


NETNUMBER :=canCH , ENABLE :=true | mCANID:= CANID, mEXT_FRAME:= EXT_FRAME,

mRTR_FRAME:= RTR_FRAME, mDATA0:= DATA0, mDATA1:= DATA1, mDATA2:=

DATA2,

mDATA3:= DATA3, mDATA4:= DATA4, mDATA5:= DATA5, mDATA6:= DATA6, mDATA7:=

DATA7,mDATALENGTH:= DATALENGTH,

mCanConfirm:= CONFIRM, xERROR:= ERROR);

```

```

if mCanConfirm = 1 then canID:= mCANID; canDAT0:= mDATA0; canDAT1:= mDATA1; canDAT2:= mDATA2;
canDAT3:= mDATA3; canDAT4:= mDATA4; canDAT5:= mDATA5; canDAT6:= mDATA6; canDAT7:= mDATA7;

RecCount:= RecCount+1; end_if;

if mCanConfirm = 1 then mCANID:= mCANID+1;

inst2_CAN_MESSAGE_WRITE8(CANID := mCANID, EXT_FRAME := mEXT_FRAME, RTR_FRAME :=
mRTR_FRAME, CHANNEL := 1, DATA0 := mDATA0, DATA1 := mDATA1, DATA2 := mDATA2, DATA3 := mDATA3,
DATA4 := mDATA4, DATA5 := mDATA5, DATA6 := mDATA6, DATA7 := mDATA7,
DATALENGTH := mDATALENGTH, NETNUMBER := canCH, ENABLE := true | mCONFIRM := CONFIRM,
xERROR := ERROR);

end_if;

(*

if first=true then

inst2_CAN_MESSAGE_WRITE8(CANID := 2, EXT_FRAME := 0, RTR_FRAME := 0,
CHANNEL := 1, DATA0 := 12, DATA1 := 13, DATA2 := 14, DATA3 := 15,
DATA4 := 16, DATA5 := 17, DATA6 := 18, DATA7 := 19, DATALENGTH := 8, NETNUMBER := canCH ,
ENABLE := true | mCONFIRM := CONFIRM, xERROR :=

ERROR);


first := false;

end_if;

*)
end_if;

```

3.3.15 CAN_NMT



用于发送NMT命令（网络管理命令）的功能块

Definition of operands:

ENABLE : Enable or disable the input of the function block;

DEVICE : Node address to be controlled (1-127 or 0, 0 means to control all nodes);


NETNUMBER : Network number;

STATE : node state;

CONFIRM : The completed message is output by the function block, FALSE indicates that the transfer was not successfully completed or terminated after an error, TRUE indicates that the transfer was successfully completed;

ERROR : The error code describes information about the result of the execution of the function block.

3.3.16 CAN_GET_STATE



用于请求设备节点状态的功能块

Definition of operands:

ENABLE : Enable or disable the input of the function block;


DEVICE : The node address that needs to be requested (1-127 or 0 , 0 represents requesting all nodes) ;

NETNUMBER : network number ;

CONFIRM : The completed message is output by the function block, FALSE indicates that the transfer was not successfully completed or terminated after an error, TRUE indicates that the transfer was successfully completed;

STATE : The current node state returned.

3.3.17 CAN_REGISTER_COBID



用于注册或删除通过网络层接收的PDO和
CAN第2层消息

Definition of operands:

EN_IN : Enable or disable the input of the function block;

NODEID : COBID (CAN Identifier) of new information to be entered

into or deleted from the registry **REGISTER** : TRUE= enter COBID into
registry; FALSE= delete COBID from registry ;

NETNUMBER : network number (Note: if the PLC only supports one CANopen interface,
this input can be skipped, because the variable value has been set to the initial
value 0 according to the IEC61131 standard ;

EN_OUT : function block output

job completion message; **ERROR** :


function block execution error

alarm information Description:

This function block can be used to register a PDO or CAN layer 2 message for
reception by the network layer, or to delete such a registration . When the input
REGISTER is 1, the function block is called, and the specified **COBID** of the message received

by the network layer will be registered. When the input **REGISTER** is 0, the function block is called, and the registry information of the corresponding **COBID** will be deleted. When **REGISTER** is 0 and **COBID** is 0, calling the function block will delete all registration information and all information stored in the network layer buffer. In fact, the network layer only supports accessing **PDO** and **CAN** layer 2 messages and registering the information by calling the function block **CAN_PDO_READ8**.

3.3.18 CAN_PDO_READ8



用于读取PDO数据的功能块

Definition of operands:

ENABLE : Enable or disable the input of the function block;

COBID : COBID of the PDO data to be read (ie

CAN frame ID) ; **NETNUMBER** : network number;

DATA0-DATA7 : received CAN data;

DATALENGTH : received CAN data

length; **ERRORINFO** : reserved;

CONFIRM : The completed message is output by the function block, **FALSE** indicates that the transfer was not successfully completed or terminated after an error, **TRUE** indicates that the transfer was successfully completed;

ERROR : The error code describes the information about the execution result of the function block , the possible error codes are defined as follows:


16#0000(= 00 dec) : no errors

16#0001(= 01 dec) : other errors

16#0002(=	02	dec) : data overflow
16#0003(=	03	dec) : timeout
16#0010(=	16	dec) : CAN bus off
16#0011(=	17	dec) : CAN bus passive error
16#0021(=	33	dec) : reserved (error)
16#0022(=	34	dec) : invalid function block
16#0023(=	35	dec) : no master mode
16#0024(=	36	dec) : invalid device
16#0025(=	37	dec) : forwarding congestion (transfer busy)
16#0030(=	48	dec) : no SDO channel available
16#0031(=	49	dec) : SDO congestion
16#0032(=	50	dec) : SDO initialization error
16#0033(=	51	dec) : wrong SDO length
16#0034(=	52	dec) : SDO errors (ERRORINFO SDO in abort code)
16#0040(=	64	dec) : no valid data
16#0041(=	65	dec) : this COBID is already registered
16#0042(=	66	dec) : no COBID table entry available

16#0043(=	67	dec) : No such COBID is registered
16#0044(=	68	dec) : no receive channel available
16#0045(=	69	dec) : CAN data length 0 shall not be

3.3.19 CAN_PDO_WRITE8



用于发送PDO数据的功能块

Definition of operands:

ENABLE : Enable or disable the input of the function block; **COBID** : The COBID (ie CAN frame ID) of the PDO message to be sent ; **DATA0-DATA7** : The data to be sent;

DATALENGTH : The length of the CAN data to be sent ; **NETNUMBER** : The network

number;

ERRORINFO : reserved;

CONFIRM : output completed message through the function block, **FALSE** indicates that the transfer was not completed successfully or terminated after an error, **TRUE** indicates that

The transfer completed successfully;

ERROR : The error code describes information about the result of the execution of the function block.

3.3.20 CAN_SDO_READ8

INST0_CAN_SDO_READ8		
EN_IN	EN_OUT	
CAN_SDO_READ8		
usint	DEVICE	ERROR
word	INDEX	ERRORINFO
byte	SUBINDEX	DATA0
usint	NETNUMBER	DATA1
		DATA2
		DATA3
		DATA4
		DATA5
		DATA6
		DATA7
		DATALENGTH

通过SDO（服务数据对象）传输，读对
象字典功能块

Definition of operands:

ENABLE : Enable or disable the input of the function block;

DEVICE : Node address to be read (1-127 or 0, 0 means to

write all nodes); **SUBINDEX** : Sub-index item to be read;

INDEX : Index item to be

read; **NETNUMBER** :

Network number;

DATA0-DATA7 : data to be read;

DATALENGTH : CAN data length to be read;

ERRORINFO : SDO abort code;

CONFIRM : message completed by function block output, **FALSE** indicates that the transfer was not completed successfully or terminated after an error, **TRUE**

Indicates that the transfer was completed successfully;

ERROR : The error code describes information about the result of the execution of the function block.

3.3.21 CAN_SDO_WRITE8

INSTO_CAN_SDO_WRITE8		
	EN_IN CAN_SDO_WRITE8	EN_OUT
uint	DEVICE	ERROR word
word	INDEX	ERRORINFO dword
byte	SUBINDEX	
byte	DATA0	
byte	DATA1	
byte	DATA2	
byte	DATA3	
byte	DATA4	
byte	DATA5	
byte	DATA6	
byte	DATA7	
uint	DATALENGTH	
uint	NETNUMBER	

通过SDO（服务数据对象）传输，写对
象字典功能块

Definition of operands:

ENABLE : Enable or disable the input of the function block;

DEVICE : The node address to be written (1-127 or 0 , 0 means to write all nodes);

SUBINDEX : Sub-index item to

be written; **INDEX** : Index item

to be written; **NETNUMBER** :

Network number;

DATA0-DATA7 : data to be written;

DATALENGTH : data length to be

written; **ERRORINFO** : SDO abort code;

CONFIRM : output completed message via the function block, **FALSE** to indicate that the transfer did not complete successfully or to terminate after an error, **TRUE** to say

Indicates that the transmission was successfully completed;

ERROR : The error code describes information about the result of the execution of the function block.

3.3.22 CAN_SDO_READ_STR

INST0_CAN_SDO_READ_STR		
EN_IN	EN_OUT	
	CAN_SDO_READ_STR	
usint	DEVICE	ERROR
word	INDEX	ERRORINFO
byte	SUBINDEX	RXLENGTH
usint	SDOTYPE	
int	MAXLENGTH	
usint	NETNUMBER	
string	RXDATA	RXDATA

用于通过SDO传输读取节点对象字典中
的字符串信息

Definition of operands:

EN_IN : Enable or disable the input of the function block;

DEVICE : The node address to be read (local OD

is 1-127 or 0); **INDEX** : The main index number

to be read;

SUBINDEX : the subindex number to read;

SDOTYPE : The type of SDO transmission mode determined according to the data type;

Note: If the input has no clear value (no input or unused), the network layer will automatically select the most appropriate SDO transmission mode according to the amount of transmitted data.

MAXLENGTH : The limit of the number of characters to be read; if the value is 0 , the buffer length of the transmission string is automatically determined by the system , (Note: The standard buffer length of strings in OpenPCS is 32 characters).

NETNUMBER : network number;

RXDATA : String variable used to receive read

characters; **EN_OUT** : Function block function

completion output message;

ERROR : The error code describes information about the result of the execution of the function block.

ERRORINFO : SDO termination code of

the communication partner .

RXLENGTH : the length of the

string information;

describe:

The function block uses the **SDO** transfer of strings read from the node's object dictionary, which always **happens** in the background. Therefore, the program described in section 3.1.3 **must** synchronize the function block and the **PLC** program through the parameters **ENABLE** and **CONFIRM** . If the output **CONFIRM** is 1 when the function block is executed , the string transmitted as element **RXDATA** contains the string characteristics of the input object. The output **RXLENGTH** indicates the number of characters read (equal to **LEN (RXDATA)**), each network layer can only support a limited number of **SDO** transfers through the **PLC** program (up to 5 transfers in standard cases , if there is no input pin in the **PLC** manual make any changes), after the **SDO** transfer is started by setting **ENABLE** to 1 , the related **SDO** channel will be closed and will not be used by other function blocks. This closed state continues until the **SDO** function block is called again by setting **ENABLE** to 0 .. If you skip calling the function block with **ENABLE** set to 0 , the resource will remain closed and will not be used by the **PLC**. You can access the **PLC local object dictionary** by calling the function block with **DEVICE** set to 0. The same method can also be used to read Your local **OD** value.

3.3.23 CAN_SDO_WRITE_STR

INSTO_CAN_SDO_WRITE_STR			
word	EN_IN INDEX	EN_OUT CAN_SDO_WRITE_STR	word
byte	SUBINDEX	ERROR	dword
uint	SDOTYPE	ERRORINFO	
int	TXLENGTH		
uint	NETNUMBER		
string	TXDATA	TXDATA	

用于通过SDO传输将字符串发送到相应节点的对象字典中

Definition of operands:

EN_IN : function block enable

input; **INDEX** : the main index

number of the data to be sent;

SUBINDEX : the sub-index number of the data to be sent;

SDOTYPE : SDO transmission mode used according to data type "CAN_SDO_Type", note: if not explicitly specified to

The value of this input (input open or unused), the function block uses the default mode, and the network layer selects the most appropriate SDO transmission method according to the amount of data to be transmitted.

TXLENGTH : The number of characters to write, if the number is 0, the length of the object characters contained in the string TXDATA is determined internally (equal to LEN (TXDATA)) and is used as the number of characters to write.

NETNUMBER : Network number (Note: If the PLC only supports one CANopen interface, the setting of this input can be skipped, because according to the IEC61131 standard, the value of the variable has been set to the initial value of 0 .

TXDATA : The string to be passed.

EN_OUT : Output message after function block execution is complete.

ERROR : Error code generated according to data type

CIA405_CANOPEN_KERNEL_ERROR . **ERRORINFO** : The communication object

SDO termination code generated according to the data type

CIA405_SDO_ERROR . describe:


function block CAN_SDO_WRITE_STR is used to write a string to the object dictionary of the node via SDO transfer.

SDO transfers usually take place in the background, so the program described in section 4.1.3 must synchronize the function block and the PLC program by using ENABLE and CONFIRM , the strings written in the object dictionary must be transferred into the element TXDATA .

Enter TXLENGTH for a valid number of characters. If the value of this entry is 0 , the number of characters contained in the string TXDATA is determined internally and used as the number of characters to be written. In this case, what the string contains will all be written. The network layer can only support a limited number of SDO transmissions at one time through the PLC program (standard: if the PLC manual has not changed the input items, up to 5 transmissions), after setting ENABLE to 1 to start SDO

transmission, each **SDO** channel will be It is closed and will not be used by other function blocks. This closed state will continue until the function block is called again through the input **ENABLE** as **0** before opening. If you skip calling the function block with **ENABLE** set to **0**, the resource will be closed forever and will no longer be used by the **PLC**. The **PLC**'s local object dictionary can be accessed by calling the function block with **DEVICE equal to 0**. This way can also be used to write values into your own object dictionary.

3.2.24 CAN_SDO_READ_BIN



功能块通过SDO传输读取节点对象字典
中的二进制数据

Definition of operands:

EN_IN : function block enable input

DEVICE : Node address read (1 to 127 or local

object dictionary 0) **INDEX** : Primary index

number read

SUBINDEX : the subindex number read

SDOTYPE : The SDO transmission mode used (refer to the data type **CAN_SDO_TYPE**), note:
if this input has no clear value (the input is open or not used), the function block
will use the SDO type automatic allocation mode. The network layer will automatically
select the most appropriate SDO transmission mode based on the amount of transmitted
data.

PTR_RXDATA : The object address of the read data byte

MAXLENGTH : The limit on the number of bytes read, if the value is 0, the length of
the object at the address defined by **PTR_RXDATA** is defined internally and used as the number of
characters read (the maximum number of bytes read is equal to the number of bytes occupied by the object bytes)

NETNUMBER : Network number (Note : If the PLC only supports 1 CANopen interface ,
the setting of this item can be skipped, because according to the IEC61131 standard,

the value of the variable has been set to the initial value 0).

EN_OUT: output function block execution result

ERROR: Refer to the error code generated by the data type

CIA405_CANOPEN_KERNEL_ERROR.ERRORINFO: Communication object SDO

interrupt code generated according to data type **CIA405_SDO_ERROR**.

RXLENGTH : The number of


data bytes read Description:

function block **CAN_SDO_READ_STR** is used to read the binary data in the node object dictionary through SDO transmission.

SDO transfers usually take place in the background, so the program described in Section 4.1.3 must synchronize the function block and PLC program by using **ENABLE** and **CONFIRM**. If the output **CONFIRM** is 1 after the execution of the function block , the object whose address is defined by **PTR_RXDATA** contains the binary data of the object to be read, and the output **RXLENGTH** indicates the number of bytes read. The network layer can only support a limited number of SDO transmissions at one time through the PLC program (standard: if the PLC manual has not changed the input items, up to 5 transmissions), after setting **ENABLE** to 1 to start SDO transmission, each SDO channel will be Closed, not used by other function blocks, this closed state will continue until the function block passes the input again

When **ENABLE** is 0 , it will be turned on. If you skip calling the function block with **ENABLE** set to 0 , the resource will be closed forever and will no longer be used by the PLC . The PLC 's local object dictionary can be accessed by calling the function block with **DEVICE** equal to 0 . This way can also be used to write values into your own object dictionary.

3.3.25 CAN_SDO_WRITE_BIN



功能块用于通过SDO传输将二进制数据写入节点的对象字典中

Definition of

operands: **EN_IN** :

function block enable

input **INDEX** : main

index number to be

written

SUBINDEX : the subindex number to write

SDOTYPE : The SDO transmission mode used (refer to the data type **CAN_SDO_TYPE**), note:
if this input has no clear value (input open or not used), the function block will use
the SDO type automatic allocation mode. The network layer will

Quantity automatically selects the most suitable SDO transfer mode.

PTR_TXDATA : Object address of binary data to be written

TXLENGTH : The number of bytes to write, if the value is 0, the object length at the address defined by **PTR_TXDATA** is determined internally and used as the number of bytes to write.

NETNUMBER : Network number (Note : If the PLC only supports 1 CANopen interface, the setting of this item can be skipped, because according to the IEC61131 standard, the value of the variable has been set to the initial value 0).

EN_OUT : output function block execution result

ERROR : Refer to the error code generated by the data type

CIA405_CANOPEN_KERNEL_ERROR.ERRORINFO : Communication object SDO

interrupt code generated according to data type **CIA405_SDO_ERROR**.


describe:

function block **CAN_SDO_WRITE_STR** writes binary data into the node object dictionary via SDO transmission. SDO transfers usually take place in the background, so the program described in Section 3.1.3 must synchronize the function block and PLC program by using **ENABLE** and **CONFIRM**.

The address of the object where the object dictionary of the binary data to be written must be passed to the parameter **PTR_TXDATA**. The input **TXLENGTH** specifies a valid number of bytes. If the value is 0, the length of the object will be defaulted and used as the bytes to be written. number. The network layer can only support a limited number of SDO transmissions at one time through the PLC program (standard: if the PLC manual has not changed the input items, up to 5 transmissions), after setting **ENABLE** to 1 to start SDO transmission, each SDO channel will be It is closed and will not be used by other function blocks. This closed state will continue until the function block is called again through the input **ENABLE** as 0 before opening. If you skip calling the function block with **ENABLE** set to 0, the resource will be closed forever and will no

longer be used by the PLC. The PLC's local object dictionary can be accessed by calling the function block with DEVICE equal to 0. This way can also be used to write values into your own object dictionary.

3.3.26 CAN_RECV_EMCY



用于读取网络层接收缓冲区中的任意节点紧急报文（Emergency）的功能块

Definition of operands:

ENABLE : Enable or disable the

input of the function block;

NETNUMBER : Network number;

DEVICE : The node address (1-127) that receives the emergency message (Emergency) ;


EMCY_ERR_CODE **EMCY_ERR_REGISTER**

EMCY_ERR_FIELD1-EMCY_ERR_FIELD5 : urgent error message;

CONFIRM : The completed message is output by the function block, FALSE indicates that the transfer was not successfully completed or terminated after an error, TRUE indicates that the transfer was successfully completed;

ERROR : The error code describes information about the result of the execution of the function block.

3.3.27 CAN_RECV_EMCY_DEV



用于从网络层接收缓冲区读取特定节点紧急报文 (Emergency) 的功能块

Definition of operands:

ENABLE : Enable or disable the input of the function block;

DEVICE : Node address to be controlled (1-127 or 0, 0 means to control all nodes);

NETNUMBER : Network number;

EMCY_ERR_CODE**EMCY_ERR_REGISTER**

EMCY_ERR_FIELD1**EMCY_ERR_FIELD5** : urgent error message;

CONFIRM : The completed message is output by the function block, FALSE indicates that the transfer was not successfully completed or terminated after an error, TRUE indicates that the transfer was successfully completed;

ERROR : The error code describes information about the result of the execution of the function block.

3.3.28 CAN_WRITE_EMCY

INST0_CAN_WRITE_EMCY		
EN_IN	CAN_WRITE_EMCY	EN_OUT
word	EMCY_ERR_CODE	ERROR
byte	EMCY_ERR_REGISTER	
byte	EMCY_ERR_FIELD1	
byte	EMCY_ERR_FIELD2	
byte	EMCY_ERR_FIELD3	
byte	EMCY_ERR_FIELD4	
byte	EMCY_ERR_FIELDS	
word	EMCY_ADD_INFO	
usint	NETNUMBER	

通过网络层，发送特定应用程序紧急报文
(Emergency) 的功能块

Definition of operands:

ENABLE : Enable or disable the input of the function block;

NETNUMBER : network number; **EMCY_ERR_CODE EMCY_ERR_REGISTER**


EMCY_ERR_FIELD1 - EMCY_ERR_FIELD5 : urgent error message;

EMCY_ADD_INFO : Additional user-specific urgent error information, note that it is not part of the urgent error message that needs to be sent, but is used for diagnostic purposes, so it can be 0.

CONFIRM : The completed message is output by the function block, **FALSE** indicates that the transfer was not successfully completed or terminated after an error, **TRUE** indicates that the transfer was successfully completed;

ERROR : The error code describes information about the result of the execution of the function block.

3.3.29 CAN_ENABLE_CYCLIC_SYNC



功能块用于激活循环SYNC同步信息

Definition of operands:

EN_IN : function block enable input

SYNC_MODE : **TRUE**= activates the generation of cyclic **SYNC synchronization messages**,
FALSE= deactivates the generation of cyclic **SYNC synchronization messages**

SYNC_TIME : time interval between two consecutive **SYNC synchronization messages** or 0 means
that **SYNC synchronization messages** are sent after each **PLC scan cycle**
step message.

NETNUMBER : Network number (Note : If the PLC only supports 1 CANopen interface , the setting of this item can be skipped, because according to the IEC61131 standard, the value of the variable has been set to the initial value 0).

EN_OUT : output function block execution result

ERROR : Refer to the error code generated by CIA405_CANOPEN_KERNEL_ERROR .

describe:


function block **CAN_ENABLE_CYCLIC_SYNC** is used to activate or deactivate the cyclic SYNC synchronization message. When activated, if the time interval between the last SYNC synchronization message and the current time is greater than the input **SYNC_TIME**, the control system will generate a SYNC synchronization message between two consecutive PLC cycles. , if the time interval between the last SYNC synchronization message and the present is less than the input **SYNC_TIME**, no SYNC synchronization message will be generated. An input value of 0 for **SYNC_TIME** will cause the control system to end each PLC scan cycle with a SYNC synchronization message . In this case, the information exchange in the process image area of the network layer will be carried out in the PLC's local input and output process image areas at the same time .

At the end of each PLC scan cycle, the control system checks the time details to send a SYNC synchronization message, so the time specified by the input **SYNC_TIME** is the minimum interval between two consecutive SYNC synchronization messages. In the system with the largest error, the two The actual time interval of consecutive SYNC synchronization messages varies with the time of the PLC scan cycle :

SYNC actual time := SYNC_TIME input time + PLC scan cycle

This function block can only be used in the CANopen master control system and can be used as a replacement function block for the function block **CAN_SEND_SYNC**.

3.3.30 CAN_SEND_SYNC



用于发送独立的同步报文 (SYNC)
的功能块

Definition of operands:

ENABLE : Enable or disable the


input of the function block;

NETNUMBER : Network number;

CONFIRM : The completed message is output by the function block, **FALSE** indicates that the transfer was not successfully completed or terminated after an error, **TRUE** indicates that the transfer was successfully completed;

ERROR : The error code describes information about the result of the execution of the function block.

3.3.31 CAN_ENABLE_CYCLIC_NODE GUARD



用于激活或停用循环同步报文 (SYNC) 的功能块

Definition of operands:

ENABLE : Enable or disable the

input of the function block;

NETNUMBER : Network number;

SYNC_MODE : TRUE=activate cyclic synchronization message, FALSE=


disable cyclic synchronization message; **SYNC_TIME** : time interval

between two consecutive synchronization messages;

CONFIRM : The completed message is output by the function block, FALSE indicates that the transfer was not successfully completed or terminated after an error, TRUE indicates that the transfer was successfully completed;

ERROR : The error code describes information about the result of the execution of the function block.

3.3.32 CAN_SEND_NODE GUARD



使能CANopen从站发送节点保护

Definition of operands:

EN_IN : function block enable

input; **DEVICE** : CANopen slave node

number; **NETNUMBER** : PLC CANopen

port number; **EN_OUT** : **function**


block **enable** output;

ERROR : The error code describes information about the result of the execution of the function block;

describe:

This function block is used to enable CANopen slave to send node protection message.

3.3.33 CAN_RECV_BOOTUP_DEV



用于从网络层的接收缓冲区中，读取特定节点Bootup消息的功能块

Definition of operands:

ENABLE : Enable or disable the

input of the function block;


NETNUMBER : Network number;

DEVICE : Node number (1-127) used to check Bootup message reception ;

CONFIRM : The completed message is output by the function block, FALSE indicates that the transfer was not successfully completed or terminated after an error, TRUE indicates that the transfer was successfully completed;

ERROR : The error code describes information about the result of the execution of the function block.

3.3.34 CAN_RECV_BOOTUP



用于从网络层的接收缓冲区中，读取总线节点Bootup消息的功能块

Definition of operands:

ENABLE : Enable or disable the input of the function block;


NETNUMBER : network number;

DEVICE : The address of the node that received the Bootup message (1-127) ;

CONFIRM : The completed message is output by the function block, FALSE indicates that the transfer was not successfully completed or terminated after an error, TRUE indicates that the transfer was successfully completed;


ERROR : The error code describes information about the result of the execution of the function block.

3.3.35 CAN_FILTER



用于CAN总线滤波

3.3.36 LAN_INIT



用于初始化以太网接口

Definition of operands:

ENABLE : enable or disable the function block,

true is enabled, false is disabled; **HOSTNAME** : set

the host name, for example: 'PLCCore' ;

IP : Specify the IP address of the Ethernet side , for example: ' 192.168.1.30 ' ; **NETMASK** : Specify the subnet mask of the Ethernet side, for example: ' 255.255.255.0 ' ;

GATEWAY : Specifies the gateway on the Ethernet

side, for example: ' 192.168.1.1' ; **NETNUMBER** :

Network number;

CONFIRM : `false` means the function block execution fails, `true` means the function block execution succeeds;

ERROR : The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0: No error occurred while executing the function block

1: A hardware error occurred while executing the function block

2: The entered host name is not supported

4: The entered IP address is not supported

8: The filled subnet mask is not supported

16: The entered gateway does not support

32: The selected Ethernet

interface does not support

ERRORINFO : Secondary

error message. describe:

The function block initializes the Ethernet interface with the specified parameters. If an error occurs during execution, the function block will display it through the output **ERROR**, and the error code can be found in Table 15. The following sample program shows the application of the function block **LAN_INIT** to initialize the Ethernet interface, setting the following parameters: IP address **192.168.1.30**, subnet mask **255.255.255.0**, gateway **192.168.1.1**.

程序

VAR

```
lanInit: bool := false; inst0_LAN_INIT: LAN_INIT;  
  
mConfirm: bool; mError: uint; mErrorinfo: uint; mIP: uint; mNetMask: uint; mGateWay: uint;  
mSocket: int;  
  
END_VAR  
  
if lanInit = false then  
  
    mIP := LAN_ASCII_TO_INET ('192.168.1.30'); mNetMask := LAN_ASCII_TO_INET ('255.255.255.0');
```

```

mGateWay:= LAN_ASCII_TO_INET ('192.168.1.0');

inst0_LAN_INIT (ENABLE:= true, HOSTNAME:= 'PLCCore', IP:= mIP, NETMASK:= mNetMask,
GATEWAY:= mGateWay, NETNUMBER:= 1

| mConfirm:= CONFIRM,   mError:= ERROR, mErrorinfo:= ERRORINFO); lanInit:=true;

end_if ;

```

3.3.37 LAN_GET_TCPCONNECT_SOCKET



Definition of Operands

SOCKET_ID: generated socket index

value; **NETNUMBER**: network number;

CLIENT_SOCKET_ID: peer socket index

value;

PEER_ADDR: The address of the peer, which can be

obtained when the peer is connected; **PEER_PORT**: The

port number of the peer, which can be obtained when the

peer is connected;

ERROR: The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0 : No error occurred while executing the function block

1 : A hardware error occurred

while executing the function

block 2 : The inserted **socket**

index value is not supported


4 : The selected Ethernet

interface is not supported

describe:

The function block initializes the Ethernet interface with the specified parameters. If an error occurs during execution, the function block will display it through the output **ERROR**, and the error code can be found in Table 16. The following sample program shows the application of the function block **LAN_INIT** to initialize the Ethernet interface, setting the following parameters: IP address 192.168.1.30, subnet mask 255.255.255.0, gateway 192.168.1.1.

3.3.38 LAN_TCP_SERVER_CREATE



用于初始化以太网TCP连接的SERVER端

Definition of operands:

PORT: the Ethernet port number to use;

ENABLE: enable or disable the function block,

true is enabled, **false** is disabled; **NETNUMBER**:

network number;

SOCKET_ID: the generated **socket index value**;

CONFIRM: **false** means the function block execution


fails, **true** means the function block execution

succeeds; **ERROR**: the error code describes the

information about the function block execution result.

ERRORINFO: Secondary error information.

3.3.39 LAN_TCP_CLIENT_CONNECT



用于建立TCP_CLIENT连接

Definition of operands:

EN_IN : function block

enable input;

NETNUMBER : network

number; **IP_ADDR** : IP

address; **PORT** : port

number;

EN_OUT : function block

enable output; **SOCKET_ID** :

SOCKET connection ID ;


ERROR : The error code describes the

information about the result of the execution

of the function block Description:

This function block is used to create a socket connection of TCP_CLIENT.

3.3.40 LAN_TCP_CLIENT_CLOSE



用于关闭TCP_CLIENT连接

Definition of operands:

EN_IN : function block enable

input; **NETNUMBER** : network

number; **SOCKET_ID** : SOCKET

connection ID ;

EN_OUT : function block enable output;

ERROR : The error code describes information


about the result of the execution of the

function block; description:

This function block is used to close the **socket** connection of **TCP_CLIENT**.

When this function block is executed, the **socket** connection needs to be opened in advance through the function block **LAN_TCP_CLIENT_CONNECT**.

3.3.41 LAN_TCP_RECV_BIN



用于从TCP端口读取二进制字符流

Definition of operands:

CLIENT_SOCKET_ID : The index value of the

peer socket; **PTR_RXDATA** : The address used

to receive the read byte object;

MAXLENGTH : limit of bytes to read, if 0, the length of the object

is determined by **PTR_RXDATA** **ENABLE** : enable or disable the function

block, **true** : enable, **false** : disable;

NETNUMBER : network number;

RXLENGTH : number of characters read (if **ERROR** : =0);

CONFIRM : **false** : function block execution failed;


true : function block execution succeeded; **ERROR** :

error code explaining information about the function

block execution result; **ERRORINFO** : secondary error

information .

3.3.42 LAN_TCP_SEND_BIN



用于将二进制字符流写入TCP端口

Definition of operands:

CLIENT_SOCKET_ID: The index value of the peer

socket; PTR_RXDATA : **The address** used to

receive the read data byte object;

TXLENGTH : The number of characters to write, if the value is 0, the length of the characters and the characters TXDATA contained in the string are determined internally (equal to LEN (TXDATA))

ENABLE : enable or disable the function block,

true : enable, false : disable; **NETNUMBER** : network

number;

CONFIRM : false : the function block execution failed,

true : the function block execution succeeded; **ERROR** :

the error code explains the information about the

execution result of the function block; **ERRORINFO** :

secondary error information;

Sample program:

VAR

lanInit:bool:=false; inst0_LAN_INIT:LAN_INIT;

mConfirm:bool; mError:uint;mErrorinfo:uint; mIP:udint;mNetMask:udint;

mGateWay:udint;mSocket:INT; inst4_LAN_TCP_SERVER_CREATE:LAN_TCP_SERVER_CREATE;

mTcpCreateOK:bool:=false; mClientSocket:INT; mPeer:udint; mPeerPort:uint ;

inst5_LAN_GET_TCPCONNECT_SOCKET:LAN_GET_TCPCONNECT_SOCKET;

inst6_LAN_TCP_RECV_BIN:LAN_TCP_RECV_BIN; inst7_LAN_TCP_SEND_BIN:LAN_TCP_SEND_BIN;

mRxLen:int;

```
abDataBuffer : ARRAY[0..1000] OF BYTE;
```

```
pDataObject : POINTER;
```

```
END_VAR
```

```
if lanInit=false then
```

```

mIP := LAN_ASCII_TO_INET('192.168.1.30'); mNetMask := LAN_ASCII_TO_INET('255.255.255.0');

mGateWay := LAN_ASCII_TO_INET('192.168.1.0');

inst0_LAN_INIT(ENABLE :=true , HOSTNAME := 'PLCCore',IP := mIP,
NETMASK :=mNetMask,GATEWAY :=mGateWay ,NETNUMBER:=1

|mConfirm:= CONFIRM,mError:= ERROR, mErrorinfo:= ERRORINFO); lanInit:=true;

else

if mTcpCreateOK=false then

inst4_LAN_TCP_SERVER_CREATE(PORT :=8089 ,ENABLE := true, NETNUMBER :=

1| mSocket:= SOCKET_ID, mConfirm:= CONFIRM, mError:= ERROR, mErrorinfo:= ERRORINFO);

mTcpCreateOK:=true; end_if;

end_if; pDataObject:=&abDataBuffer; if mTcpCreateOK=true then

inst5_LAN_GET_TCPCONNECT_SOCKET(SOCKET_ID := mSocket,
NETNUMBER := 1| mClientSocket:= CLIENT_SOCKET_ID, mPeer:= PEER_ADDR,mPeerPort:=
PEER_PORT, mError:= ERROR);

if mClientSocket>=0 then

inst6_LAN_TCP_RECV_BIN(CLIENT_SOCKET_ID :=mClientSocket , PTR_RXDATA :=pDataObject ,
MAXLENGTH := 1500, ENABLE :=1 , NETNUMBER := 1|mRxLen:= RXLENGTH, mConfirm:= CONFIRM,
mError:= ERROR,
mErrorinfo:= ERRORINFO); if mRxLen>0 then


inst7_LAN_TCP_SEND_BIN(CLIENT_SOCKET_ID :=mClientSocket , PTR_TXDATA :=pDataObject ,
TXLENGTH := mRxLen, ENABLE :=1 ,
NETNUMBER :=1| mConfirm:= CONFIRM, mError := ERROR, mErrorinfo:= ERRORINFO);

end_if; end_if;

end_if;

```

3.3.43 LAN_UDP_CREATE_SOCKET



可建立一个UDP的socket连接，用于发送和接收数据

Definition of operands:

PORT: the Ethernet port number to be used;

ENABLE: enable or disable the function block,

true is enabled, **false** is disabled; **NETNUMBER**:

network number;

SOCKET_ID: the generated **socket** index value (referenced internally by the **UDP** layer of the **PLC**); **CONFIRM**: **false** : the function block execution failed, **true** : the function block execution succeeded; **ERROR** : the error code describes the information about the function block execution result.

ERRORINFO : Secondary

error information.

describe:

function block **LAN_UDP_CREATE_SOCKET** can establish a UDP socket connection for sending and receiving data. If the connection is used to receive data, the input **PORT** must be a valid port number. Only under the premise that the port is valid, the **PLC** will call the internal function at the **UDP** layer, and can receive the data packet at the IP address matching its port number . In most systems, the port number less than 1024 is only used by the internal privileged program.

Use, port numbers in the range **1024** to **49151** are still reserved for default applications and managed by **IANA** (Internet Assigned Numbers Authority), so it is best to use port numbers from **49152** to **65535** for PLC UDP communication.


If the created connection is only used to send data, the port number is arbitrary. If the input **PORT** is set to **0**, the **PLC** will call a free port number in the internal dedicated space of the **UDP** layer to send data. At this time, the internal function is not necessary, however, the specification of the port number that is defined to send the data is necessary, eg an active firewall in the network only forwards data to a specific port.

After the function block is executed correctly, the **PLC** will internally reference the **UDP** layer and generate a **SOCKETID** at the output, the value of this **SOCKETID** will be

Referenced in the relevant function block called subsequently, e.g. the function block **LAN_UDP_SENDTO_STR** or **LAN_UDP_RECVFROM_STR**.

Socket connections that are no longer needed can be closed with the function block **LAN_UDP_CLOSE_SOCKET**.

3.3.44 LAN_UDP_CLOSE_SOCKET



用于关闭一个不再需要的UDP socket连接

Definition of operands:

SOCKET_ID : The index value of the **socket** that needs to be closed ;

ENABLE : enable or disable the function block,

true is enabled, **false** is disabled; **NETNUMBER** :

network number;

CONFIRM : **false** means the function block execution

fails, **true** means the function block execution

succeeds; **ERROR** : the error code describes the

information about the function block execution result;

ERRORINFO : secondary error information.

describe:

SOCKETID is internally referenced by the **UDP** layer of the **PLC** when the function block **LAN_UDP_CREATE_SOCKET** is called. All unclosed socket connections will be automatically closed when the **PLC** program exits.

3.3.45 LAN_UDP_RECVFROM_BIN

INSTO_LAN_UDP_RECVFROM_BIN	
usint	EN_IN
int	NETNUMBER
pointer	SOCKET_ID
int	PTR_RXDATA
usint	MAXLENGTH
uint	EN_OUT
uint	PEER_ADDR
int	PEER_PORT
usint	RXLENGTH
usint	ERROR

用于从UDP层接收缓存区读取UDP数据包

Definition of operands:

SOCKET_ID : The index value of the **socket** to

be polled ; **PTR_RXDATA** : The address where

the data byte object (received) is stored;

MAXLENGTH : The limit of the number of bytes

to be read;

ENABLE : enable or disable the function block, **true** is enabled, **false** is disabled;

NETNUMBER : network number;

PEER_ADDR: The address of the opposite end (remote end), which can

be obtained when the opposite end is connected; **PEER_PORT**: The

port number of the opposite end (remote end), which can be

obtained when the opposite end is connected; **RXLENGTH** : The

number of characters read ;

CONFIRM : **false** : the function block execution failed,

true : the function block execution succeeded; **ERROR** :

the error code explains the information about the

function block execution result. **ERRORINFO** :

Secondary error information.


describe:

This function block is used to read UDP data packets from the receive buffer of the UDP layer. After the function block is successfully executed, **CONFIRM** will be set to **TRUE**. **PTR_RXDATA** contains the received data bytes, and the output **RXLENGTH** specifies the number of data bytes read. If the function block fails, no data bytes will be output.

When the data packet is successfully received (**CONFIRM** is **TRUE**), the output

PEER_ADDR and **PEER_PORT** are used to store the peer (remote end) IP address and port number. If the **PLC** responds to the received data packet, the opposite end address and opposite end port must be used as the target specification for subsequent function block calls. When this function block is executed, it needs to pass the function **LAN_UDP_CREATE_SOCKET** opens a **socket** connection.

3.3.46 LAN_UDP_SENDTO_BIN



用于发送UDP数据包

Definition of operands:

SOCKET_ID : the socket index value for sending ;

PEER_ADDR : The IP address of the peer (remote), which can be obtained when the peer is connected; **PEER_PORT** : The port number of the peer (remote), which can be obtained when the peer is connected; **PTR_TXDATA** : The binary to be sent the address of the object of the data;

TXLENGTH : the number of data bytes to send;

ENABLE : enable or disable the function block,

true is enabled, **false** is disabled; **NETNUMBER** :

network number;

CONFIRM : **false** : the function block execution failed,

true : the function block execution succeeded; **ERROR** :

the error code explains the information about the

function block execution result. **ERRORINFO** :


Secondary error information.

describe:

This function block is used to send **UDP** packets. **PEER_ADDR** and **PEER_PORT** are used to set the IP address and port number of the peer (remote end) , and are used in conjunction with the function block **LAN_UDP_RECVFROM_BIN** .

When this function block is executed, the **socket** connection needs to be opened in advance through the function block **LAN_UDP_CREATE_SOCKET** .

3.3.47 LAN_UDP_RECVFROM_STR



用于从UDP层的接收缓存区读取UDP数据包

Definition of operands:

RXDATA : a variable used to receive the read

string; **SOCKET_ID** : the index value of the

socket to be polled ; **MAXLENGTH** : the limit of

the number of bytes to be read;

ENABLE : enable or disable the function block,

true is enabled, **false** is disabled; **NETNUMBER** :

network number;

RXDATA : a variable used to receive the read string;

PEER_ADDR: The address of the opposite end (remote end), which can

be obtained when the opposite end is in a connected state;

PEER_PORT: The port number of the opposite end (remote end), which

can be obtained when the opposite end is in a connected state;

RXLENGTH : Read the string length;

CONFIRM : **false** : function block execution failed, **true** : function block execution succeeded;

ERROR : The error code describes information about the result of the execution of the function block. Possible error codes are detailed in Table 27;

ERRORINFO : Secondary

error information.


describe:

This function block is used to read **UDP** packets from the **UDP** receive buffer .

PEER_ADDR and **PEER_PORT** are used to store the IP address and port number of the peer (remote end) .

When this function block is executed, the `socket` connection needs to be opened in advance through the function block `LAN_UDP_CREATE_SOCKET`.

3.3.48 LAN_UDP_SENDTO_STR



用于发送UDP数据包

Definition of operands:

TXDATA : String variable to be sent;

SOCKET_ID : Socket index value for

sending ;

PEER_ADDR : The IP address of the peer (remote), which can be

obtained when the peer is connected; **PEER_PORT** : The port

number of the peer (remote), which can be obtained when the

peer is connected;

TXLENGTH : the number of data bytes to send, if the number is 0, the length of the

object is determined by the `PTR_TXDATA` internal addressing; **ENABLE** : enable or

disable the function block, `true` : enable, `false` : disable;

NETNUMBER : network number;

TXDATA : string variable to

be sent;

CONFIRM : false : function block execution failed, true : function block execution succeeded;

ERROR : The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0: No error occurred while executing the function block

1: When calling the function block, an invalid network number was set

2: When calling the function block, an invalid parameter was set

3: Error in UDP initialization of PLC

4: When adding, sending, or receiving a **socket**

connection, the **UDP** layer of the PLC reports an error 5:

There is no available **socket** connection

6: An invalid **socketID** is set. The **socket** corresponding to

socketID cannot be used normally. 8: The sending buffer

area is too large, and the packet size is limited by the

maximum number of bytes.

9: The sending buffer is too small, no data can be sent

10: There is an error in the set host

11: The pointer points to an unsupported data type

ERRORINFO : Secondary


error information.

describe:

This function block is used to send **UDP** packets. **PEER_ADDR** and **PEER_PORT** are used to set the IP address and port number of the peer (remote end) .

When this function block is executed, the **socket** connection needs to be opened in advance through the function block **LAN_UDP_CREATE_SOCKET** .

3.3.49 EXT_GPRS_INIT



扩展GPRS通讯初始化功能块

Definition of operands:

EN_IN : function block

enable input; **NUMBER** :

network number;

MODE : Communication mode, 1 is TCP , 2 is UDP ;

SERVER_IP_ADDR: server IP address;

SERVER_PORT: server port

number; **EN_OUT :** function

block enable output;


ERROR : The error code describes the

information about the result of the execution

of the function block Description:

This function block is used to initialize extended **GPRS** communication.

3.3.50 EXT_GPRS_STATUS



获取GPRS通讯状态功能块

Definition of operands:

EN_IN : function block

enable input;

NETNUMBER : network

number; **STATUS :** GPRS

communication status;


EN_OUT : function block

enable output;

description:

This function block is used to obtain the **GPRS** communication status.

3.3.51 EXT_GPRS_READ_BIN



GPRS通讯读取数据

Definition of operands:

EN_IN : function block

enable input;

NETNUMBER : network

number;

PTR_RXDATA : Array pointer stored

after reading data; **MAXLENGTH** :

Maximum length of data to be read;

EN_OUT : Function block enable output;

RXLENGTH : The length of the data actually read;


ERROR : The error code describes the error

information of the function block execution

result; description:

This function block is used for **GPRS** communication to read data.

3.3.52 EXT_GPRS_WRITE_BIN



GPRS通讯发送数据

Definition of operands:

EN_IN : function block

enable input;

NETNUMBER : network

number;

PTR_RXDATA : The array pointer where

the data to be sent is stored;

TXLENGTH : The length of the sent data;

EN_OUT : function block enable output;


ERROR : The error code describes the error

information of the function block execution

result; description:

This function block is used for GPRS communication to send data.

3.3.53 MQTT_INIT



MQTT初始化功能块

Definition of operands:

EN_IN : function block

enable input; **NETNUMBER** :

network number; **MODE** :

function mode;

SERVER_IP_ADDR : server IP

address; **SERVER_PORT** : server

port number; **CLIENT_ID** : client

ID name; **USERNAME** : username;

PASSWORD : password;

EN_OUT : function block enable output;


ERROR : The error code describes the error

information of the function block execution

result; description:

This function block is used for **MQTT** communication initialization.

3.3.54 MQTT_STATUS



MQTT状态功能块

Definition of operands:

EN_IN : function block

enable input;

NETNUMBER : network

number; **STATUS** : MQTT

communication status;


EN_OUT : function block

enable output;

description:

This function block is used to get the MQTT status.

3.3.55 MQTT_SEND



MQTT发送数据功能块

Definition of operands:

EN_IN : function block

enable input;

NETNUMBER : network

number;

CONTENT : data structure;

LENGTH_STR : length of the

string to be sent;

PTR_DATA : pointer to the storage

array of data to be sent;

LENGTH_BIN : length of the character

stream to be sent; **QS** : character

stream parameter;

EN_OUT : function block enable output;


ERROR : The error code describes the

information about the execution result of

the function block; description:

This function block is used to send data through MQTT.

3.3.56 MODBUS_SLAVE_INIT



用于初始化Modbus-RTU从站接口

Definition of operands:

ENABLE : Enable or disable the input of the function block;

MODE : Select the communication protocol: enter a value of 1 to define the Port as Modbus protocol and enable the protocol, and enter a value of 0 to define the Port as PPI and disable the Modbus protocol.

ADDRESS : Set the site address

PORt : The serial interface definition number to be used, 1 is RS232, 2 is RS485BAUD : Set the baud rate. 1200 , 2400 , 4800 ,

9600, 19200, 38400, 57600, 115200

DATABITS : Number

of data bits

PARITY : Set parity

0: No parity ,1: Odd parity ,2: Even parity

STOPBITS : stop bits

ERROR : The error code describes the information of the execution result of the function block. Possible error codes are defined as follows:

0: no error

1: memory area range error

2: Illegal baud rate or parity

3: Illegal slave

address 4: Illegal

value of **Modbus**

parameter

5: The holding register is duplicated with the **Modbus** slave symbolic address

6: Receive check error

7: Receive **CRC** error

8: Illegal feature request / unsupported feature

9: Illegal memory area address in the request

10: The slave

function is not


enabled

Description:

The MODBUS_SLAVE_INIT instruction is used to enable and initialize or disable Modbus communication.

The MODBUS_SLAVE_INIT instruction must be executed without errors before the MBUS_SLAVE instruction can be used. The MODBUS_SLAVE_INIT instruction must be executed before continuing with the next instruction . The MODBUS_SLAVE_INIT instruction should only be executed once per communication state change. Therefore, the ENABLE input should be pulse-triggered using an edge-detect element, or executed only once during the first loop cycle.

3.3.57 MODBUS_SLAVE_CTRL



执行Modbus-RTU从站接口的控制指令

Definition of operands:

PORT : Serial interface

definition number to be used;

DO_ENABLE : Digital output

enable; **DO_PTR** : Digital output

storage address; **DO_LENGTH** :

Digital output length;

DI_ENABLE : Digital input

enable; **DI_PTR** : Digital input

storage address; **DI_LENGTH** :

digital input data length;

AI_ENABLE : analog input enable;

AI_PTR : analog input storage

address; **AI_LENGTH** : analog

input data length; **REG_ENABLE** :

register enable;

REG_PTR : Register storage address;

REG_LENGTH : Register storage data

length; **DONE**: Completion flag bit;

ERROR : According to the error code of the data type "CAN_ERROR", the possible error codes are defined as follows:

0: no error

1: Response verification error

2: unused

3: Receive timeout (no response from slave)

4: Request parameter

error 5: Modbus/

Freeport not enabled

6: Modbus is busy with other requests

7: Response error (response is not the requested operation)

8: Response CRC

checksum error

description:

Calling the function block MODBUS_SLAVE_CTRL can realize the data transmission and reception of the MODBUS-RTU slave station. Sample program:

```
Var; inst1_MODBUS_SLAVE_CTRL:MODBUS_SLAVE_CTRL;
```

```
modbusDOBuf : ARRAY[0..5] OF byte; DO_Ptr : POINTER;
```

```
modbusDIBuf : ARRAY[0..5] OF byte; DI_Ptr : POINTER;
```

```
modbusAIBuf : ARRAY[0..10] OF int; AI_Ptr : POINTER;
```

```
modbusRegBuf : ARRAY[0..127] OF int; mPtr : POINTER;
```

```
xDONE:BOOL;
```

```
END_VAR
```

```


if xInitOk then mPtr:=&modbusRegBuf; DO_Ptr:=&modbusDOBuf; DI_Ptr:=&modbusDIBuf;
AI_Ptr:=&modbusAIBuf;

inst1_MODBUS_SLAVE_CTRL(DO_ENABLE :=1 ,DO_PTR :=DO_Ptr ,DO_LENGTH :=5 ,DI_ENABLE :=1 ,
DI_PTR :=DI_Ptr ,DI_LENGTH :=5 ,AI_ENABLE :=1 , AI_PTR :=AI_Ptr ,AI_LENGTH :=10 ,REG_ENABLE :=1 ,
REG_PTR :=mPtr ,REG_LENGTH :=127 | xDONE := DONE, xERROR := ERROR);

end_if;

```

3.3.58 MODBUS_MASTER_INIT



用于初始化Modbus-RTU主站接口

Definition of operands:

ENABLE : enable or disable the function block,

true is enabled, false is disabled; **MODE** : mode

selection;

PORT : port number, 1 is 232 ,2 is 485 ;


BAUD : Baud rate, set the baud rate. 1200 , 2400 , 4800 , 9600 , 19200 , 38400 , 57600 ,

115200 ; **DATABITS** : Number of data digits **PARITY** : Set check

0 : No parity, 1 : Odd parity, 2 : Even parity **STOPBITS** : Stop bits

ERROR : The error code describes the information of the execution result of the function block.

3.3.59 MODBUS_MASTER_CTRL



执行Modbus-RTU主
站接口的控制指令（功能码）

Definition of operands:

ENABLE : function block enable

PORT : Serial interface definition number to

be used, 1 is 232, 2 is 485 ; **SLAVEID** : ID of

Modbus_RTU slave station ;

READWRITE : read and

write enable; **ADDRESS** :

slave address; **COUNT** :

the number of read or

write;

DATA_PTR : Array pointer to read or

write; **DONE** : Completion flag bit;


ERROR : error

message;

description:

Calling the function block **MODBUS_MASTER_CTRL** can realize the data sending and receiving of the **MODBUS-RTU** master station.

3.3.60 MODBUS_TCP_SLAVE_INIT



Definition of operands:

ENABLE : enable or disable the function block, **true** is enabled, **false** is disabled;

MODE : mode selection;

ADDRESS : specifies the slave address of the Ethernet TCP side;

NETNUMBER : network number;

CONFIRM : **false** : function block execution failed, **true** : function block execution succeeded;

ERROR : The error code describes information about the result of the

execution of the function block. Possible error codes are defined as

follows :**0**: No error occurred while executing the function block

1: A hardware error occurred while executing the function block

2: When calling the function block, an invalid mode was set

4: The set address is too large and exceeds the maximum available storage area

8: When calling the function block, an invalid ethernet interface was set

ERRORINFO : secondary error information

3.3.61 MODBUS_TCP_SLAVE_CTRL

INSTO_MODBUS_TCP_SLAVE_CTRL	
EN_IN	DONE
uint	MODBUS_TCP_SLAVE_CTRL
NETNUMBER	ERROR
bool	DO_ENABLE
pointer	DO_PTR
int	DO_LENGTH
bool	DI_ENABLE
pointer	DI_PTR
int	DI_LENGTH
bool	AI_ENABLE
pointer	AI_PTR
int	AI_LENGTH
bool	REG_ENABLE
pointer	REG_PTR
int	REG_LENGTH

用于执行Modbus-TCP从站接口的控制指令

Definition of operands:

NETNUMBER : network number;

DO_ENABLE : digital output

enable; **DO_PTR** : digital output

storage address; **DO_LENGTH** :

digital output length;

DI_ENABLE : digital input

enable; **DI_PTR** : digital input

storage address; **DI_LENGTH** :

digital input data length;

AI_ENABLE : analog input enable;

AI_PTR : analog input storage

address; **AI_LENGTH** : analog

input data length; **REG_ENABLE** :

register enable; **REG_PTR** :

register storage address;

REG_LENGTH : Register storage data

length; **DONE** : Completion flag bit;

ERROR : The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0: No error occurred while executing the function block

1: A hardware error occurred while executing the function block

2: When calling the function block, an invalid mode was set

4: The set address is too large and exceeds the maximum available storage area

8: When the function block is called, an

invalid Ethernet interface is set.

Example program:

VAR

lanInit:bool:=false; inst0_LAN_INIT:LAN_INIT;

mConfirm:bool; mError:uint; mErrorinfo:uint; mIP:udint; mNetMask:udint; mGateWay:udint;

mSocket:INT;

inst0_MODBUS_TCP_SLAVE_INIT:MODBUS_TCP_SLAVE_INIT;

mModbusInitOK:bool:=false; modbusDOBuf : ARRAY[0..5] OF byte; DO_Ptr : POINTER;

modbusDIBuf : ARRAY[0..5] OF byte; DI_Ptr : POINTER;

modbusAIBuf : ARRAY[0..10] OF int; AI_Ptr : POINTER;

modbusRegBuf : ARRAY[0..127] OF int; mPtr : POINTER;

xDONE:BOOL; inst4_MODBUS_TCP_SLAVE_CTRL:MODBUS_TCP_SLAVE_CTRL;

xError:uint;

mDI at %I0.0:byte; mAI at %I1.0:int; mDO at %Q0.0:byte;

END_VAR

```

if lanInit=false then

    mIP := LAN_ASCII_TO_INET('192.168.1.31'); mNetMask := LAN_ASCII_TO_INET('255.255.255.0');

    mGateWay := LAN_ASCII_TO_INET('192.168.1.1');

    inst0_LAN_INIT(ENABLE :=true , HOSTNAME := 'PLCCore', IP := mIP, NETMASK :=mNetMask,
    GATEWAY :=mGateWay ,NETNUMBER:=1

    | mConfirm:= CONFIRM,mError:= ERROR, mErrorinfo:= ERRORINFO); lanInit:=true;

else

if mModbusInitOK=false then

inst0_MODBUS_TCP_SLAVE_INIT(ENABLE := true, MODE := 1, ADDRESS :=1 ,

    NETNUMBER :=1 | mConfirm:= CONFIRM, mError:= ERROR, mErrorinfo:= ERRORINFO);

mModbusInitOK:=true; end_if;

end_if; mDO:=modbusDOBuf[0]; modbusDIBuf[0]:=mDI; modbusAIBuf[0]:=mAi;

modbusRegBuf[0]:=byte_to_int(mDI); modbusRegBuf[1]:=mAi;

modbusRegBuf[2]:=byte_to_int(mDO);

mPtr:=&modbusRegBuf; DO_Ptr:=&modbusDOBuf; DI_Ptr:=&modbusDIBuf; AI_Ptr:=&modbusAIBuf;


if mModbusInitOK=true then

inst4_MODBUS_TCP_SLAVE_CTRL(NETNUMBER :=1,DO_ENABLE :=1 , DO_PTR :=DO_Ptr ,
    DO_LENGTH :=5 , DI_ENABLE :=1 ,DI_PTR :=DI_Ptr , DI_LENGTH :=5 , AI_ENABLE :=1 ,
    AI_PTR :=AI_Ptr , AI_LENGTH :=10 , REG_ENABLE :=1 , REG_PTR :=mPtr , REG_LENGTH :=127 | xDONE :=
    DONE, xError := ERROR);

end_if;

```

3.3.62 MODBUS_TCP_MASTER_INIT



用于初始化Modbus-TCP主站接口

操作数的定义：

EN_IN: enable or disable the function block,

true is enabled, false is disabled; **MODE**: mode

selection;

REMOTE_IP_ADDR: Remote IP address

REMOTE_PORT: remote


port number **EN_OUT**:

completion flag;

SOCKET_ID: network ID

ERROR: The error code describes information about the result of the execution of the function block.

3.3.63 MODBUS_TCP_MASTER_CTRL



第 182 页

用于执行Modbus-TCP主
站接口的控制指令（功能码）

Definition of

operands **ENABLE** :

function block

enable; **NETNUMBER** :

network number;

SOCKET : network ID ;

SLAVEID : slave

station ID ;

READWRITE : read and

write enable; **ADDRESS** :

slave station address;

COUNT : the number of

read and write;


DATA_PTR : Pointer to store read and

write variable array; **DONE** :

Completion flag bit;

ERROR : The error code describes information about the result of the execution of the function block.

3.3.64 DT_CLOCK



用于设置实时时钟RTC并从PLC的RTC中读取日期和时间。这个功能块仅在配有RTC功能的控制器上可用

Definition of operands:

SET_YEAR, SET_MONTH, SET_DAY: year / month / day setting

SET_HOUR, **SET_MINUTE**, **SET_SECOND**: Hour / minute / second setting

SET: **TRUE**: Allows the inputs **SET_YEAR**, **SET_MONTH** and **SET_DAY** to change the date, allows the inputs **SET_HOUR**, **SET_MINUTE** and **SET_SECOND** to change the specific time, and at the same time, can read the setting at the respective outputs date and time.

FALSE: Only read the current date and time of the **RTC**,

the date and time cannot be changed. **YEAR**, **MONTH**,

DAY: output date of year / month / **day**

HOUR, **MINUTE**, **SECOND**: output time in hours / minutes / seconds

RELTIME: Read the relative form of date and time (seconds since

01.01.1980)

ERROR: Error code information describing the result of function block execution. Possible error codes are defined as follows:

No error occurred while executing the function block

A hardware error occurred while executing the function block

4 The mode (**MODE**) during a function block call is invalid

8 Power failure, invalid read time

16 Reading absolute time

and date invalid

description:

If the function block is called by setting the input **SET** to **TRUE**, the input date (**SET_YEAR**, **SET_MONTH** and **SET_DAY**) and input time (**SET_HOUR**, **SET_MINUTE** and **SET_SECOND**) can be passed to the **RTC** of the **PLC** according to their respective input values . At the same time, the set date and time can be read on the respective outputs. However, if the function block is called by setting the input **SET** to **FALSE**, only the current

date and time can be read, the **RTC** is not affected, the setting input is discarded, and possible errors during the execution of the function block are displayed at the output **ERROR**.

output is **ERROR=3** after the execution of the function block **DT_CLOCK**, the power supply is **RTC** interrupted (power failure or empty battery) and the read time is invalid. This error state remains until the **PLC**'s **RTC** is reset (the function block is called via the input **SET : =TRUE**) or the **PLC** is reset via the reset switch.

The following sample program shows the process of the function block **DT_CLOCK** setting and viewing the system **RTC**.

Sample program:

VAR

Year : UINT; Month : USINT; Day : USINT; Hour : USINT;

Minute : USINT; Second : USINT; RelTime : UDINT;

ErrorCode : ARRAY [0..1] OF USINT;

FB_DtClock : DT_CLOCK; END_VAR

LD 0

ST ErrorCode[0] ST ErrorCode[1]

CAL FB_DtClock (SET_YEAR := 2003,SET_MONTH := 8,SET_DAY := 6,SET_HOUR := 12, SET_MINUTE := 3,SET_SECOND := 0,SET := TRUE | Error[0] := ERROR)

CAL FB_DtClock (SET := FALSE)

LD FB_DtClock.YEAR ST Year

LD FB_DtClock.MONTH ST Month

LD FB_DtClock.DAY ST Day

LD FB_DtClock.HOUR ST Hour

LD FB_DtClock.MINUTE ST Minute


LD FB_DtClock.SECOND ST Second

LD FB_DtClock.RELTIME ST RelTime

LD FB_DtClock.ERROR ST ErrorCode[1] RET

END_PROGRAM

3.3.65 RTC



用于当IN=1时设置输出
CDT等于输入PDT，否则
CDT无效

操作数的定义：

IN : Function block

enable input **PDT** :

System date and

time **Q** : Same state

as **IN**

CDT : When **IN**=1 , output the system date and time

3.3.66 GETSYSTEMDATEANDTIME



Definition of

Operands: **EN**:

Enable Input

ENO: Enable

Output **ODT**:

System Time

Description:

This function block is used to display the actual system time at the output **ODT**,

which is not defined by the IEC61131-3 standard.

3.3.67 SETSYSTEMDATEANDTIME



Definition of operands:

EN: enable input

IDT: Set value of system


date and time **ENO**: Enable

output

describe:

sets the actual system time at the input **IDT**, which is not defined by the IEC61131-3 standard.

3.3.68 GETDATESTRUCT



由日期类型转为结构体类型

Definition of operands :

EN: enable input

IN : the date to convert


DATESTRUCT_INOUT: Converted date structure , such as:

datestruct : structYear : uint ; Month : usintDay :

usintend_struct Description:

GETDATESTRUCT converts a given date into a date structure, representing day, month, and year as separate integer variables.

3.3.69 NVDATA_BIT



用于在读取PLC存储单元(EEPROM)中数据的同时，写入过程数据(这些数据可以是1字节，或1个字，或4个字节)

Definition of operands:

DIN1 : write data of one

byte; **DIN2** : write data of

two bytes; **DIN3** : write

data of four bytes;

ADDR : address in memory for reading and writing data

(parameter mode needs to be set); **MODE** : setting for

performing read or write operations, all supported modes

are included in Table 31-1; **DEVICE** : device number, required

set to 0;

DOUT1 : read one byte of

data; **DOUT2** : read two

bytes of data; **DOUT3** : read

four bytes of data;

SIZE : When **MODE** is not 0, it is used to output the

number of bytes read or written, and when **MODE** is

0, it is used to output the available memory size;

ERROR : The error code describes information about the result of the

execution of the function block. Possible error codes are defined as

follows: **0**:No error occurred while executing the function block

1:A hardware error occurred while executing the function block

- 2: When calling the function block, an invalid device number was set
- 4: When calling the function block, an invalid mode was set
- 8: The set address is too large and exceeds the maximum available storage area
- 16: The pointer points to an unsupported data type function
- block call mode :

16#00 Determine available memory size

16#01 in **DOUT1**, read one byte of data

16#02 In **DOUT2**, read two bytes of data


16#03 In **DOUT3**, read four bytes of data

16#81 in **DIN1**, write one byte of data

16#82 in **DIN2**, write two bytes of data

16#83 in **DIN3**, write four bytes of data

3.3.70 NVDATA_BIN



用于在读取PLC存储单元(EEPROM)
中数据的同时，写入过程数据(
这些数据为二进制数据)

Definition of operands:

PTR_DINOUT: Digital input and output storage

address (for reading and writing data); **LENGTH** :

Length of read / write bytes;

ADDR : address in memory for reading and writing data
(parameter mode needs to be set) ; **MODE** : setting for performing read or write operations, all supported modes are included in Table 30-1 ; **DEVICE** : device number, required set to 0 ;

SIZE : When MODE is not 0, it is used to output the number of bytes read or written, MODE is 0, it is used to output the available memory size;

ERROR : The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows:

0: No error occurred while executing the function block

1: A hardware error occurred while executing the function block

2: When calling the function block, an invalid device number was set

4: When calling the function block, an invalid mode was set

8: The set address is too large and exceeds the maximum available storage area

16: The pointer points to an

unsupported data type mode


function:

16#00: Determine available memory size

16#09: Read binary data from memory , address at PTR_DINOUT

16#89: Write binary data to memory at address PTR_DINOUT

3.3.71 NVDATA_STR



该功能块用于将字符串过程数据写入PLC非易失性存储区中或从PLC非易失性存储区中读取字符串过程数据

Definition of operands:

EN: Function block enable input

LENGTH: Limit on the number of strings to read or write. If the value is 0,

the length of the string is internally defined (equal to **LEN (DINOUT)**);

note: the standard string buffer length in OpenPCS is 32 characters. **SETEOT**:

TRUE: string storage with terminating character **FALSE**: string storage without

terminating character (default :**TRUE**) **ADDR**: address in memory for reading

and writing data

MODE: The operating mode setting for read or write, list 12 includes all supported modes.

DEVICE: Device number, this parameter is determined by the respective

control system. (Note: Most control systems only support device number 0,

and device number 0 will be defaulted to the initial value, so it is not

necessary to set it separately)

DINOUT: Input and output for reading and writing string values

SIZE: used to indicate the number of bytes read or written (**MODE ≠ 0**) or

the available size of the non-volatile memory area (**MODE=0**) **ERROR**: The

error code indicates the information of the execution result of the function

block, and the possible error codes are defined as follows :

How to call the function block:

16#00 Determine the size of the available non-volatile memory

16#08 Read a string in a non-volatile buffer at the data output port **DINOUT**

16#88 Write a string to the non-volatile buffer at the

data input port **DINOUT** as described in:

The character string data in the non-volatile storage area can be read or written through the function block. According to the read or written data, the corresponding mode according to the list 12 must be set at the input **MODE**. In this case, the parameter **DINOUT** is used as input or output depending on the type of mode, and the value of the input **ADDR** is the base address where the read or write is performed. If the addressing range exceeds the maximum value, the function block will report an appropriate error. The **PLC** program is used to divide the available memory area and ensure that the values entered into **ADDR** do not cause overlapping of stored data. The number of bytes read or written is displayed to output **SIZE**. This value will be used to calculate the next free address (**ADDR new = ADDR old + SIZE**) enter **LENGTH** to specify the number of characters valid during the write process, if With a value of 0, the length of the string is determined internally (equal to **LEN (DINOUT)**) and is used as the number of characters written, in which case the entire used string content is written. The input **LENGTH** is also used when reading to limit the number of characters to be processed to the specified value.

Use the input **SETEOT** to set whether or not the end character of the string is also stored (default is **TRUE**) . Required (**LENGTH=0**), the function block will receive all character data until the end delimiter is detected in **DINOUT**. When the function block is called with **SETEOT =false**, the storage area of the terminator is empty. Therefore, each string will occupy less than one byte of non-volatile memory. But in this case the length of the string must be known and assigned to the input **LENGTH** during reading . If a terminator has already been written, the length of the terminator is still taken into account when the processed character is specified at the output **SIZE**. Therefore, when the function block is called with **SETEOT=TRUE**, the value of output **SIZE** is equal to **LEN** (**DINOUT**) +1 . When the function block is called with **MODE=0**, the size of the available area of the non-volatile memory will be determined. In this case, the remaining size of the remaining area from the input **ADDR** will be fed back to the output **SIZE** (**SIZE** : =**NVDATAFullSize-ADDR**). Calling the function block with **ADDR=0** will determine the full size of the non-volatile memory. Possible error messages during the execution of the function block will be displayed on the output **ERROR** and described in Table 10 (the error code is the same as the function block **NVDATA_BIT**).

The following sample program shows the application of the function block **NVDATA_STR**. Initially, a string is written from address 30 and then read from the same address, the standard settings remain the same, and the default device number is 0 .

Sample program :

VAR CONSTANT

```

NVDSTR_MODE_GET_SIZE : USINT := 16#00; NVDSTR_MODE_RD_STRING : USINT :=16#08;
NVDSTR_MODE_WR_STRING : USINT := 16#88; NVDATA_ERROR_SUCCESS      : USINT := 0;
NVDATA_ERROR_HW_ERROR      : USINT  :=  1;      NVDATA_ERROR_UNKNOWN_DEVICE :
USINT := 2; NVDATA_ERROR_INVALID_MODE   : USINT := 4;    NVDATA_ERROR_OUT_OF_MEM   :
USINT := 8;
```

END_VAR

VAR

WriteDataString : STRING; WriteDataSize : UINT; ReadDataString : STRING; ReadDataSize : UINT;

Error : ARRAY[0..1] OF USINT;

FB_NvDataStr : NVDATA_STR;

```
END_VAR

(* write a STRING value into EEPROM *) LD    'HelloWorld'

ST    WriteDataString

CAL   FB_NvDataStr ( DINOUT := WriteDataString,
LENGTH := 0,      (* save whole string  *)      SETEOT := TRUE, (* include termination character *)
ADDR := 30,
MODE := NVDSTR_MODE_WR_STRING

|
WriteDataSize := SIZE, Error[0] := ERROR)


(* read a STRING value from EEPROM *) CAL FB_NvDataStr

( DINOUT := ReadDataString,
LENGTH := 0,  (* read whole string *) ADDR := 30,
MODE := NVDSTR_MODE_RD_STRING

|
ReadDataSize := SIZE, Error[1] :=  ERROR) RET

END_PROGRAM
```

3.3.72 EXT_MOTOR_PWM_INIT



GC-2302模块初始化脉冲输出功能块

Definition of operands:

EN_IN : function block enable input;

NETNUMBER : The sequence number of the GC- 2302 module, the first GC-2302 module connected to the main control module or the coupler is 1 , the second GC-2302 module is 2 , and so on;

MOTOR_CH : The sequence number of the pulse output of each module, each GC-2302 module has two pulse outputs, the first pulse output serial number is 1 , and the second pulse output serial number is 2 ;

MOTOR_MODE : The pulse output mode of the GC-2302 module : 1 is the speed mode, 2 is the position mode, 3 is the pulse mode Acceleration time, meaningless in pulse mode

DECTIME : Deceleration time,

meaningless in pulse mode **FLEX** :

Slope factor:

EN_OUT : function block enable output;

ERROR : The error code describes the

information about the result of the execution

of the function block Description:


This function block is used to initialize the pulse output of the **GC-2302 module**.

There are three pulse output modes . When **MOTOR_MODE** is 1 and 2 , the three parameters **ACCTIME** , **DECTIME** and **FLEX** are meaningful for configuring the motor. in the output address

Define and call the function block **EXT_MOTOR_EN** to configure the motor parameters.

When **MOTOR_MODE** is 3 , the output of the terminal module is pure pulse. Similarly, the output address can be defined in the program to configure the pulse duty cycle and frequency.

3.3.73 EXT_MOTOR_EN



GC2302模块使能电机功能块

Definition of operands:

EN_IN : function block enable input;

NETNUMBER : GC-2302 The serial number of the module, the first GC-2302 after the main control module or the coupler Module is 1 , the second GC-2302 The module is 2 , and so on;

MOTOR_CH : The sequence number of the pulse output of each module, each GC-2302 module has two pulse outputs, the first pulse output serial number is 1 , and the second pulse output serial number is 2 ;

MOTOR_MODE : GC-2302 module pulse output

mode: 1 is speed mode, 2 is position mode,

3 is pulse mode **ENABLE** : motor enable


signal

EN_OUT : function block enable output;

ERROR : The error code describes the information about the result of the execution of the function block Description:

This function block is used to enable the motor with the GC-2302 pulse output module. In the program, the function block **EXT_MOTOR_PWM_INIT** needs to be called in advance to initialize the output terminal module and configure the parameters. After the initialization is successful, the function block is called to enable the motor, and the motor will run according to the set parameters.

3.3.74 CTU



Definition of

operands: **CU** :

count pulse

RESET : reset

counter **PV** :

count limit value

Q : Displays whether the

counter reaches the limit


value **CV** : Current counter

value

describe:

The function block is used to count the number of pulses received from the input CU, when initialized, the value of the counter will be set to 0, if the input RESET is set to 1, the value of the counter will be reset, each detected rising edge at input CV it will make the value of the counter +1, and the output CV is the current value of the counter. If the counter value is less than PV, the output Q is 0, and if the counter value is greater than or equal to PV, the output Q is 1.

3.3.75 CTD



减计数

Definition of

operand: **CD**:

count pulse

LOAD: set

initial value

PV: initial value

Q: Output 1 when the

counter value is 0


CV: The value of the

counter

describe:

function block CTD collects the pulse signal at the input CD and performs a countdown operation. If the value of the parameter LOAD is 1, the value of the operand PV will be loaded into the counter. Every time a rising edge is detected at the input CD, the counter will be counted. The value is minus 1, the output CV is the current value of the counter , if the value of the counter is positive, the value of the output Q is 0. If the value of the counter is less than or equal to 0, the value of the output Q is 1, and the function block has been approved by IEC61131-3 standard definition.

3.3.76 CTUD



加、减计数

Definition of

operands: **CU:**

count up on

rising edge **CD:**

count down on

rising edge

RESET: reset

counter **LOAD:**

load initial

value **PV:**

initial

value

QU: Displays whether the

value of the counter is

greater than **PV** **QD:**

Displays whether the

value of the counter is

greater than **0** **CV:**

Current value of the

counter

describe:


function block **CTUD** is used to count up and down. The value of the counter at initialization is **0**. Each rising edge at the input **CU** will increment the counter by **1**, and each rising edge at the output **CD** will decrement the value of the counter by **1**.

If the value of operand **LOAD** is **1**, the value of **PV** will be loaded into the counter

If the value of operand **RESET** is **1**, the value of the counter will be **0**. If **RESET** remains at **0**, the normal operation of counting and loading will not be affected.

output **CV** is the current value of the counter. If the counter value is less than **PV**, the output **QD** will be **0**. If the counter value is greater than or equal to **PV**, the output **QD** will be **1**. If the counter value is positive, the output **QD** will be **0**, if the counter value is less than or equal to **0**, then the output **QD** will be **1**. This function block has been defined in the **IEC61131-3** standard.

3.3.77 INIT_TBL



初始化列表存储功能块

Definition of operands:

EN_IN: enable initialization list

storage function block; **COUNT:**

define the number of members in the

list; **TBL_PTR:** array pointer of list

members; **EN_OUT:** function block


enable output; **ERRORINFO : error**

message description of the function

block execution result :

This function block is used to initialize the list storage function. The number of list members is defined by the input **COUNT**, and the array pointer where the list members are defined by **TBL_PTR**.

3.3.78 FIFO_TBL



列表成员先进先出

Definition of operands:

EN_IN: enable list member FIFO

function block; **TBL_PTR:** array

pointer of list member; **EN_OUT:**

function block enable output;

DATA: First-in, first-out list


members; **ERRORINFO :** Error

information of the execution result

of the function block Description:

This function block is used for first-in, first-out of list members. The function block is enabled by the input **EN_IN**, and **TBL_PTR** defines the array pointer where the list members are located.

3.3.79 LIFO_TBL



列表成员先进后出

Definition of operands:

EN_IN: Enable list member FIFO

function block; **TBL_PTR:** Array

pointer of list member; **EN_OUT:**

Function block enable output;

DATA: First-in, last-out list member;


ERRORINFO : Error message

description of the function block

execution result:

This function block is used for the first-in, last-out of the list members. The function block is enabled by the input **EN_IN**, and **TBL_PTR** defines the array pointer where the list members are located.

3.3.80 ADD_TBL



添加列表成员

Definition of operands:

EN_IN: Enable adding list member function block; **TBL_PTR:** Array pointer of list member;

DATA: added list members;

EN_OUT: function block

enable output; **COUNT:** the

number of list members;

ERRORINFO : Error message

description of the function block

execution result:

enabled by the input **EN_IN**, and **TBL_PTR** defines the array pointer where the list members are located.

3.3.81 COUNT_TBL



Definition of operands:

EN_IN: Enable list member

count function block; **TBL_PTR:**

Array pointer of list members;

EN_OUT: Function block enable


output; **COUNT :** Number of

list members;

describe

This function block is used to count the number of list members, the function block is enabled by the input **EN_IN**, and **TBL_PTR** defines the array pointer where the list members are located.

3.3.82 PID1



该功能块用于实现PID控制

Definition of Operands

ENABLE : If the input rising edge is detected, the control factors KR, T0, TI, TD will be received by the system, and the integral sum of the initial value deviation will be calculated at the same time. The outputs READY, ERROR and CO are reset by setting ENABLE=0. The function block checks the valid area and, if necessary, displays an overflow error at the output ERROR during the transfer of parameters T0 and BIAS;

SPV : controller standard setting value (control variable), valid range is 0.0~1.0 , the function block will automatically detect the parameters (but will not detect overflow errors)

APV : controller standard actual value (process variable), valid range is 0.0~1.0 , the controller will automatically detect the parameter (but will not detect overflow error)

KP :

proportional

coefficient;

KI : integral

coefficient;

KD :

differential

coefficient;

READY : Output state of the PID controller TRUE = the function blocks of the controller are fully parameterized and have entered the pre-operational state. FALSE= The function block of the controller is not fully parameterized or incorrectly parameterized (the control parameter is outside the valid value range) , the controller does not enter pre- operational mode.

CO: The output of the controller, the correction variable of the controller is

calculated (the value range is 0.0~1.0)

ERROR: The error code indicates the information of the execution result of the function block. The possible error codes are defined as follows:

0: No error occurred during function block execution

8: The value of the specified parameter **BIAS** is invalid (less than 0 or greater than 1)

16: The value of the specified parameter **T0**

is invalid (time is equal to 0)

Description:


This function block is used to implement PID control, if a rising edge is detected at the input **ENABLE**, the function block receives the control parameters **KR**, **TO**, **TD**, **TI** and **BIAS** and starts the controller. In the first operation, the setpoint and the last actual value are set to the current actual value. The first time the correction variable is calculated, the initial deviation value is usually present, because the proportional gain, integral gain and derivative gain all default to 0 for the first time. The performance of the controller will be affected by the control parameters. If **TI=t#0ms**, the integral gain of the controller will not be calculated and will be assigned a value of 0. If **TD=t#0ms**, the value of the differential gain will be assigned to 0. If the gain of the parameter **KR** is 0, the proportional gain is not needed. Since the **KR** gain is related to both the proportional gain and the derivative gain, the integral and derivative gains are set to 1 here. P controller: **TI=TD=0**, **KR ≠ 0**,

The integral and derivative gains are 1. PI controller: TD=0, KR, TI ≠ 0. PID controller: KR, TI, TD ≠ 0. There are many ways to determine control parameters (tangent to inflection point, oscillation test), and parameters can also be determined by simulation tools. However, it is necessary that the complete control system be described as a model in terms of frequency and phase response. Models of the relevant transfer parameters of the control system can be built from known values and states and used to determine the parameters during the simulation. The set value, actual value, deviation value and correction variable are used as standard variables. The value of these standard variables varies from 0.0 to 1.0. When the function block starts to execute, the valid range of the deviation will be checked. When the deviation value exceeds the valid range Outputting ERROR will report an error. Setpoints and actual values are not checked during program run. The function block limits the value of the correction variable and the integral sum, and if the result of the calculation is negative, the variable value is set to 0. If the value exceeds 1, the variable value is set to 1. In addition, the integral sum is affected by the correction variable, also following the following rules:

If the value of the correction variable is greater than 1, the integral sum is calculated as follows: Integral sum = 1 - (proportional gain + differential gain)

If the value of the correction variable is greater than 0, the integral sum is calculated as follows: Integral gain = 1 - (Proportional gain + differential gain)

3.3.83 SYS_PLA_RESET



PLC系统复位重启功能块

Definition of operands:

ENABLE: Enable PLC system reset restart function block;

ERROR : The error code describes information

about the result of the execution of the

function block; description:

This function block is used to reset and restart the PLC system. When the input ENABLE is 1, the PLC will stop the current process and restart.

3.3.84 PTO_PWM

INSTO_PTO_PWM			
ENABLE	READY	PTO_PWM	bool
bool	PTO_MODE	BUSY	bool
bool	APPEND	ERROR	usint
usint	TB_IDX		
uint	CT		
uint	PT		
int	DELTA		
udint	PC		
usint	CHANNEL		

脉冲输出PTO功能块

Definition of operands:

ENABLE: enable or disable the function block,

true is enabled, **false** is disabled; **PTO_MODE**: mode

selection

1 : PTO generator (pulse counter output, one-shot pulse train)

0 : PWM generator (pulse width modulated output, continuous pulse train)

while input **ENABLE** is 1 terminates the functions set in the previous mode

APPEND: used to control extension parameters

1 : Accept currently configured parameters as further parameter sets

0 : Only update the output status of the function block, discarding the previously configured parameters

T B _ I D X: used to set the basic period of the pulse generator, this parameter depends on the corresponding control mode. The valid values are as follows: **0=800ns**

Basic period **1=1ms** basic period

set after a rising edge is received at the input **ENABLE**

CT : PTO Mode:

Duration **PWM** Mode:

Cycle Time

The duration and cycle time depend on the basic cycle specified by the input **TB_IDX**:
TB_IDX:=0:

125...65535(100μs-52428μs)TB_IDX:=1: 2...65535(2ms-65535ms)

PT : PTO Mode: Not used

PWM mode: Pulse duration, value range: **0...65535**

DELTA : PTO mode: continuous period change between two pulses, value

range :**-32768...+32767** PWM mode: not used

PC : PTO mode: number of pulses, value

range :**1...4294967295** **CHANNEL** : channel

number used

READY : The output status of the pulse generator

1 : The pulse generator is fully parameterized and the generator is ready to run

0 : The pulse generator is not parameterized, or the

function block terminated with an error, the generator is

not ready **BUSY** : Status output of the pulse generator:

1: Pulse generator active (pulse train is being generated); generator controls digital output

0: The pulse generator is inactive (the pulse train has been generated); the process image controls the digital output (PLC program direct image output)

ERROR : The error code indicates the information of the execution

result of the function block. The possible error codes are

defined as follows: **0** : There is no error during the execution of

the function block

1 : A hardware error occurred during the execution of the function block

2 : The selected channel number is not supported

8 : The index of the selected base period is not supported

16 : Overflow bug in recalculation of duration when **DELTA** is considered

32 : No space available in the data record

buffer, the data record has been discarded

Description:

The function blocks directly parameterize the pulse generators **PTO** (Pulse Train Output) and **PWM** (Pulse Width Modulation Output). Pulse output mode

Is an alternative to digital output. If **ENABLE=0** is entered, the process image directly affects the corresponding digital output. If you enter

ENABLE=1, the pulse generator controls the output.

PTO generator (**PDO_MODE=1**, pulse counter output, one-shot pulse train): The **PTO** generator creates a one-shot pulse train to control the digital output. A pulse train is described by a parameter set that includes the cycle duration (initial value) , the increment of the cycle duration (the change in value between two consecutive pulses), and the number of pulses to generate. The pulse width is set to **50%** of the period duration (sampling ratio **1:1**). Considering **DELTA**, the cycle duration **Tn** is calculated as follows: $Tn=(CT+n*DELTA)*tB$ (**0<=n<=PC**)

If **tB=1ms** (**tB_IDX:=1**) and **CT:=1000** , the initial cycle duration (**n=0**) is: **Tn=1ms*1000=1** second (variation of period duration) and pulse trains of pulse number values are connected . To do this, the function block needs to be called with **APPEND=1** , making each parameter set expandable.

This extends up to **255** parameter sets. until **ERROR=32** (no space available in the data record buffer, the data record has been discarded) . All parameter sets are based on the same time criteria. The time standard (input **TB_IDX**) can only be changed when the pulse generator is deactivated. Time standard indexing is only started when a rising edge is detected at input **ENABLE**. If the pulse train has been completely transmitted and no further parameterization is available, the pulse generator **PTO** is automatically switched off and the process image controls the digital outputs again. Therefore, the **PLC** program must store in the process image the desired state of the digital outputs after the pulse generator is deactivated. The **PTO** generator also automatically shuts down if an overflow or underflow error occurs during subsequent pulses . This is the case if **Tn** is greater than **65535** or less than **0** . The function block displays **ERROR=32** (overflow error). Since it is an accumulation operation including **DELTA**, the result of **ERROR** is obtained after a series of consecutive successful operations.

PWM generator (**PDO_MODE=0**, pulse duration output, continuous pulse train): In the **PWM** generator function, a continuous pulse train is generated at the digital output. In this case, the cycle duration and pulse duration can be set to the number of basic cycles.

If the input **ENABLE** is **1**, the **PWM** generator is activated directly after the parameters are acquired. If the pulse duration **PT** has a value of **0**, the individual outputs remain inactive for the entire cycle duration. However, if the value of the pulse duration **PT** is greater than or equal to the cycle duration, the output is active for the entire cycle duration. The continuous duty time is always changed asynchronously, and the current duty state is interrupted by receiving a new value. The duration of the pulses is varied synchronously and accepted at the beginning of the next cycle duration. The parameters are changed by calling the function block with **APPEND=1**, and the generation of continuous pulse trains is terminated with **ENABLE=0**. If an error occurs during execution, the function block automatically shuts down. The function block can only be reused after it has been reset with **ENABLE=0**.

output **READY** indicates that the function block is fully parameterized and enters the pre-operational state, the parameter **TB_IDX** (used to set the index of the basic period of the pulse generator) is not changed (**TB_IDX** is only read when a rising edge is detected at input **ENABLE**), if the function block is called with **ENABLE=0, READY=0** is output.

If the function block output **BUSY=1**, it means that the pulse generator is activated and controls the corresponding digital output (**PTO** mode: parameterized pulse train is transmitted, **PWM** mode: continuous pulse train is generated). **BUSY=0** means the generator is not activated and is controlled by the **PLC** program

The corresponding digital outputs are directly influenced via the process image.

Possible error messages during function block execution are displayed in **ERROR**.

The example program below shows the application of the function block to generate a one-shot pulse train in **PTO** mode and a continuous pulse train in **PWM** mode . Due to the particularity of parameter selection, no additional techniques or test equipment are required to observe the **LED** light state of the pulse train at the output **PWM**. The **PTO** cycle mode is started by a rising edge at the output **xStartButton**. The burst starts with a **1s** pulse (**CT*TB=1000*1ms=1s**), each subsequent pulse is shortened by **50ms** (**Delta=-50**). A total of **15** pulses are generated (**PC=15**) . **PWM** mode is started by a rising edge at input **xStartButtonPwm**. The resulting burst duration is **500ms** (**CT*TB=500*1ms=0.5s->2Hz**), the **on-time** of each pulse is **150ms** (**PT*TB=150*1ms=150ms**).

Sample program:

VAR CONSTANT

```
(* Definition of TimeBase-Index *) PTO_TB_IDX_800_US:USINT:=0;      (* TimeBase-Index 800us *)
PTO_TB_IDX_1_MS:USINT:=1;    (* TimeBase-Index 1ms   *) (* Error Codes of FB PTO_TAB *)
PTOTAB_ERROR_SUCCESS:SINT=0;

PTOTAB_ERROR_HW_ERROR: USINT:=1;

PTOTAB_ERROR_UNKNOWN_CHANNEL:USINT:=2; PTOTAB_ERROR_UNKNOWN_TB_IDX:USINT:= 8;
PTOTAB_ERROR_DELTA_OVERFLOW:USINT:=16; PTOTAB_ERROR_INVALID_TAB:USINT:=64;
PTO_PWM_CHANNEL:USINT:=0;

END_VAR VAR

xStartButtonPto AT %IX0.0 : BOOL; xStartButtonPwm AT %IX0.1 : BOOL; xPtoPwmOut AT %QX2.4 :
BOOL;

FB_RTrigPto  : R_TRIG; FB_RTrigPwm  : R_TRIG; usiPtoTbIdx: USINT := 1; uiPtoCt : UINT  := 1000;
iPtoDelta : INT    := -50;
```

```
udiPtoPc : UDINT := 15; usiPwmTbIdx : USINT := 1; uiPwmCt : UINT := 500;
```

```
uiPwmPt : UINT := 150;
```

```
xPtoAppend : BOOL := TRUE; xPtoReady : BOOL := FALSE;
```

```
xPtoBusy : BOOL := FALSE;  
  
xPwmAppend : BOOL := TRUE; xPwmReady : BOOL := FALSE;  
  
xPwmBusy : BOOL := FALSE;  
  
FB_PtoPwm : PTO_PWM; usiPtoPwmError : USINT;  
  
END_VAR
```

(* ----- Wait for Start-----*) WaitForStart:

```
CAL FB_RTrigPto  
  
LD FB_RTrigPto.Q JMPC StartPtoMode CAL FB_RTrigPwm  
  
LD FB_RTrigPwm.Q JMPC StartPwmMode LD xPtoBusy  
  
JMPC RunPtoMode  
  
LD xPwmBusy  
  
JMPC RunPwmMode  
  
JMP ProgExit
```

(* ----- Run PTO Mode-----*)

StartPtoMode:

```
LD FALSE (* preset output state, this state is *) ST xPtoPwmOut (* used when PTO  
Generator isn't running *) LD FALSE (* reset state flags *)  
  
ST xPtoReady  
  
ST xPtoBusy  
  
ST xPwmReady  
  
ST xPwmBusy
```

```
CAL FB_PtoPwm ( ENABLE := FALSE,  
CHANNEL := PTO_PWM_CHANNEL)  
  
CAL FB_PtoPwm ( ENABLE := TRUE, PTO_MODE := TRUE,  
APPEND := xPtoAppend, TB_IDX := usiPtoTbIdx, CT := uiPtoCt,  
DELTA := iPtoDelta, PC := udiPtoPc,  
CHANNEL := PTO_PWM_CHANNEL  
  
|  
xPtoReady := READY, xPtoBusy := BUSY, usiPtoPwmError := ERROR)
```

RunPtoMode:

```
CAL FB_PtoPwm ( ENABLE := TRUE, PTO_MODE := TRUE, APPEND := FALSE,  
CHANNEL := PTO_PWM_CHANNEL  
  
|  
xPtoReady := READY, xPtoBusy := BUSY, usiPtoPwmError := ERROR)  
  
JMP ProgExit
```

(* ----- Run PWM Mode-----*)

StartPwmMode:

```
        FALSE          preset output state, this state is  
D      xPtoPwmO *          used when PTO Generator isn't      )  
        ut           running  
T      *          )
```

FALSE reset state flags *)
 D *

 xPtoReady

 T

 xPtoBusy

 T

ST xPwmReady

ST xPwmBusy

CAL FB_PtoPwm (ENABLE := FALSE,

CHANNEL := PTO_PWM_CHANNEL)

CAL FB_PtoPwm (ENABLE := TRUE, PTO_MODE := FALSE,

APPEND := xPwmAppend, TB_IDX := usiPwmTbIdx, CT := uiPwmCt,

PT := uiPwmPt,

CHANNEL := PTO_PWM_CHANNEL

|

xPwmReady := READY, xPwmBusy := BUSY, usiPtoPwmError := ERROR)

RunPwmMode:

CAL FB_PtoPwm (ENABLE := TRUE, PTO_MODE := FALSE, APPEND := FALSE,

CHANNEL := PTO_PWM_CHANNEL

|

xPwmReady := READY, xPwmBusy := BUSY, usiPtoPwmError := ERROR)

JMP ProgExit

(* ----- Cycle End ----- *) ProgExit:

RET END_PROGRAM

3.3.85 PTO

INSTO_PTO	
ENABLE	READY
PTO	
TB_IDX	BUSY
uint	bool
RECORDS	ERROR
uint	usint
CHANNEL	
uint	
DO_IDX	
TABLE	TABLE
Array[0..255] of pto_record	

用于执行脉冲计时器。典型的应用例子是控制步进电机的单脉冲，实现步进电机控制的斜坡函数

Definition of operands:

TABLE : parameter setting table, containing the pulse sequence to be generated;

ENABLE : enable or disable the function block, **true** to enable,

false To disable;; **TB_IDX** : set the reference period for the

pulse generator, 0=800ns , 1=1ms ; **RECORDS** : the address in

the memory, used to read and write data (need to set the

parameter mode); **CHANNEL** : the channel to be used No;

DO_IDX : device number, needs to be set to 0 ;

TABLE : read one byte of data;


READY : Indicates the output state of the pulse generator, **True** represents initialized, **False** represents uninitialized;

BUSY : Indicates the output state of the pulse generator, **True** means the pulse generator is busy, **False** means the pulse generator is idle;

ERROR : The error code describes information about the result of the execution of the function block. Possible error codes are defined as follows :**0**:No error occurred while executing the function block

- 1: A hardware error occurred while executing the function block
- 2: When calling the function block, an invalid device number was set
- 4: When calling the function block, an invalid mode was set
- 8: The set address is too large and exceeds the maximum available storage area
- 16: The pointer points to an unsupported data type

3.3.86 GETVARDATA



Definition of operands:

EN : Enable input

VarName : String name of the

variable to be accessed **Q** :

Output 1 if the variable is

valid **VarData** : Valid variable

information

describe:

The variable specified at the input is located in the memory address space and information about the variable is displayed at the output, if the variable cannot be addressed, the output **Q** is 0 . OpenPCS must have the function of addressing by name. The premise of this function is to generate a mapping file in the resource option.

3.3.87 GETVARFLATADDRESS



查询变量地址

Definition of operands:

EN : Enable input.

VARNAME : The string name of the variable to be queried. **Q** : Output
1 if the variable is valid .

VARADDRESS : The address of the variable to be queried.

describe:

If the variable specified at the input is in the memory address space, the address of the memory space is output. If the variable is not in the memory address space, the output **Q** will be 0

In order for OpenPCS to be addressable by name, a memory-mapped file must be generated (in the resource options). The memory address space can only be used in the current program cycle and cannot be stored or called by other programs.

3.3.88 GETTASKINFO

INST0_GETTASKINFO	
EN	dword
GETTASKINFO	
COUNT	dword
LASTCT	time
AVERAGECT	time
MINCT	time
MAXCT	time
STATE	dword

获取任务周期各执行时间

Definition of operands:

COUNT: the number of cycles

to perform this task; **LASTCT**:

the time required for the

previous cycle;

AVERAGECT: Average time required for execution; **MINCT**: Minimum

time required for execution; **MAXCT**: Maximum time required for

execution;

STATE: not yet

used; description:

This function block returns information about the execution time of the last cycle of the current task. This function block has no input parameters.

4. Explanation of basic function application routines

Since the previous article has introduced how to open program files, compile programs, download programs, etc., this chapter will not describe in detail. The content of this chapter only explains the programming ideas, programming logic and functions implemented by the routines.

1. Explanation of Marquee Experiment Routine



```
9VAR
10
11 v1:INT:=0;          (*定义整形变量，初始值为0*)
12 v2:INT:=0;
13 oled at%Q0.0:Byte; (*输出Q0.0~Q0.7共8位*)
14
15END_VAR

1
2
3IF v1<1000 THEN      (*如果v1<1000，则自加1*)
4    v1:=v1+1;
5
6ELSE                  (*如果v1=1000，则把v1赋值为0*)
7    v1:=0;
8    v2:=v2+1;
9    if v2>=255 then   (*如果v2加到255，则把v2赋值为0*)
10       v2:=0;
11   end_if;
12   oled:=int_to_byte(v2); (*将数据类型为int的v2转化为byte赋值给oled*)
13
14end_if;
15
```

In this program, the initial value of the V1 variable is 0. When V1 is less than 1000, V1 is incremented by 1. After 1000 scan cycles, the value of V1 is 1000. Enter ELSE, V1 returns to 0, and V2 starts to increment by 1. Return to zero, so the next cycle continues to enter V1 and increments by 1. The actual effect of this program is that every time V1 is added to 1000, V2 is incremented by 1.

When V2 is added to 255 each time, V2 is reset to zero, and the data type of V2 is converted to BYTE and assigned to oled every cycle to output the marquee.

data conversion is performed because BYTE cannot directly perform mathematical operations, so it is necessary to use INT to add to realize the phenomenon of marquee.

2. Input and output experiment

The screenshot shows a PLC program editor with two main sections: a variable declaration area and a ladder logic area.

Variable Declaration Area (Top):

```
11 DIO AT%IO.0:BOOL; (* 数字量输入1 *)
12 DIO1 AT%IO.1:BOOL; (* 数字量输入2 *)
13 DIO2 AT%IO.2:BOOL; (* 数字量输入3 *)
14 DIO3 AT%IO.3:BOOL; (* 数字量输入4 *)
15 DIO4 AT%IO.4:BOOL; (* 数字量输入5 *)
16 DIO5 AT%IO.5:BOOL; (* 数字量输入6 *)
17 DIO6 AT%IO.6:BOOL; (* 数字量输入7 *)
18 DIO7 AT%IO.7:BOOL; (* 数字量输入8 *)
19
20 DO0 AT%Q0.0:BOOL; (* 模拟量输出1 *)
21 D01 AT%Q0.1:BOOL; (* 模拟量输出2 *)
22 D02 AT%Q0.2:BOOL; (* 模拟量输出3 *)
23 D03 AT%Q0.3:BOOL; (* 模拟量输出4 *)
24 D04 AT%Q0.4:BOOL; (* 模拟量输出5 *)
25 D05 AT%Q0.5:BOOL; (* 模拟量输出6 *)
26 D06 AT%Q0.6:BOOL; (* 模拟量输出7 *)
27 D07 AT%Q0.7:BOOL; (* 模拟量输出8 *)
28
29 AIO AT%IO.0:int; (* 模拟量输入1 *) (* int形式的变量用于定义-32767~+32767的输入 *)
30 A11 AT%I2.0:int; (* 模拟量输入2 *)
31 A12 AT%I4.0:int; (* 模拟量输入3 *)
32 A13 AT%I6.0:int; (* 模拟量输入4 *)
33
34 A00 AT%Q5.0:uint; (* 模拟量输出1 *) (* uint形式的变量用于定义0~+65535的输出 *)
35 A01 AT%Q3.0:uint; (* 模拟量输出2 *)
36
37 A02 AT%Q5.0:int; (* 模拟量输出3 *) (* int形式的变量用于定义-32767~+32767的输出 *)
38 A03 AT%Q7.0:int; (* 模拟量输出4 *)
39
40 v1:bool;(* 中间变量1 *)
41 v2:bool;(* 中间变量2 *)
42
```

Ladder Logic Area (Bottom):

```
1 2D00:=DIO; (* 数字量输出=数字量输入 *)
3 D01:=D11;
4 D02:=D12;
5 D03:=D13;
6 D04:=D14;
7 D05:=D15;
8 D06:=D16;
9 D07:=D17;
10
11 if AIO>5000 then (* 电压/电流输入换算值大于5000 *)
12
13 v1:=1;
14 v2:=0;
15
16 else
17     (* 电压/电流输入换算值小于等于5000 *)
18 v1:=0;
19 v2:=1;
20
21 end_if;
22
23 A00:=-65535; (* 输出换算值为65535的电压/电流 *)
24 A01:=-50000; (* 输出换算值为50000的电压/电流 *)
25
26 A02:=-32767; (* 输出换算值为32767的电压/电流 *)
27 A03:=-32767; (* 输出换算值为-32767的电压/电流 *)
28
```

Notes from the ladder logic comments:

- Line 11: 计数和频率均为32位(*)
- Line 22: 2204位宽为8位，但只用到了前4位，后4位为空(*)

In this program, the variable declaration area reflects how the variable with the hardware address of the IO module is declared, and the program editing area reflects the use of simple statements, as well as the corresponding data type and value range of the IO module.

3. CAN Send and receive data experiment ST

The screenshot shows a PLC program editor with a single function block definition for CAN initialization.

```
1 (*该程序实现了将每个读到的CAN帧信息在CANID加1后重新写出去*)
2
3 canCH:=2; (*使用的CAN端口号，PLC-400/510的CAN端口号为2，PLC-core的CAN端口号为1或2*)
4
5 if not mCanInit then (*如果未初始化CAN口*)
6
7     inst0 CAN_INIT(EN_IN :=1 ,
8         NETNUMBER :=canCH , (*PLC的CAN口初始化功能块，EN_IN为使能；NETNUMBER为端口号，PLC-400/510为2；初始化功能块只在上电第一个周期启动，若*)
9         BERRATE:= ERROR);
10    if xERROR=0 then (* BITRATE = 0表示1 Mbit/s BITRATE = 1表示840 kBit/s BITRATE = 2表示700 kBit/s BITRATE = 3表示500 kBit/s BITRATE = 4表示400 kBit/s*)
11        mCanInit:=true; (* BITRATE = 5表示250 kbit/s BITRATE = 6 表示200 kbit/s BITRATE = 7 表示125 kbit/s BITRATE = 8 表示100 kbit/s BITRATE = 9 表示80 kbit/s*)
12    end_if;
13
14 else
15     inst1_CAN_MESSAGE_READ(EN_IN :=can_read (*如果CAN初始化成功，则启动CAN读功能块*),
16         NETNUMBER := canCH | (*CAN读功能块读到CAN帧数据的标志*)
```

This section of the program is a CAN initialization function block. The use of the function block has been explained in Chapter 3, and will not be described in detail in this

section. The parameters for adjusting the baud rate can be seen in the program comments. The logic of this program is that if the CAN initialization completion flag is FALSE executes initialization, the initialization ERROR is 0 , the flag bit becomes TRUE , and the next time it judges IF , it enters the ELSE program segment.

```

16
17else
18
19    inst1_CAN_MESSAGE_READ8(EN_IN :=can_read (*如果CAN初始化成功，则启动CAN读功能块*)
20    , NETNUMBER := canCH |
21    mCanConfirm := EN_OUT,
22    mCANID := CANID,
23    mEXT_FRAME := EXT_FRAME,
24    mRTR_FRAME := RTR_FRAME,
25    mDATALENGTH := DATALENGTH,
26    mDATA0:= DATA0,
27    mDATA1:= DATA1,
28    mDATA2 := DATA2,
29    mDATA3:= DATA3,
30    mDATA4:= DATA4,
31    mDATA5:= DATA5,
32    mDATA6 := DATA6,
33    mDATA7 := DATA7,
34    xERROR:= ERROR);
35
36    if mCanConfirm=1 then
37        canID:=mCANID;
38        canDAT0:=mDATA0;
39        canDAT1:=mDATA1;
40        canDAT2:=mDATA2;
41        canDAT3:=mDATA3;
42        canDAT4:=mDATA4;
43        canDAT5:=mDATA5;
44        canDAT6:=mDATA6;
45        canDAT7:=mDATA7;
46        can_read:=0;
47        can_write:=1;
48    end_if;
49
50
51    if can_write=1 then
52        mCANID:=mCANID+1;
53    end_if;
54

```

Enter ELSE After the program segment, execute **CAN_READ** , CAN Read function block, where mDATA0-7 For the read data, only the actual data is read at the moment of reading, and the rest of the time is a random number, mCanConfirm In order to read the complete flag bit, it is only set to TRUE at the moment of reading the data, and it returns to FALSE immediately in the next cycle , so a judgment is made when the flag bit is 1 In that cycle, immediately assign the read data to another variable to save the data, turn off the read enable, and turn on the write enable. write enable as 1 Add CANID+1 to avoid writing out the ID The same as receiving data frame collision. (Note: It is the logic of the routine to turn off the read enable here, CAN Read function block enable is always set to 1 Can be read all the time.)

```

50
51    if can_write=1 then
52        mCANID:=mCANID+1;
53    end_if;
54
55
56    inst2_CAN_MESSAGE_WRITE8(
57        EN_IN :=can_write ,
58        NETNUMBER := canCH ,
59        CANID :=mCANID ,
60        EXT_FRAME := mEXT_FRAME,
61        RTR_FRAME := mRTR_FRAME,
62        DATALENGTH :=mDATALENGTH ,
63        DATA0 :=mDATA0 ,
64        DATA1 :=mDATA1 ,
65        DATA2 :=mDATA2 ,
66        DATA3 :=mDATA3 ,
67        DATA4 :=mDATA4 ,
68        DATA5 :=mDATA5 ,
69        DATA6 :=mDATA6 ,
70        DATA7 :=mDATA7 );
71    mCONFIRM := EN_OUT,
72    xERROR:= ERROR);
73
74    if mCONFIRM=1 then
75        can_read:=1;
76        can_write:=0;
77    end_if;
78
79end_if;
80
81

```

CAN read program segment is processed and the CAN ID+1 is completed, the CAN write function block is entered. The enable trigger condition of this function block is the rising edge trigger. For the meaning of the rising edge trigger, please refer to page 39 of this book, and this section will not be repeated. To reiterate, the CAN write function block sends out the data after identifying the rising edge of the enable variable . When the frame data is sent, the CAN write success flag will be set to 1 (same as the CAN read success flag).

Only when this cycle is 1, the next cycle will change back to 0), when the flag bit is 1, the CAN write enable is turned off so that the rising edge is triggered next time, and the CAN read enable is turned on and read.

4. Serial RS232, 485 Experimental ST

```

1 (*本示例程序实现了串口数据的先读后写，且写的内容为先前读到的数据*)
2
3 mPORT:=2; (*串行端口号，1为RS232,2为RS485*)
4
5 if xInitOk=false then (*如果未初始化串口*)
6   inst0_USART_INIT(BAUD :=115200, DATABITS :=8, PARITY :=0, STOPBITS :=1, PROTOCOL :=0, ENABLE :=1, PORT :=mPORT | xE := ERROR); (*启用串口初始化功能块，BAUD为波特率，DATABITS为数据位数，PARITY为奇偶校验，0表示无校验*)
7   if xE=0 then (*如果串口初始化功能块执行无错误*)
8     xInitOk :=TRUE; (*将串口初始化状态置1，不再执行串口初始化*)
9   end_if;
10
11 end_if;
12
13
14 end_if;
15
16

```

This routine realizes that the data received by the serial port is sent back intact. This program is serial port initialization. The serial port initialization function block parameters used have been explained in Chapter 3. The meaning of each parameter can also be seen in the comments. The meaning of the segment program is that if the initialization is not completed, the initialization function block will be called, and if the initialization has no errors, the initialization will be completed.

```

10 pDataObject:=&abDataBuffer; (*指针指向数组*)
11
12 if xInitOk then (*在初始化成功前提下*)
13
14   if xReadStart then (*如果启动串口读取模式*)
15
16     inst0_USART_READ_BIN(ENABLE :=0, PORT :=mPORT | xERROR:= ERROR); (*以使能ENABLE为0调用串口读取功能块，与接下来以ENABLE为1调用功能块相配合，生成使能ENABLE的上升沿指令*)
17     xWaitForReceipt:=true; (*置位串口读取标志*)
18     xRdBinConfirm:=false; (*复位串口读取功能块执行完成标志*)
19     xReadStart:=false; (*复位串口模式的启动指令*)
20   end_if;
21
22   if xwaitForReceipt then (*如果串口读取标志为1*)
23
24     inst0_USART_READ_BIN(ENABLE :=1, PTR_RXDATA :=pDataObject, MAXLENGTH :=0, ETXCHR :=10, CHKETX :=1, PORT :=mPORT | xRdBinConfirm:= CONFIRM, iRxDataSize:= RXLENGTH, xERROR:= ERROR);
25     (*以使能ENABLE为1调用功能块，将读取到的数据存放到数组abDataBuffer中，读取的最大长度为20个字节，实际读取长度值到iRxDataSize中*)
26
27     if xRdBinConfirm then
28       val4:=iRxDataSize; (*将串口读到的实际数据长度赋值到该变量*)
29       xWaitForReceipt:=false; (*复位串口读取标志*)
30     end_if;
31
32   end_if;
33
34   if xRdBinConfirm then (*如果串口读取功能块执行完成*)
35
36     inst0_USART_WRITE_BIN(ENABLE :=0, PORT :=mPORT | xERROR:= ERROR); (*以使能ENABLE为0调用串口发送功能块，与接下来以ENABLE为1调用功能块相配合，生成使能ENABLE的上升沿指令*)
37
38     xRdBinConfirm:=false; (*复位串口读取功能块执行完成标志*)
39     xTransmitting:=true; (*启动串口发送模式*)
40
41   end_if;
42
43   if xTransmitting then (*如果串口发送模式已启动*)
44
45     inst0_USART_WRITE_BIN(ENABLE :=1, PTR_RXDATA :=pDataObject, TXLENGTH :=iRxDataSize, PORT :=mPORT | xWrBinConfirm := CONFIRM, xERROR:= ERROR);
46     (*以使能ENABLE为1调用串口发送功能块，将先前读到数组abDataBuffer中的数据发送出去，发送长度为串口先前读取数据的实际长度*)
47
48     if xWrBinConfirm then (*如果串口发送完成*)
49
50       IW:=IW+1;
51       xTransmitting :=false; (*关闭串口发送模式*)
52       xReadStart:=true; (*启动串口读取模式，继续先读后写的循环*)
53     end_if;
54
55   end_if;
56
57 end_if;
58
59 end_if;
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
639
640
641
642
643
644
645
646
647
648
649
649
650
651
652
653
654
655
656
657
658
659
659
660
661
662
663
664
665
666
667
668
669
669
670
671
672
673
674
675
676
677
678
679
679
680
681
682
683
684
685
686
687
687
688
689
689
690
691
692
693
694
695
696
697
698
699
699
700
701
702
703
704
705
706
707
708
709
709
710
711
712
713
714
715
716
717
718
719
719
720
721
722
723
724
725
726
727
728
729
729
730
731
732
733
734
735
736
737
738
739
739
740
741
742
743
744
745
746
747
748
749
749
750
751
752
753
754
755
756
757
758
759
759
760
761
762
763
764
765
766
767
768
769
769
770
771
772
773
774
775
776
777
778
779
779
780
781
782
783
784
785
786
787
787
788
789
789
790
791
792
793
794
795
796
797
797
798
799
799
800
801
802
803
804
805
806
807
808
809
809
810
811
812
813
814
815
816
817
818
819
819
820
821
822
823
824
825
826
827
828
829
829
830
831
832
833
834
835
836
837
838
839
839
840
841
842
843
844
845
846
847
848
849
849
850
851
852
853
854
855
856
857
858
859
859
860
861
862
863
864
865
866
867
868
869
869
870
871
872
873
874
875
876
877
878
879
879
880
881
882
883
884
885
886
887
887
888
889
889
890
891
892
893
894
895
896
897
897
898
899
899
900
901
902
903
904
905
906
907
908
909
909
910
911
912
913
914
915
916
917
918
919
919
920
921
922
923
924
925
926
927
928
929
929
930
931
932
933
934
935
936
937
938
939
939
940
941
942
943
944
945
946
947
948
949
949
950
951
952
953
954
955
956
957
958
959
959
960
961
962
963
964
965
966
967
968
969
969
970
971
972
973
974
975
976
977
978
979
979
980
981
982
983
984
985
986
987
987
988
989
989
990
991
992
993
994
995
996
997
998
999
999
1000
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1088
1089
1090
1091
1092
1093
1094
1095
1096
1096
1097
1098
1099
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1178
1179
1180
1181
1182
1183
1184
1185
1186
1186
1187
1188
1189
1189
1190
1191
1192
1193
1194
1195
1195
1196
1197
1198
1199
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1277
1278
1279
1280
1281
1282
1283
1284
1285
1285
1286
1287
1288
1289
1289
1290
1291
1292
1293
1294
1295
1295
1296
1297
1298
1299
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1377
1378
1379
1380
1381
1382
1383
1384
1385
1385
1386
1387
1388
1389
1389
1390
1391
1392
1393
1394
1395
1395
1396
1397
1398
1399
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1477
1478
1479
1480
1481
1482
1483
1484
1485
1485
1486
1487
1488
1489
1489
1490
1491
1492
1493
1494
1495
1495
1496
1497
1498
1499
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1577
1578
1579
1580
1581
1582
1583
1584
1585
1585
1586
1587
1588
1589
1589
1590
1591
1592
1593
1594
1595
1595
1596
1597
1598
1599
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1677
1678
1679
1680
1681
1682
1683
1684
1685
1685
1686
1687
1688
1689
1689
1690
1691
1692
1693
1694
1695
1695
1696
1697
1698
1699
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1778
1779
1780
1781
1782
1783
1784
1785
1785
1786
1787
1788
1789
1789
1790
1791
1792
1793
1794
1795
1795
1796
1797
1798
1799
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1877
1878
1879
1880
1881
1882
1883
1884
1885
1885
1886
1887
1888
1889
1889
1890
1891
1892
1893
1894
1894
1895
1896
1897
1898
1899
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1977
1978
1979
1980
1981
1982
1983
1984
1985
1985
1986
1987
1988
1989
1989
1990
1991
1992
1993
1994
1994
1995
1996
1997
1998
1999
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2018
2019
2020
2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2068
2069
2070
2
```

Enter the serial port read mode, when the enable is 1, wait for the data to be read. When the read data is completed, the read completion flag will be set to 1. At this time, the serial port write function block is called (enable is 0), and the call will be enabled after the call is completed . Set to 1 and call the trigger rising edge again to write out the data in the array.

5. TCP SERVER Communication experiment

This routine implements PLC as a TCP SERVER, communicates with the TCP CLIENT device, and sends back the received data intact.

```

1 (*本示例程序实现了PLC作为TCP_SERVER与TCP_CLIENT通讯，将读取到的数据原样发送出去*)
2
3
4
5 if lanInit=false then      (*如果网口未初始化*)
6
7 mIP := LAN_ASCII_TO_INET('192.168.1.30');          (*将PLC的IP地址转化成ASCII码*)
8 mNetMask := LAN_ASCII_TO_INET('255.255.255.0');    (*将子网掩码转化成ASCII码*)
9 mGateWay := LAN_ASCII_TO_INET('192.168.1.1');       (*将网关转化成ASCII码*)
10 inst0_LAN_INIT(ENABLE :=true,
11                 HOSTNAME := 'PLCCore',
12                 IP := mIP,                                (*主机名*)
13                 NETMASK :=mNetMask,                         (*PLC的IP地址*)
14                 GATEWAY :=mGateWay,                          (*PLC的子网掩码*)
15                 NETNUMBER:=1,                            (*PLC的网关*)
16                 | mConfirm:= CONFIRM,                      (*网络端口号*)
17                 mError:= ERROR,                           (*初始化功能块执行完成标志*)
18                 mErrorinfo:= ERRORINFO);                  (*功能块执行完成报的错误信息*)
19
20 else                      (*如果网口已初始化*)
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99

```

This section of the program is the network port initialization function block, the meaning of each parameter can be seen in the program comments, among which **mIP** stands for PLC IP, if not on the PLC IP _ If it has been modified, fill in PLC here Factory default IP : 192.168.1.30 That is, if it has been modified, according to the IP modified by the user Fill in

```

1 laninit:=true;           (*待网口初始化状态，不再进行网口初始化*)
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99

```

(Note: This is not an IP How much to fill, PLC device IP will be modified to how much, if you need to modify the IP, please contact the technical engineer of Guangcheng Technology). The subnet mask and gateway can also be filled in according to the user's networking requirements.

After the initialization is successful, create a TCP SERVER , you can set the port number,

```

1 pDataObject:=&abDataBuffer;      (*指针指向网口读写数据的地址*)
2
3 if mTcpCreateOK=true then     (*如果TCP_SERVER建立成功*)
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99

```

after the creation, the SOCKET ID will be greater than 0, then jump out of the creation and enter the main program.

This section of the program is the main program of the routine. First, establish a connection with the **TCP CLIENT**. When there is a **CLIENT** connection, **mClientSocket** will be greater than **0**. At this time, **TCP** read is called to read the data sent by the **CLIENT** and save it in the pointer pointed to by the **In** in the array, when the length of the received data is greater than **0**, the **TCP** write function block is started, and the data in the array pointed to by the pointer is sent out. (For details of the video explanation, see https://www.bilibili.com/video/BV1Sq4y1E7Cn?spm_id_from=333.999.0.0 This link explains the case of **TCP SERVER/TCP CLIENT** and **UDP** communication, so this article will not go into details).