



DS5N1 series servo driver
User manual

Wuxi Xinje Electric Co., Ltd.

Data No. SC5 09 20210818EN 1.0

Basic explanation

- Thank you for purchasing Xinje DS5N1 series servo driver products.
- This manual mainly introduces the product information of DS5N1 series servo driver and MS series servo motor.
- Before using the product, please read this manual carefully and connect the wires on the premise of fully understanding the contents of the manual.
- Please deliver this manual to the end user.

This manual is suitable for the following users

- Designer of servo system
- Installation and wiring workers
- Commissioning and servo debugging workers
- Maintenance and inspection workers

Get the manual

- Please consult the supplier, agent and office who purchased the product.

Declaration of liability

- Although the contents of the manual have been carefully checked, errors are inevitable, and we cannot guarantee complete consistency.
- We will often check the contents of the manual and make corrections in the subsequent versions. We welcome your valuable comments.
- If there is any change to the contents introduced in the manual, please understand without further notice.

Contact information

- Tel: 400-885-0136
- Fax: 0510-85111290
- Address: Floor 4, building 7, creative industry park, No. 100, DiCui Road, Wuxi City
- Postcode: 214072

WUXI XINJE ELECTRIC CO., LTD. Copyright

Without explicit written permission, this material and its contents shall not be copied, transmitted or used, and the violator shall be liable for the losses caused. All rights provided in the patent license and registration including utility module or design are reserved.

Jan. 2020

Safety Precautions

Be sure to review this section carefully before use this product. In precondition of security, wire the product correctly.

Before using this product, please read this part carefully and operate after fully understanding the use, safety and precautions of the product. Please connect the product correctly on the premise of paying great attention to safety.

The problems that may arise during the use of the product are basically listed in the safety precautions, and all are indicated by the two levels of attention and danger. For other unmentioned matters, please follow the basic electrical operation rules.



Caution

When used incorrectly, there may be danger, moderate injury or minor injury, and property loss.



Danger

When used incorrectly, it may cause danger, personal casualties or serious injuries, as well as serious property losses.



Attention to Product Confirmation

1. Do not install damaged drives, drives that lack spare parts, or drives whose models do not meet the requirements.



Installation Notes

1. Before installing wiring, be sure to disconnect the power supply to prevent electric shock.
2. It is forbidden to expose the product to water, corrosive gases, flammable gases and other substances, causing electric shock and fire hazards.
3. Do not touch the conductive part of the product directly, which may cause misoperation and malfunction.



Cautions for wiring

1. Please connect AC power to LN or L1/L2/L3 or R/S/T on the dedicated power terminal of the driver. Do not connect the output terminals U, V, W of the driver to the three-phase power supply.
2. Please connect the ground wire correctly. Poor grounding may cause electric shock. Please use 2mm² wire to ground the ground terminal of the driver.
3. Please lock the fixed screw of the terminal, otherwise it may cause fire.
4. Be sure to disconnect all external power supply before wiring the driver.
5. Wiring, please ensure that the encode line, power line is loose, do not tighten, lest cable damage.



Operation Cautions

1. Do not touch the rotating part of the motor after the driver is running. There is a danger of injury.
2. Please pay attention to the test run of the motor once, do not connect the motor with the machine, there is the possibility of injury.
3. After connecting the machine, please set the appropriate parameters before running, otherwise it may cause the machine out of control or failure.
4. In operation, do not touch the radiator, there is a risk of scald.
5. Under power-on condition, do not change the wiring, there is a risk of injury.
6. Do not switch power frequently. If you need to switch power many times, please control it once in 2 minutes.



Maintenance and inspection

1. Do not touch the inside of servo driver and servo motor, otherwise it may cause electric shock.
2. When the power is started, it is forbidden to remove the driver panel, otherwise it may cause electric shock.
3. Within 10 minutes of power off, the terminal should not be contacted. Otherwise, the residual voltage may cause electric shock.



Wiring attention

1. Do not cross the power line and the control signal line from the same pipeline, nor tie them together. The power line and the control signal line are separated by more than 30 centimeters.
2. For signal line and encoder (PG) feedback line, please use multi-stranded wire and multi-core stranded integral shielding line. For wiring length, the longest signal input line is 3 meters and the longest PG feedback line is 20 meters.

Catalog

| | |
|--|-----------|
| 1 SELECTION OF SERVO SYSTEM..... | 8 |
| 1.1 SELECTION OF SERVO DRIVER | 8 |
| 1.1.1 Part description..... | 8 |
| 1.1.2 Naming rule..... | 8 |
| 1.1.3 Performance specification..... | 8 |
| 1.2 SELECTION OF SERVO MOTOR | 9 |
| 1.2.1 Part description..... | 9 |
| 1.2.2 Naming rule..... | 9 |
| 1.2.3 Axial force and radial force..... | 10 |
| 1.3 CABLE SELECTION | 11 |
| 1.3.1 Naming rule..... | 11 |
| 1.3.2 Cable terminal definition..... | 12 |
| 1.4 SELECTION OF REGENERATIVE RESISTOR | 14 |
| 2 INSTALLATION OF SERVO SYSTEM | 15 |
| 2.1 SERVO DRIVER INSTALLATION..... | 15 |
| 2.1.1 Installation site..... | 15 |
| 2.1.2 Environment condition | 15 |
| 2.1.3 Installation standard..... | 15 |
| 2.2 SERVO MOTOR INSTALLATION | 16 |
| 2.2.1 Installation environment..... | 16 |
| 2.2.2 Environment condition | 16 |
| 2.2.3 Installation cautions | 17 |
| 2.3 SERVO CABLE INSTALLATION | 18 |
| 2.3.1 Cable selection | 18 |
| 2.3.2 Xinje cable specification..... | 19 |
| 2.4 SERVO DRIVER DIMENSION | 21 |
| 2.5 SERVO MOTOR DIMENSION..... | 22 |
| 3 SERVO SYSTEM WIRING..... | 25 |
| 3.1 MAIN CIRCUIT WIRING..... | 25 |
| 3.1.1 Servo driver terminal arrangement..... | 25 |
| 3.1.2 Main circuit terminal..... | 25 |
| 3.2 CN0, CN1, CN2 TERMINALS | 26 |
| 3.2.1 CN0 terminals..... | 26 |
| 3.2.2 CN1 terminals..... | 26 |
| 3.2.3 CN2 terminals..... | 26 |
| 3.3 CANOPEN CONNECTION | 27 |
| 4 OPERATE PANEL | 28 |
| 4.1 PANEL DISPLAY..... | 28 |
| 4.2 OPERATION STATE DISPLAY | 29 |
| 4.3 PX-XX CONTROL PARAMETERS..... | 30 |
| 4.4 UX-XX MONITOR PARAMETERS | 31 |
| 4.5 FX-XX AUXILIARY FUNCTION | 33 |
| 4.6 PARAMETER SETTING EXAMPLE..... | 35 |
| 4.7 CHECK MOTOR CODE | 36 |
| 5 OBJECT DICTIONARY AREA ALLOCATION | 37 |
| 5.1 CANOPEN OBJECT DICTIONARY IN BUS COMMUNICATION AREA (DS301) | 37 |
| 5.2 LIST OF OBJECT DICTIONARIES IN THE MANUFACTURER'S USER DEFINED AREA..... | 40 |
| 5.3 LIST OF OBJECT DICTIONARY IN SUB PROTOCOL AREA OF MOTION CONTROL EQUIPMENT | 42 |
| 6 CIA402 MOTION CONTROL..... | 45 |
| 6.1 PDS (POWER DRIVE SYSTEMS) SPECIFICATION | 45 |
| 6.2 CONTROL STATUS..... | 47 |
| 6.2.1 Controlword(6040h)..... | 47 |
| 6.2.2 Statusword(6041h)..... | 48 |
| 6.3 CONTROL MODE..... | 49 |
| 6.3.1 Modes of operation (6060h) | 49 |

| | |
|--|-----------|
| 6.3.2 Modes of operation display (6061h)..... | 49 |
| 6.4 SELECTION OF THE CODE (DECELERATION STOP TIME SETTING) | 50 |
| 6.4.1 Quick stop option code(605Ah) | 50 |
| 6.4.2 Shutdown on code(605Bh)..... | 51 |
| 6.4.3 Disable operation option code(605Ch) | 53 |
| 6.4.4 Halt option code(605Dh)..... | 53 |
| 6.4.5 Fault reaction option code(605Eh) | 55 |
| 7 DS5N1 MOTION CONTROL MODE | 56 |
| 7.1 PP MODE..... | 56 |
| 7.1.1 Related parameters..... | 56 |
| 7.1.2 Control word (6040h) < pp control mode function > | 56 |
| 7.1.3 Status word (6041h) < pp control mode function > | 57 |
| 7.1.4 Action description of PP control mode..... | 58 |
| 7.1.5 Operation instance of pp mode..... | 59 |
| 7.2 PV MODE | 63 |
| 7.2.1 Related parameters..... | 63 |
| 7.2.2 Control word (6040h) < pv control mode function > | 63 |
| 7.2.3 Control word (6041h) < pv control mode function > | 64 |
| 7.2.4 pv control mode action description | 64 |
| 7.2.5 PV mode operation instance..... | 65 |
| 7.3 TQ MODE..... | 67 |
| 7.3.1 Related parameters..... | 67 |
| 7.3.2 Control word (6040h) < tq control mode function >..... | 67 |
| 7.3.3 Status word (6041h) < tq control mode function > | 68 |
| 7.3.4 TQ control action description..... | 68 |
| 7.3.5 TQ mode operation instance | 69 |
| 7.4 HM MODE..... | 70 |
| 7.4.1 Related parameters..... | 70 |
| 7.4.2 Control word (6040h) < hm control mode function > | 71 |
| 7.4.3 Status word (6041h) < hm control mode function > | 71 |
| 7.4.4 Homing mode (6098h)..... | 72 |
| 7.4.5 HM mode operation instance | 78 |
| 8 SERVO GAIN ADJUSTMENT | 80 |
| 8.1 OVERVIEW OF SERVO GAIN ADJUSTMENT | 80 |
| 8.1.1 Overview and process..... | 80 |
| 8.1.2 The difference of these adjustment modes | 81 |
| 8.2 ROTARY INERTIA PRESUMPTION | 81 |
| 8.2.1 Overview..... | 81 |
| 8.2.2 Notes..... | 81 |
| 8.2.3 Operation tool | 82 |
| 8.2.4 Operation steps..... | 82 |
| 8.3 FAST ADJUSTMENT..... | 86 |
| 8.3.1 Overview..... | 86 |
| 8.3.2 Fast adjustment steps | 86 |
| 8.3.3 Rigidity level corresponding gain parameters..... | 86 |
| 8.3.4 Notes..... | 88 |
| 8.4 AUTO-TUNING | 89 |
| 8.4.1 Overview..... | 89 |
| 8.4.2 Notes..... | 89 |
| 8.4.3 Operation tools..... | 89 |
| 8.4.4 Internal instruction auto-tuning steps | 89 |
| 8.4.5 External instruction auto-tuning steps | 93 |
| 8.4.6 Related parameters..... | 97 |
| 8.5 MANUAL ADJUSTMENT | 99 |
| 8.5.1 Overview..... | 99 |
| 8.5.2 Adjustment steps | 99 |
| 8.5.3 Gain parameters for adjustment..... | 100 |
| 8.6 ADAPTIVE..... | 101 |
| 8.6.1 Overview..... | 101 |
| 8.6.2 Notes..... | 101 |
| 8.6.3 Operation steps..... | 101 |

| | |
|---|------------|
| 8.6.4 Inertia mode and related parameters | 102 |
| 8.6.5 Recommended inertia ratio parameters | 102 |
| 8.6.6 Adaptive parameters effect | 103 |
| 8.6.7 Invalid parameters when adaptive effective | 103 |
| 8.7 VIBRATION SUPPRESSION | 104 |
| 8.7.1 Overview | 104 |
| 8.7.2 Operation tools | 104 |
| 8.7.3 Vibration suppression (panel) | 104 |
| 8.7.4 Vibration suppression (PC software) | 105 |
| 8.7.5 Vibration suppression (manual setting) | 106 |
| 8.7.6 Vibration suppression (quick FFT) | 106 |
| 8.7.7 Notch filter | 107 |
| 8.8 GAIN ADJUSTMENT | 109 |
| 8.8.1 Model loop control | 109 |
| 8.8.2 Torque disturbance observation | 110 |
| 8.8.3 Gain adjustment parameters | 111 |
| 8.8.4 Gain switch | 111 |
| 8.9 GAIN ADJUSTMENT | 115 |
| 8.9.1 Load shaking | 115 |
| 8.9.2 Vibration | 115 |
| 8.9.3 Noise | 115 |
| 9 ALARM | 116 |
| 9.1 CANOPEN COMMUNICATION ASSOCIATION ABNORMAL ALARM | 116 |
| 9.2 CANOPEN COMMUNICATION NON ASSOCIATED ABNORMAL ALARM | 116 |
| APPENDIX | 125 |
| APPENDIX 1. PARAMETER LIST | 125 |
| Appendix 1.1 Group P parameter list | 125 |
| Appendix 1.2 Group F parameters | 135 |
| Appendix 1.3 Group U monitor parameters | 135 |
| APPENDIX 2. TERM SET | 138 |

►► Confirmation on product arrival

After the product arrives, please confirm the integrity of the product in the following aspects.


| Items | Notes |
|--|---|
| Does the product on arrival match the specified model? | Please confirm according to the nameplate of servo motor and servo unit. |
| Does the servomotor shaft rotate smoothly? | The servo motor shaft is normal if it can be turned smoothly by hand. Servo motors with brakes, however, cannot be turned manually. |
| Is there any damage? | Check the overall appearance, and check for damage or scratches that may have occurred during shipping. |
| Are there any loose screws? | Check screws for looseness using a screwdriver. |
| Is the motor code the same with the code in drive? | Check the motor code marked on the nameplates of the servomotor and the parameter U3-70 on the servo drive. |

If any of the above is faulty or incorrect, contact Xinje or an authorized distributor.


1 Selection of servo system

1.1 selection of servo driver

1.1.1 Part description



1.1.2 Naming rule




1.1.3 Performance specification

| | | |
|--------------------|----------------------|---|
| Servo unit | | DS5N1 series servo driver |
| Applicable encoder | | Standard: 17-bit/23-bit communication encoder |
| Input power supply | | DS5N1-2□P□-PTA: single phase AC200-240V, 50/60Hz |
| Control mode | | Three-phase full-wave rectifier IPM PWM control sinusoidal current drive mode |
| Using condition | Using temperature | 0~+50 °C |
| | Storage temperature | -20°C~+60°C |
| | Environment humidity | Below 90% RH (no condensation) |
| | Vibration resistance | 4.9m/s ² |
| Structure | | Pedestal installation |

1.2 Selection of servo motor

1.2.1 Part description



1.2.2 Naming rule

■ MS5 series motor

MS5S - 80 ST E - C S 02430 B Z - 2 OP7 - S01

| Name | Inertia |
|------|----------------|
| MS5S | Low inertia |
| MS5G | Middle inertia |
| MS5H | High inertia |

| Name | Seat number |
|------|-------------|
| 60 | 60 seat |
| 80 | 80 seat |

| Name | Product name |
|------|------------------|
| ST | Sine drive motor |

| Name | Product name |
|-------|---------------|
| empty | No oil seal |
| E | With oil seal |

| Name | Encoder type |
|------|-----------------------|
| C | Magnetic encoder |
| T | Photoelectric encoder |

| Name | Encoder accuracy |
|------|----------------------|
| S | Single circle 17-bit |
| M | Multi-circle 17-bit |
| U | Single circle 23-bit |
| L | Multi-circle 23-bit |

| Name | Rated torque (N·m) | Rated speed (rpm) |
|-------|--------------------|-------------------|
| 00630 | 0.637 | 3000 |
| 01330 | 1.3 | 3000 |
| 02430 | 2.39 | 3000 |

| Name | Design number |
|------|--------------------------|
| S01 | standard |
| S02 | Small Aviation Plug Type |

| Name | Rated power (KW) |
|------|------------------|
| OP2 | 0.2 |
| OP4 | 0.4 |
| OP7 | 0.75 |

| Name | Voltage level |
|------|---------------|
| 2 | 220V |
| 4 | 380V |

| Name | Power-off brake |
|-------|-----------------|
| Empty | without |
| Z | with |

| Name | Shaft |
|------|----------|
| A | No key |
| B | With key |

Note: At present, only the combination of CS, CM, TL and T is selected for the type of encoder.

■ MS6 series motor

MS6S-60 C S 30 B Z 1 - 2 0P4

| Display | Inertia |
|---------|----------------|
| MS6S | Low inertia |
| MS6G | Medium inertia |
| MS6H | High inertia |

| Display | Base no. |
|---------|-----------|
| 40 | 40 flange |
| 60 | 60 flange |
| 80 | 80 flange |

| Symbol | Product name |
|--------|-----------------------|
| C | Magnetic Encoder |
| T | Photoelectric encoder |

| Symbol | Encoder |
|--------|--------------------|
| S | Single turn 17-bit |
| M | Multi-turn 17-bit |
| U | Single turn 23-bit |
| L | Multi-turn 23-bit |

| Display | Rated speed (rpm) |
|---------|-------------------|
| 15 | 1500 |
| 20 | 2000 |
| 25 | 2500 |
| 30 | 3000 |

| Symbol | Shaft |
|--------|---|
| A | Key, no oil seal, with threaded hole |
| B | With key, oil seal and threaded hole |
| C | No key, no oil seal, with threaded hole |
| D | No key, with oil seal and threaded hole |

| Display | Power-loss brake |
|---------|------------------|
| Z | With brake |
| Empty | No brake |


| Display | Connector |
|---------|--------------------|
| 1 | Standard 1 |
| 2 | Standard 2 |
| D | Customized machine |

| Display | Power supply |
|---------|--------------|
| 2 | 220V |
| 4 | 380V |

| Display | Rated output |
|---------|--------------|
| 0P1 | 100W |
| 0P2 | 200W |
| 0P4 | 400W |
| 0P7 | 750W |

Note: At present, only the combination of CS, CM, TL and T is selected for the type of encoder.

1.2.3 Axial force and radial force




| Base no. | 40ST | 60ST | 80ST | 100ST | 110ST | 130ST | 180ST | 220ST/265ST |
|--------------|------|------|------|-------|-------|-------|-------|-------------|
| Axial force | 54N | 74N | 147N | ≤200N | 250N | 300N | 400N | ≤500N |
| Radial force | 78N | 245N | 392N | 500N | 500N | 600N | 800N | 1000N |


1.3 Cable selection

1.3.1 Naming rule

Encoder cable




Power cable



Brake cable explanation

- ◆ Applicable to flange motors of 80 and below with motor suffix S01, brake cable model shall be selected: CB-P03-length (ordinary material) / CBT-P03-length (high flexible material).
- ◆ Applicable to 750W and below motors with motor suffix S02: CMBT-W07-M-length.
- ◆ For the MS5G series 130 flange medium inertia brake motor, the cable shall be selected the power cable and brake cable in one.
- ◆ The standard wiring length of Xinje is 2m, 3m, 5m, 8m, 10m, 12m, 16m and 20m.
- ◆ Non high flexible cables are 25m and 30m.

■ CANopen communication cable



1.3.2 Cable terminal definition

■ Encoder cable

(1) Pin definition of encoder on servo driver side

| Connector appearance | Pin definition | | |
|----------------------|----------------|------------|-------------|
| | No. | Definition | Note |
| | 1 | 5V | Encoder 5V |
| | 2 | GND | Encoder GND |
| | 3 | / | |
| | 4 | / | |
| | 5 | 485-A | RS485 B |
| | 6 | 485-B | RS485 A |

(2) Cable connection of encoder on motor side

| Connector pins | Pin definition | | Suitable model |
|----------------|----------------|----------------|---|
| | No. | Definition | |
| | 1 | Battery + | MS5-40, 60, 80 flange -S01 motor MS6-40, 60, 80 flange B1 motor |
| | 2 | Battery - | |
| | 3 | Shielded cable | |
| | 4 | 485-A | |
| | 5 | 485-B | |
| | 6 | / | |
| | 7 | 5V | |
| | 8 | GND | |
| | 9 | / | |
| | 1 | Shielded cable | MS5-40, 60, 80 flange -S02 motor MS6-40, 60, 80 flange B2 motor |
| | 2 | Battery + | |
| | 3 | Battery - | |
| | 4 | 485-A | |
| | 5 | 485-B | |
| | 6 | 5V | |
| | 7 | GND | |
| | 1 | / | Flange 130 850W medium inertia motor |
| | 2 | 5V | |
| | 3 | GND | |
| | 4 | 485-A | |
| | 5 | 485-B | |
| | 6 | Battery + | |
| | 7 | Battery - | |
| | 8 | / | |
| | 9 | / | |
| | 10 | Shielded cable | |

Battery box description:

(1) The encoder including the cable definition of battery +, battery- is for the absolute motor, and the non-

absolute motor cable has no such pin.





(2) Only the cable of absolute value motor has external battery box, which contains a 3.6V/2.7Ah large capacity battery, and has the function of replacing batteries when power cut. The using life is more than two years.

■ Power cable

(1) Pin definition of power cable on servo driver side

| Connector appearance | Pin definition | |
|---|----------------|------------|
| | Color | Definition |
|  | Brown | U |
| | Black | V |
| | Blue | W |
| | Yellow-green | PE |

(2) Power cable connection on motor side

| Connector pins | Pin definition | | Suitable model |
|---|----------------|------------|---|
| | No. | Definition | |
|  | 1 | U | Applicable to 40, 60, 80 flange S01 / B1 motors |
| | 2 | W | |
| | 3 | V | |
| | 4 | PE | |
|  | No. | Definition | Applicable to 40, 60 and 80 flange S01 / B1 brake motors |
| | 1 | BK | |
| | 2 | BK | |
|  | No. | Definition | Applicable to 40, 60 and 80 flange S02 motors |
| | 1 | PE | |
| | 2 | U | |
| | 3 | V | |
| | 4 | W | |
| | 5 | BK | |
|  | No. | Definition | Applicable to 40, 60 and 80 flange B2 motors |
| | 1 | U | |
| | 2 | W | |
| | 3 | V | |
|  | No. | Definition | Applicable to 40, 60 and 80 flange B2 brake motors |
| | 1 | U | |
| | 2 | W | |
| | 3 | V | |
| | 4 | PE | |
| | 5 | BK+ | |
|  | No. | Definition | Applicable to flange 130 850W medium inertia brake motors |
| | 1 | PE | |
| | 2 | U | |
| | 3 | V | |
| | 4 | W | |
| | 5 | BK+ | |
| | 6 | BK- | |
| 7 | / | | |

Brake pins:

The cable including pin BK+, BK- is used for the brake motor. The cable of the non-brake motor has no BK pins.

1.4 Selection of regenerative resistor

When the servo motor is driven by the generator mode, the power returns to the servo amplifier side, which is called regenerative power. The regenerated power is absorbed by charging the smooth capacitor of the servo amplifier. After exceeding the rechargeable energy, the regenerative resistance is used to consume the regenerative power.

The servo motor driven by regenerative (generator) mode is as follows:

- The deceleration stop period during acceleration and deceleration operation
- Running vertically and axially
- When the external load drives the motor to rotate

| Servo driver model | Regenerative resistance connection terminals |
|--------------------|--|
| DS5N1-20P□-PTA | (1) Use external regenerative resistor below 750W: connect the regenerative resistor to terminals P + and C. (2) 750W use external regenerative resistor: connect the regenerative resistor to terminals P + and C, and remove the short wiring of P + and D. |

The following table is the recommended specifications of external regenerative resistance for each type of motor.

| Servo driver model | Built-in brake unit | Rmin (Not less than this value) | External regenerative resistance (Recommended resistance value) | External regenerative resistance (Recommended power values) |
|--------------------|---------------------|------------------------------------|--|--|
| DS5N1-20P1-PTA | Built-in | ≥50Ω | 50Ω—100Ω | >200W |
| DS5N1-20P2-PTA | | | | |
| DS5N1-20P4-PTA | | ≥40Ω | 40Ω—100Ω | >500W |
| DS5N1-20P7-PTA | | ≥40Ω | 40Ω—100Ω | >500W |

Note:

(1) When selecting external resistance, "resistance" try to choose close to the "minimum resistance" in "recommended resistance". The smaller the resistance, the faster the discharge. The selection of "power" shall be based on the actual use on site, and the specific shall depend on the heating value. Generally, the external regeneration resistor with higher power shall be selected as far as possible.

(2) The surface temperature will be very high when the regenerative resistance is discharged frequently. Please use high-temperature and flame-retardant wires when wiring, and pay attention that the surface of the regenerative resistance does not contact with the wires.

2 Installation of servo system

2.1 Servo driver installation

2.1.1 Installation site


- Please install it in the installation cabinet without sunshine or rain.
- Do not use this product near corrosive and flammable gas environments such as hydrogen sulfide, chlorine, ammonia, sulfur, chlorinated gas, acid, alkali, salt, etc.
- Do not install in high temperature, humidity, dust, metal dust environment.
- No vibration places.

2.1.2 Environment condition

| Item | Description |
|-------------------------|--|
| Use ambient temperature | -10~40°C (no freezing) |
| Use ambient humidity | -20~90%RH (no condensation) |
| Storage temperature | -20~60°C |
| Storage humidity | -20~90%RH (no condensation) |
| Vibration resistance | ≤4.9m/s ² |
| Altitude | ≤1000m, when higher than 1000m, please reduce the amount for use (1% for every 100m) |

2.1.3 Installation standard

Be sure to comply with the installation standard in the control cabinet shown in the figure below. This standard is applicable to the situation where multiple servo drivers are installed side by side in the control cabinet (hereinafter referred to as "when installed side by side").



■ Servo Drive Orientation

Install the servo drive perpendicular to the wall so the front panel containing connectors faces outward.

■ Cooling

As shown in the figure above, allow sufficient space around each servo drive for cooling by cooling fans or natural convection.

■ Side-by-side Installation

When install servo drives side by side as shown in the figure above, make at least 10mm between and at least 50mm above and below each servo drive. Install cooling fans above the servo drives to avoid excessive temperature rise and to maintain even temperature inside the control panel.

■ Environmental Conditions in the Control Panel

- Servo driver working ambient Temperature: -10~40 °C


- Humidity: 90%RH or less
- Vibration: 4.9m/s²
- Condensation and Freezing: None
- Ambient Temperature for Long-term Reliability: 50°C maximum

2.2 Servo motor installation

MS series servomotors can be installed either horizontally or vertically. The service life of the servomotor can be shortened or unexpected problems might occur if it is installed incorrectly or in an inappropriate location. Follow these installation instructions carefully.


CAUTION

1. The end of the motor shaft is coated with antirust. Before installing, carefully remove all of the paint using a cloth moistened with paint thinner.
2. Avoid getting thinner on other parts of the servo motor.




2.2.1 Installation environment

- Do not use this product near corrosive and flammable gas environments such as hydrogen sulfide, chlorine, ammonia, sulfur, chlorinated gas, acid, alkali, salt, etc.
- In places with grinding fluid, oil mist, iron powder, cutting, etc., please choose motor with oil seal.
- A place away from heat sources such as stoves;
- Do not use motor in enclosed environment. Closed environment will lead to high temperature and shorten service life of motor.

2.2.2 Environment condition


When used in places with water droplets or oil droplets, the protection effect can be achieved through the treatment of motors. However, in order to seal the through part of the shaft, please specify the motor with oil seal. Connectors should be installed downward.



MS series servo motors are for indoor use. Please use them under the following installation conditions:

| Item | Description |
|-------------------------|------------------------------|
| Use ambient temperature | -10°C~40°C (no freeze) |
| Use ambient humidity | 20%~90%RH (no condensation) |
| Storage temperature | -20°C~60°C |
| Storage humidity | -20%~90%RH (no condensation) |
| Protection level | IP65(MS5)/IP66(MS6) |

2.2.3 Installation cautions

| Item | Description |
|--------------------|---|
| Antirust treatment | <ul style="list-style-type: none"> ◆ Before installation, please wipe the "rust-proof agent" of the extension end of the servo motor shaft, and then do the relevant rust-proof treatment. |
| Encoder cautions | <ul style="list-style-type: none"> ◆ It is forbidden to impact the extension end of the shaft during installation, otherwise the internal encoder will be broken.  |
| | <ul style="list-style-type: none"> ◆ When the pulley is installed on the servo motor shaft with keyway, the screw hole is used at the end of the shaft. In order to install the pulley, the double-headed nails are inserted into the screw holes of the shaft, the washer is used on the surface of the coupling end, and the pulley is gradually locked with the nut. ◆ For the servo motor shaft with keyway, use the screw hole at the end of the shaft to install. For shaft without keyway, friction coupling or similar methods are used. ◆ When the pulley is dismantled, the pulley mover is used to prevent the bearing from being strongly impacted by the load. ◆ To ensure safety, protective covers or similar devices, such as pulleys installed on shaft, are installed in the rotating area. |

2.3 Servo cable installation

DS5 series servo motor adopts communication encoder, which may cause uncertain influence due to improper use and environmental factors. When installing power cable and encoder cable, please pay attention to the following instructions.

2.3.1 Cable selection

Our regular cable materials include ordinary cable and high flexible cable. The adapter cable connector for motors with 80 flange or less is divided into aviation plug and amp plug; the adapter cable connector for motors with 80 flange or more is aviation plug.

The cable selected by the customer needs to define the operating conditions on site.

If the cable is used in general occasions, please select the cable from other manufacturers (2.3.2 specifications of Xinje cable) in strict accordance with the specifications given by Xinje. If the cable is used in unconventional occasions, please select the cable according to the actual working conditions to be superior to the existing specifications of Xinje.


1. In normal situations, the following points should be noted:

- ◆ For pulse command signal cable, please ensure wiring less than 3m.
- ◆ The encoder cable shall be within 20 meters. It is recommended to select special cable if it is more than 20 meters. The wire diameter of encoder cable depends on the length of encoder cable used on site. The longer the cable is, the greater the wire resistance is, and the more severe the voltage attenuation or signal distortion is, which is likely to cause pulse loss or no signal can be detected. Therefore, in general, the customized special cable should be selected if it is more than 20 meters.
- ◆ The power cable diameter depends on the current condition of the motor. Generally, the wire diameter is 1/10 of the maximum current of the motor. For example, the maximum current of the motor is 60A, and the wire diameter of 6mm² is selected.
- ◆ In case of interference, it is necessary to separate strong and weak current. It is recommended to separate power cable from encoder cable and signal cable.
- ◆ Ensure the correct grounding of servo driver and servo motor. The grounding resistance is not more than 4Ω, and the grounding depth is more than 2m. It is recommended to use 4*40 angle galvanized steel or 40mm diameter galvanized steel pipe;
- ◆ If the customer makes the wire by himself, the cable specification please refer to chapter 2.3.2 Xinje cable specification, the welding reliability shall be ensured when making the wire to avoid false welding, bridge connection, wrong welding, missing welding, etc., and the continuity of both ends of the cable can be tested after the welding is completed.

2. In unconventional occasions, the following items shall be noted:

(1) Occasions of dragging and bending cables

- ◆ Do not bend the cable or bear the tension. As the core diameter of signal cable is only 0.2mm or 0.3mm, it is easy to break, please pay attention to it when using.
- ◆ When the cable needs to be moved, please use flexible cable. Ordinary cable is easy to be damaged after long-term bending. Small power motor (motor below 80 flange) with its own cable can not be used for cable movement.
- ◆ When using cable protection chain, please ensure that:
 - ① The bending radius of the cable is more than 10 times of the outer diameter of the cable;
 - ② The wiring in the cable protection chain shall not be fixed or bundled, only the two immovable wires end in the cable protection chain shall be bound and fixed;
 - ③ Do not twist the cable;
 - ④ The duty cycle in the cable protection chain shall be less than 60%;
 - ⑤ Do not mix the cables with too big difference in appearance. The thin wire will be broken by the thick wire. If it is necessary to mix the wiring, partition device is arranged in the middle of the cable.



(2) Greasy and humid occasions

- ◆ It is recommended to select cable with aviation plug as connector instead of AMP interface cable.
- ◆ It is necessary to make corresponding protection (glass glue/insulating cloth binding, etc.) for the used AMP interface cable on site.
- ◆ Use special cable.

(3) Interference, high current / high power occasions (such as welding equipment)

- ◆ The motor is properly grounded.
- ◆ High current equipment shall be grounded separately.
- ◆ Reasonable wiring. Such as separation of strong and weak current cables.
- ◆ Use metal shielding layer to shield, add magnetic ring to the encoder cable to resist interference.





(4) Low / high temperature

- ◆ Select cables (special cables) that meet the use conditions.

2.3.2 Xinje cable specification

1. Material composition of Xinje cable

Cross section of cable (encoder, power cable), corresponding introduction of wire skin material, wire diameter, wire core material shielding material, etc.



2. Cable diameter specification

| Power | Type | Encoder cable | Power cable |
|-------|------|----------------------|--|
| 100W | | 6*0.2mm ² | 4*0.75mm ² |
| 200W | | 6*0.2mm ² | 4*0.75mm ² |
| 400W | | 6*0.2mm ² | 4*0.75mm ² |
| 750W | | 6*0.2mm ² | 4*0.75mm ² |
| | | | 4*1.5mm ² (MS5G-130STE) |
| 1.5kW | | 6*0.2mm ² | 4*1.5mm ² |
| 3.0kW | | 6*0.2mm ² | 4*2.5mm ² |
| 5.5kW | | 6*0.2mm ² | 3*6.0mm ² +1*2.5mm ² |
| 7.5kW | | 6*0.2mm ² | 3*6.0mm ² +1*2.5mm ² |
| 11kW | | 6*0.2mm ² | 3*6.0mm ² +1*2.5mm ² |
| 15kW | | 6*0.2mm ² | 3*6.0mm ² +1*2.5mm ² |
| 22kW | | 6*0.2mm ² | 3*8mm ² +1*4mm ² |
| 32kW | | 6*0.2mm ² | 3*12mm ² +1*4mm ² |


3. Cable performance specification

| Performance | | Normal cable | High flexible cable |
|---------------------------------|--------------------------|--|--|
| Ordinary temperature resistance | | -20°C~80°C | -20°C~80°C |
| Encoder cable withstand voltage | | 1000V/min | 1000V/min |
| Power cable withstand voltage | | 3000V/min | 3000V/min |
| Mobile installation | Bending radius | Travel <10m, 7.5*D; Travel ≥10m, 10*D; | Travel <10m, 7.5*D; Travel ≥10m, 10*D; |
| | Bending resistance times | Travel <10m, ≥1 million times; Travel ≥10m, ≥2 million times; | Travel <10m, ≥3 million times; Travel ≥10m, ≥5 million times; |
| Fixed installation | Bending radius | 5*D | 5*D |


Note: D represents the finished product cable diameter.

2.4 Servo driver dimension

■ DS5N1-20P1/20P2/20P4-PTA




■ DS5N1-20P7-PTA



2.5 Servo motor dimension


- ◆ 40 series motor installation dimensions
- ◆ MS5 motor

Unit: mm



| Motor model | LA±1 | | Inertia level |
|----------------------------------|--------|-------------|---------------|
| | Normal | With brake | |
| MS5S-40STE-C□0030□□-20P1-S01/S02 | 89.5 | Low inertia | Low inertia |


- ◆ MS6 motor



| Motor model | LA±1 | | Inertia level |
|---------------------|--------|------------|---------------|
| | Normal | With brake | |
| MS6H-40C□30B□1-20P1 | 91 | 122.9 | High inertia |


- ◆ 60 series motor installation dimensions
- ◆ MS5 motor

Unit: mm



| Motor model | LA±1 | | Inertia level |
|-----------------------------------|--------|------------|---------------|
| | Normal | With brake | |
| MS5S-60STE-C□00630□□-20P2-S01/S02 | 79 | 114 | Low inertia |
| MS5S-60STE-C□01330□□-20P4-S01/S02 | 99 | 134 | |
| MS5H-60STE-C□00630□□-20P2-S01/S02 | 91 | 126 | High inertia |
| MS5H-60STE-C□01330□□-20P4-S01/S02 | 111 | 146 | |

◆ MS6 motor




| Motor model | LA±1 | | Inertia level |
|----------------------|--------|------------|---------------|
| | Normal | With brake | |
| MS6H-60C□301B□□-20P2 | 90 | 121 | High inertia |
| MS6S-60C□301B□□-20P4 | 107 | 139 | Low inertia |
| MS6H-60C□301B□□-20P4 | 119 | 151 | High inertia |

■ 80 series motor installation dimensions


Unit: mm

◆ MS5 motor



| Motor model | LA±1 | | Inertia level |
|-----------------------------------|--------|------------|---------------|
| | Normal | With brake | |
| MS5S-80STE-C□02430□□-20P7-S01/S02 | 107 | 144 | Low inertia |
| MS5S-80STE-C□03230□□-21P0-S01/S02 | 128 | 165 | |
| MS5H-80STE-C□02430□□-20P7-S01/S02 | 119 | 156 | High inertia |
| MS5H-80STE-C□03230□□-21P0-S01/S02 | 140 | 177 | |

◆ MS6 motor




| Motor model | LA±1 | | Inertia level |
|---------------------|--------|------------|---------------|
| | Normal | With brake | |
| MS6S-80C□30B□□-20P7 | 117 | 150 | Low inertia |
| MS6S-80C□20B□□-20P7 | 127 | 160 | |
| MS6H-80C□30B□□-20P7 | 124 | 157 | High inertia |
| MS6H-80C□20B□□-20P7 | 149 | 182 | |

■ 130 series motor installation dimensions


Unit: mm

◆ MS5 motor



| Motor model | LA±1 | | LB | Inertia level |
|--------------------------------|--------|------------|------|----------------|
| | Normal | With brake | | |
| MS5G-130STE-C□05415□□-20P8-S01 | 117.5 | 147 | 12.5 | Medium inertia |
| MS5G-130STE-TL05415□□-20P8-S01 | 134.5 | 164.5 | | |

◆ MS6 motor




| Motor model | LA±1 | | Inertia level |
|----------------------|--------|------------|---------------|
| | Normal | With brake | |
| MS6H-130C□15B□2-20P8 | 126 | 156 | High inertia |
| MS6H-130TL15B□2-20P8 | 142 | 172 | |

3 Servo system wiring


3.1 Main circuit wiring

3.1.1 Servo driver terminal arrangement




3.1.2 Main circuit terminal

■ DS5N1-20P1/20P2/20P4-PTA



| Terminal | Function | Note |
|-------------|------------------------------------|---|
| L/N | Power supply input of main circuit | Single phase AC 200~240V, 50/60Hz |
| • | Vacant terminal | - |
| P+, C | External regenerative resistor | Connect regenerative resistor between P+ and C, P0-25= power value, P0-26= resistor value |
| U, V, W, PE | Motor terminals | Connect the motor |

■ DS5N1-20P7-PTA



| Terminal | Function | Note |
|-------------|------------------------------------|--|
| L/N | Power supply input of main circuit | Single phase AC 200~240V, 50/60Hz |
| • | Vacant terminal | - |
| P+, D, C | Internal regenerative resistor | Short P+ and D, disconnect P+ and C |
| | External regenerative resistor | Connect regenerative resistor between P+ and C, disconnect P+ and D, P0-25= power value, P0-26= resistor value |
| U, V, W, PE | Motor terminals | Connect the motor |

■ Servo motor wiring terminals


| Signal | 40, 60, 80 series motor | 130 series motor |
|--------|-------------------------|------------------|
| PE | 4-yellow green | 1-yellow green |
| U | 1-brown | 2-brown |
| V | 3-black | 3-black |
| W | 2-blue | 4-blue |

3.2 CN0, CN1, CN2 terminals

3.2.1 CN0 terminals


The numbers of the following connectors are in the order when looking at the solder patch.

■ DS5N1-20P1/20P2/20P4/20P7-PTA



| Name | Note |
|------|------------------------|
| SI1 | Input terminal 1 |
| SI2 | Input terminal 2 |
| SI3 | Input terminal 3 |
| +24V | Input terminal +24V |
| S01 | Output terminal 1 |
| S02 | Output terminal 2 |
| S03 | Output terminal 3 |
| COM | Output terminal ground |

3.2.2 CN1 terminals




| No. | Name | No. | Name |
|-----|---------|-----|---------|
| 1 | CAN_H | 9 | CAN_H |
| 2 | CAN_L | 10 | CAN_L |
| 3 | CAN_GND | 11 | CAN_GND |
| 4 | - | 12 | - |
| 5 | - | 13 | - |
| 6 | - | 14 | - |
| 7 | - | 15 | - |
| 8 | - | 16 | - |

Note: the servo motion bus function requires optional bus module, which is inserted into the driver CN1 port to realize the extended bus function. Note that the module cannot be hot swapped in use. It is recommended to use PROFIBUS standard connecting wire in order to achieve the best communication reliability.

3.2.3 CN2 terminals

The terminals of the CN2 connector are arranged as follows (faced solder plates):



| No. | Definition |
|-----|------------|
| 1 | 5V |
| 2 | GND |
| 5 | A |
| 6 | B |

3.3 CANopen connection

It is recommended to use linear connection method for CANopen bus wiring. The communication between DS5N1 series servo driver and Xinje PLC needs to be connected through left expansion module XD-COBOX-ED. The two communication network ports of the servo driver follow the principle of "bottom in and top out", that is, the XD-COBOX-ED communication port must be connected with the network port below the LIN1 port of the first servo, and then the top network port of the first servo is connected with the bottom network port of the second servo, and so on (the maximum number of supported axes is 16 axes).

The communication transmission process will inevitably be affected by the surrounding electromagnetic environment. It is recommended that users use CAT5e network cable, which can also be purchased from our company.

Physical connection diagram of bus communication connection




CANopen communication follows the rules of bottom in and top out.

For the definition of network cable interface pin, see the terminal description of CN1 in chapter 3.2.

4 Operate panel


4.1 Panel display



| Button | Operation |
|---------|--|
| STA/ESC | Short press: state switch, state return |
| INC | Short Press: The display data increases Long press: The display data increases continuously |
| DEC | Short Press: The display data decreases Long press: The display data decreases continuously |
| ENTER | Short press: shift Long press: Set and view parameters. |

By switching the basic state of the panel operator, the operation state display, parameter setting, auxiliary function operation, alarm state and other operations can be carried out. After pressing the STA / ESC key, the States will be switched in the order shown in the figure below.

Status: BB indicates that the servo system is idle. Run indicates that the servo system is running and RST indicates that the servo needs to be powered on again.




- Parametric setting Px-xx: The first X represents the group number, and the last two X represents the parameter serial number under the group.
- Monitor status Ux-xx: The first X represents the group number, and the last two X represents the parameter number under the group.
- Auxiliary function Fx-xx: The first X denotes the group number, and the last two X denotes the parameter number under the group.
- Alarm state E-xxx: The first two X denote the alarm category, and the last x denotes the small category under the category.

4.2 Operation state display

When powered on, the panel displays, which is set according to P8-25 parameters

| Parameter | Signal name | Default | Suitable mode | Meaning | Modify | Effective |
|-----------|-------------------------------|---------|---------------|--|---------|------------|
| P8-25 | Operate panel display setting | 0 | All | 0: normal display, power on display 'bb' or 'run' 1: Power on the panel to display the value of U0-00, speed feedback, unit: rpm 2: Power on the panel to display the value of U0-07, torque feedback, unit% | At once | Repower on |

■ Speed, torque control mode



1. Digit display content


| Bit data | Display contents |
|--|--|
| P5-39 Same speed detection (/V-CMP) | When the actual speed of the motor is the same as the command speed, turn on the light. Detection Width of Same Speed Signal: P5-04 (Unit: rpm) |
| P5-42 Torque limit (/CLT) | When the speed is controlled, when the torque exceeds the set value, turn on the light. Internal Forward Torque Limitation: P3-28 Internal Reverse Torque Limitation of: P3-29 |
| P5-40 Rotate detection (/TGON) | P5-03 (Unit: rpm) When the motor speed is higher than the rotating speed, turn on the lamp. Rotation detection speed: P5-03 (unit: rpm) |
| P5-31 Zero clamp (/ZCLAMP) | When the zero clamp signal starts to operate, turn on the light. |
| P5-43 Speed limit (/VLT) | When the speed exceeds the set value in torque control mode, turn on the light. Forward speed limit in torque control: P3-16; reverse speed limit: P3-17. |

2. Short code display content

| Short code | Display contents |
|------------|---|
| | Standby status Servo OFF status. (The motor is in a non-electrified state) |
| | In operation Servo enabling state. (The motor is on-line) |
| | Need reset status Servo needs to be re-energized |

| | |
|--|---|
| | Forbidden forward drive state P-OT ON status. |
| | Forbidden reversal drive state N-OT ON status. |
| | Control mode 2 is vacant. |

■ Position control mode



1. Digit display contents

| Digit data | Display contents |
|---|---|
| P5-38 Positioning completion (/COIN) | In position control, when the given position is the same as the actual position, turn on the light. Location Completion Width: P5-00 (Unit: Instruction Pulse) |
| P5-36 Near (/NEAR) | In position control, when the given position is the same as the actual position, turn on the light. Near signal width: P5-06 |
| P5-40 Rotate detection (/TGON) | When the motor speed is higher than the rotating speed, turn on the lamp. Rotation detection speed: P5-03 (unit: rpm) |

2. Short code display contents


| Short code | Display contents |
|------------|---|
| | Standby status Servo OFF status. (The motor is in a non-electrified state) |
| | In operation Servo enabling state. (The motor is on-line) |
| | Need reset status Servo needs to be re-energized |
| | Forbidden forward drive state P-OT ON status. |
| | Forbidden reversal drive state N-OT ON status. |
| | Control mode 2 is vacant. |

4.3 PX-XX control parameters

See Appendix 1.1 for details.

4.4 UX-XX monitor parameters

■ U0-21 input signal status




■ U0-21 input signal 1 distribution

| Segment code | Description | Segment code | Description |
|--------------|--|--------------|--|
| 1 | /S-ON servo enable | 2 | /P-CON proportion action instruction |
| 3 | /P-OT prohibition of forward drive | 4 | /N-OT prohibition of reverse drive |
| 5 | /ALM-RST alarm reset | 6 | /P-CL forward side external torque limit |
| 7 | /N-CL reverse side external torque limit | 8 | /SPD-D internal speed selection |
| 9 | /SPD-A internal speed selection | 10 | /SPD-B internal speed selection |

Note: When reading through communication, the binary numbers read from right to left correspond to the position of / S-ON, / P-CON, 0 means that the position signal is not input, 1 means that the position signal has input. Example: 0x0001 means / S-ON has input, 0x0201 means / S-ON and / SPD-B has input.

■ U0-22 input signal status




■ U0-22 input signal status

| Code | Description | Code | Description |
|------|--|------|----------------------|
| 11 | /C-SEL control mode selection | 12 | /ZCLAMP zero clamp |
| 13 | /INHIBIT instruction pulse prohibition | 14 | /G-SEL gain switch |
| 15 | /CLR pulse clear | 16 | /CHGSTEP change step |
| 17 | /I-SEL inertia switching | 18 | — |
| 19 | — | 20 | — |

Note: When reading through communication, the binary numbers read from right to left correspond to the position of / C-SEL, / ZCLAMP, 0 means that the position signal is not input, 1 means that the position signal has input. Example: 0x0001 means / C-SEL has input, 0x0041 means / C-SEL and / G-SEL have input.

Note: "-" is for reserved display and does not represent any signal. The status bit is always 0.

■ U0-23 output signal status




■ U0-23 output signal distribution

| Code | Description | Code | Description |
|------|--|------|--------------------------------|
| 1 | Positioning completion hold (/COIN_HD) | 2 | Positioning completion (/COIN) |
| 3 | Same speed detection (/V-CMP) | 4 | Rotate detection (/TGON) |
| 5 | Ready (/S-RDY) | 6 | Torque limit (/CLT) |
| 7 | Speed limit detection (/VLT) | 8 | Break lock (/BK) |
| 9 | Warn (/WARN) | 10 | Output near (/NEAR) |

Note: When reading through communication, the binary numbers read from right to left correspond to the position of / COIN_HD, / COIN, 0 means that the position signal is not output, 1 means that the position signal has output. Example: 0x0001 means / COIN_HD has output, 0x0201 means / COIN_HD and / NEAR has output.

■ U0-24 output signal status



■ U0-24 output signal distribution

| Code | Description | Code | Description |
|------|----------------------|------|---------------------|
| 11 | Alarm (/ALM) | 12 | — |
| 13 | — | 14 | — |
| 15 | Speed reach (/V-RDY) | 16 | Customized output 1 |
| 17 | Customized output 2 | 18 | — |
| 19 | — | 20 | — |

Note: When reading the state through communication, the binary numbers correspond to /ALM “-“ position in turn from right to left. 0 means that the position signal has no input, and 1 means that the position signal has input. For example, 0x0001 means /ALM has signal output, 0x0041 means /ALM and /customized output 2 have signal output.

Note: “-” is for reserved display and does not represent any signal. The status bit is always 0.

4.5 FX-XX auxiliary function

■ F0-XX

| Function code | Description |
|---------------|----------------------------|
| F0-00 | Alarm clear |
| F0-01 | Resume to default settings |
| F0-02 | Clear the position offset |

1. Alarm clear (F0-00)

In case of failure, it will automatically jump out of the alarm state of E-XXX and display the alarm number. In case of no failure, the alarm state will not be visible.

In the alarm state, write 1 to F0-00 through panel operation to reset the fault.

When an alarm occurs, first eliminate the cause of the alarm, and then clear the alarm. In case of servo alarm due to servo power off, it is not necessary to clear the alarm.

2. Resume to default setting (F0-01)

First turn the servo off, and then restore the factory operation. The operation is as follows:

Set F0-01=1 when enabler is shut down, press ENTER to resume to default settings, no need to cut power.

3. Clear the position offset (F0-02)


Set F0-02=1 to clear the offset.

4. Panel inertia identification (F0-07)

Before inertia identification, please use F1-00 jog function to confirm the servo rotation direction. At the beginning of inertia identification, Inc or Dec determines the initial direction of servo operation!

If the servo jitters under the adaptive default parameters, please switch to the adaptive large inertia mode (P2-03.3 = 1) to ensure the stable operation of the servo before inertia identification!

When the servo is in bb state, enter the parameter F0-07 display:



Refer to chapter 8-2-4 for details.

5. Panel external instruction auto-tuning (F0-08)

Refer to chapter 8-4-5 for details.

6. Panel internal instruction auto-tuning (F0-09)


Refer to chapter 8-4-4 for details.

7. Panel vibration suppression (F0-10, F0-11)


| Vibration suppression mode | Display | Parameter |
|----------------------------|---------|--|
| Mode 1 | vib-1 | Only the parameters related to vibration suppression will be changed |
| Mode 2 | Vib-2 | The parameters related to vibration suppression and the gain of speed loop will be changed |

The operation steps are described below:


(1) In the self-tuning mode, enter the parameter F0-10 and the panel displays vib-1 or enter F0-11 and the panel displays vib-2



(2) Press ENTER, the panel displays Son and flashes. At this time, it needs to be enabled manually



(3) After the servo enable is turned on, the panel displays tune and flashes to enter the tuning state



(4) The upper device starts to send pulse command until done is displayed and flashes to complete vibration suppression




(5) Press STA/ESC to exit

The vibration suppression parameters will be automatically written into the second and first notch filters (when there is only one vibration point, the second notch will be opened first). Refer to chapter 8-7-7 notch filter for relevant parameters.

8. Panel vibration suppression (fast FFT) (F0-12)

This function can analyze the mechanical characteristics through F0-12 parameters on the servo operation panel to find out the mechanical resonance frequency, so as to realize vibration suppression.




■ F1-XX

| Code | Note |
|-------|----------------------------------|
| F1-00 | Jog run |
| F1-01 | Test run |
| F1-02 | Current Sampling Zero-correction |
| F1-05 | Panel enable |
| F1-06 | Reset turns of absolute encoder |

1. Jog run (F1-00)

Before entering jog mode, please confirm that the motor shaft is not connected to the machine and the driver is in bb idle status!



During jog operation, parameters such as gain will participate in the control, and whether the parameter setting is appropriate can be judged according to the operation condition.


| P3-18 | JOG speed | | | | | |
|-------|-----------|---------|--------|---------------|-----------|-----------|
| | Unit | Default | Range | Suitable mode | Modify | Effective |
| | 1rpm | 100 | 0~1000 | JOG | Servo OFF | At once |

2. Test run (F1-01)

Before entering the test run mode, please confirm that the motor shaft is not connected to the machine!


When the servo driver is connected to the non-original encoder or power cable, it should first enter the test run mode to verify that the encoder terminal or power terminal is connected correctly.

Test run mainly checks the power cable and the encoder feedback cable to determine whether the connection is normal. According to the following operation, the motor can normally achieve forward and reverse rotation. If the motor shaft shakes or driver alarms, please immediately disconnect the power supply, and re-check the wiring situation.



3. Current sampling zero-correction (F1-02)

When the servo driver is updated or the motor runs unsteadily after a long time, it is recommended that the user automatically adjust the current detection offset, and carry out the following operations when the driver is bb idle.



Press STATUS/ESC to exit. It needs to repower on the driver.

4. Panel enable (F1-05)

| Parameter | Signal name | Setting | Meaning | Change | Effective |
|---|-------------|-------------|---|-----------|-----------|
| P0-03 | Enable mode | 0 | Not enable | Servo OFF | At once |
| | | 1 (default) | I/O enable /S-ON | | |
| | | 2 | Software enable (F1-05 or communication) | | |
| | | 3 | Fieldbus enable (the model which supports motion bus) | | |
| Set P0-03=2 | | | | | |
| F1-05 = 0: cancel enable, enter bb status. | | | | | |
| F1-05 = 1: forced enable, servo is in RUN status. | | | | | |

Note:

- (1) After power on again, the forced enable set by F1-05 will fail.
- (2) If it needs to enable when power on and still enable after re-power on, P0-03 should be set to 1 and P5-20 to n.0010.

5. Reset turns of absolute encoder (F1-06)

First turn the servo off, and then clear the number of turns of the absolute encoder. The operation is as follows:
 Write 1 to F1-06 through panel operation to clear the number of turns of absolute encoder.
 Write 1 to 0x2106 hexadecimal address through Modbus RTU to clear the number of turns (servo bb status takes effect, and write 0x2106 to 0 after clearing)

4.6 Parameter setting example


Take P3-09 as an example:

| Step | Panel display | Used buttons | Operations |
|------|---------------|----------------------------------|---|
| 1 | bb | STA/ESC INC DEC ENTER ⊙ ⊙ ⊙ ⊙ | No operation |
| 2 | P0-00 | STA/ESC INC DEC ENTER ⊙ ⊙ ⊙ ⊙ | Press STA/ESC |
| 3 | P3-00 | STA/ESC INC DEC ENTER ⊙ ⊙ ⊙ ⊙ | Press INC for three times to show P3-00 |
| 4 | P3-00 | STA/ESC INC DEC ENTER ⊙ ⊙ ⊙ ⊙ | Press ENTER, the last 0 will flash |
| 5 | P3-09 | STA/ESC INC DEC ENTER ⊙ ⊙ ⊙ ⊙ | Press INC for 9 times |


| | | | |
|---|-----|----------------------------------|--|
| 6 | | STA/ESC INC DEC ENTER ⊙ ⊙ ⊙ ⊙ | Long press ENTER to show the value of P3-09 |
| 7 | | STA/ESC INC DEC ENTER ⊙ ⊙ ⊙ ⊙ | Press INC, DEC, ENTER to increase decrease or shift, after changing, long press ENTER to confirm |
| 8 | END | | |

4.7 Check motor code

A servo driver can be equipped with a variety of motors with similar power levels. Different types of motors are distinguished by the motor code on the motor nameplate. Before commissioning the servo system, please confirm whether the driver parameter U3-70 is consistent with the motor nameplate label. In case of inconsistency, please contact the agent or technical support.



Driver nameplate



5 Object dictionary area allocation

CANopen object dictionary partition description:

| Object dictionary index | Note |
|-------------------------|---|
| 0x1000~0x1FFF | DS301 CANopen communication area (CANopen bus area) |
| 0x2000~0x2FFF | Corresponding general function code P group area (manufacturer defined area) |
| 0x3000~0x3FFF | Corresponding monitoring function code U group area (manufacturer defined area) |
| 0x4000~0x4FFF | Corresponding auxiliary function code group F area (manufacturer defined area) |
| 0x6000~0x6FFF | CiA402 object dictionary area (motion control equipment sub protocol area) |

The object dictionary of CANopen bus is all in the device description file, namely EDS file, and the file format is eds. The tool for viewing and editing EDS files can be EDS editor.

5.1 CANopen object dictionary in bus communication area (DS301)

| Index | Sub index | Object type | Name | Data type | Read write | PDO mapping |
|-------|-----------|-------------|--|-----------|------------|-------------|
| 1000 | - | VAR | Device type | UINT32 | RO | NO |
| 1001 | - | VAR | Error register | UINT8 | RO | NO |
| 1003 | - | ARRAY | Pre-defined Error Field | - | - | - |
| | 01 | VAR | Standard Error Field | UINT32 | RO | NO |
| | 02 | VAR | Standard Error Field | UINT32 | RO | NO |
| | 03 | VAR | Standard Error Field | UINT32 | RO | NO |
| | 04 | VAR | Standard Error Field | UINT32 | RO | NO |
| 1005 | - | VAR | COB-ID SYNC | UINT32 | RW | NO |
| 1006 | - | VAR | Communication Cycle Period | UINT32 | RW | NO |
| 1007 | - | VAR | Sync Windows Length | UINT32 | RW | NO |
| 1008 | - | VAR | Manufacturer Device Name | STRING | - | - |
| 1009 | - | VAR | Manufacturer Hardware Version | STRING | - | - |
| 100A | - | VAR | Manufacturer Software Version | STRING | - | - |
| 100B | - | VAR | Device ID | UINT8 | RW | NO |
| 100C | - | VAR | Guard Time | UINT16 | RW | NO |
| 100D | - | VAR | Life Time Factor | UINT8 | RW | NO |
| 1010 | - | ARRAY | Store Parameter Field | - | - | - |
| | 01 | VAR | Save All Parameters | UINT32 | RW | NO |
| | 02 | VAR | Save Communication Parameters | UINT32 | RW | NO |
| | 03 | VAR | Save Application Parameters | UINT32 | RW | NO |
| 1011 | - | ARRAY | Restore Default Parameters | - | - | - |
| | 01 | VAR | Restore all Default Parameters | UINT32 | RW | NO |
| | 02 | VAR | Restore Communication Default Parameters | UINT32 | RW | NO |
| | 03 | VAR | Restore Application Default Parameters | UINT32 | RW | NO |
| 1014 | - | VAR | COB-ID EMCY | UINT32 | RW | NO |
| 1017 | - | VAR | Producer Heartbeat Time | UINT16 | RW | NO |

| Index | Sub index | Object type | Name | Data type | Read write | PDO mapping |
|-------|-----------|-------------|--------------------------|-----------|------------|-------------|
| 1018 | - | - | Identity Object | - | - | - |
| | 01 | VAR | Vendor ID | UINT32 | RO | NO |
| | 02 | VAR | Product Code | UINT32 | RO | NO |
| | 03 | VAR | Revision Number | UINT32 | RO | NO |
| | 04 | VAR | Serial Number | UINT32 | RO | NO |
| 1400 | - | RECORD | 1. receive PDO parameter | - | - | - |
| | 01 | VAR | COB-ID used by PDO | UINT32 | RW | NO |
| | 02 | VAR | transmission type | UINT8 | RW | NO |
| 1401 | - | RECORD | 2. receive PDO parameter | - | - | - |
| | 01 | VAR | COB-ID used by PDO | UINT32 | RW | NO |
| | 02 | VAR | transmission type | UINT8 | RW | NO |
| 1402 | - | RECORD | 3. receive PDO parameter | - | - | - |
| | 01 | VAR | COB-ID used by PDO | UINT32 | RW | NO |
| | 02 | VAR | transmission type | UINT8 | RW | NO |
| 1403 | - | RECORD | 4. receive PDO parameter | - | - | - |
| | 01 | VAR | COB-ID used by PDO | UINT32 | RW | NO |
| | 02 | VAR | transmission type | UINT8 | RW | NO |
| 1600 | - | RECORD | 1. receive PDO mapping | - | - | - |
| | 01 | VAR | 1. mapped object | UINT32 | RW | NO |
| | 02 | VAR | 2. mapped object | UINT32 | RW | NO |
| | 03 | VAR | 3. mapped object | UINT32 | RW | NO |
| | 04 | VAR | 4. mapped object | UINT32 | RW | NO |
| | 05 | VAR | 5. mapped object | UINT32 | RW | NO |
| | 06 | VAR | 6. mapped object | UINT32 | RW | NO |
| | 07 | VAR | 7. mapped object | UINT32 | RW | NO |
| | 08 | VAR | 8. mapped object | UINT32 | RW | NO |
| 1601 | - | RECORD | 2. receive PDO mapping | - | - | - |
| | 01 | VAR | 1. mapped object | UINT32 | RW | NO |
| | 02 | VAR | 2. mapped object | UINT32 | RW | NO |
| | 03 | VAR | 3. mapped object | UINT32 | RW | NO |
| | 04 | VAR | 4. mapped object | UINT32 | RW | NO |
| | 05 | VAR | 5. mapped object | UINT32 | RW | NO |
| | 06 | VAR | 6. mapped object | UINT32 | RW | NO |
| | 07 | VAR | 7. mapped object | UINT32 | RW | NO |
| | 08 | VAR | 8. mapped object | UINT32 | RW | NO |
| 1602 | - | RECORD | 3. receive PDO mapping | - | - | - |
| | 01 | VAR | 1. mapped object | UINT32 | RW | NO |
| | 02 | VAR | 2. mapped object | UINT32 | RW | NO |
| | 03 | VAR | 3. mapped object | UINT32 | RW | NO |
| | 04 | VAR | 4. mapped object | UINT32 | RW | NO |
| | 05 | VAR | 5. mapped object | UINT32 | RW | NO |
| | 06 | VAR | 6. mapped object | UINT32 | RW | NO |
| | 07 | VAR | 7. mapped object | UINT32 | RW | NO |
| | 08 | VAR | 8. mapped object | UINT32 | RW | NO |
| 1603 | - | RECORD | 4. receive PDO mapping | - | - | - |
| | 01 | VAR | 1. mapped object | UINT32 | RW | NO |

| Index | Sub index | Object type | Name | Data type | Read write | PDO mapping |
|-------|-----------|------------------|---------------------------|-----------|------------|-------------|
| | 02 | VAR | 2. mapped object | UINT32 | RW | NO |
| | 03 | VAR | 3. mapped object | UINT32 | RW | NO |
| | 04 | VAR | 4. mapped object | UINT32 | RW | NO |
| | 05 | VAR | 5. mapped object | UINT32 | RW | NO |
| | 06 | VAR | 6. mapped object | UINT32 | RW | NO |
| | 07 | VAR | 7. mapped object | UINT32 | RW | NO |
| | 08 | VAR | 8. mapped object | UINT32 | RW | NO |
| 1800 | - | RECORD | 1. transmit PDO parameter | - | - | - |
| | 01 | VAR | COB-ID used by PDO | UINT32 | RW | NO |
| | 02 | VAR | transmission type | UINT8 | RW | NO |
| 1801 | - | RECORD | 2. transmit PDO parameter | - | - | - |
| | 01 | VAR | COB-ID used by PDO | UINT32 | RW | NO |
| | 02 | VAR | transmission type | UINT8 | RW | NO |
| 1802 | - | RECORD | 3. transmit PDO parameter | - | - | - |
| | 01 | VAR | COB-ID used by PDO | UINT32 | RW | NO |
| | 02 | VAR | transmission type | UINT8 | RW | NO |
| 1803 | - | RECORD | 4. transmit PDO parameter | - | - | - |
| | 01 | VAR | COB-ID used by PDO | UINT32 | RW | NO |
| | 02 | VAR | transmission type | UINT8 | RW | NO |
| 1A00 | - | RECORD | 1. transmit PDO mapping | - | - | - |
| | 01 | VAR | 1. mapped object | UINT32 | RW | NO |
| | 02 | VAR | 2. mapped object | UINT32 | RW | NO |
| | 03 | VAR | 3. mapped object | UINT32 | RW | NO |
| | 04 | VAR | 4. mapped object | UINT32 | RW | NO |
| | 05 | VAR | 5. mapped object | UINT32 | RW | NO |
| | 06 | VAR | 6. mapped object | UINT32 | RW | NO |
| | 07 | VAR | 7. mapped object | UINT32 | RW | NO |
| 08 | VAR | 8. mapped object | UINT32 | RW | NO | |
| 1A01 | - | RECORD | 2. transmit PDO mapping | - | - | - |
| | 01 | VAR | 1. mapped object | UINT32 | RW | NO |
| | 02 | VAR | 2. mapped object | UINT32 | RW | NO |
| | 03 | VAR | 3. mapped object | UINT32 | RW | NO |
| | 04 | VAR | 4. mapped object | UINT32 | RW | NO |
| | 05 | VAR | 5. mapped object | UINT32 | RW | NO |
| | 06 | VAR | 6. mapped object | UINT32 | RW | NO |
| | 07 | VAR | 7. mapped object | UINT32 | RW | NO |
| 08 | VAR | 8. mapped object | UINT32 | RW | NO | |
| 1A02 | - | RECORD | 3. transmit PDO mapping | - | - | - |
| | 01 | VAR | 1. mapped object | UINT32 | RW | NO |
| | 02 | VAR | 2. mapped object | UINT32 | RW | NO |
| | 03 | VAR | 3. mapped object | UINT32 | RW | NO |
| | 04 | VAR | 4. mapped object | UINT32 | RW | NO |
| | 05 | VAR | 5. mapped object | UINT32 | RW | NO |
| | 06 | VAR | 6. mapped object | UINT32 | RW | NO |
| | 07 | VAR | 7. mapped object | UINT32 | RW | NO |
| 08 | VAR | 8. mapped object | UINT32 | RW | NO | |

| Index | Sub index | Object type | Name | Data type | Read write | PDO mapping |
|-------|-----------|-------------|-------------------------|-----------|------------|-------------|
| 1A03 | - | RECORD | 4. transmit PDO mapping | - | - | - |
| | 01 | VAR | 1. mapped object | UINT32 | RW | NO |
| | 02 | VAR | 2. mapped object | UINT32 | RW | NO |
| | 03 | VAR | 3. mapped object | UINT32 | RW | NO |
| | 04 | VAR | 4. mapped object | UINT32 | RW | NO |
| | 05 | VAR | 5. mapped object | UINT32 | RW | NO |
| | 06 | VAR | 6. mapped object | UINT32 | RW | NO |
| | 07 | VAR | 7. mapped object | UINT32 | RW | NO |
| | 08 | VAR | 8. mapped object | UINT32 | RW | NO |

Note: items marked with "-" in the table indicate that there are no relevant attributes in the object dictionary.

5.2 List of object dictionaries in the manufacturer's user defined area

The object dictionary in the user-defined area of the manufacturer corresponds to the panel parameters of the servo driver one by one, and only group U parameters in the object dictionary in this area have TPDO mapping attribute, which can be read by PDO, and other object dictionaries can only be operated based on SDO. The corresponding rules are as follows:

| Object dictionary index | Corresponding panel parameters | |
|-------------------------|--------------------------------|--------|
| 2000 | P0 group parameters | P0-00 |
| 2001 | | P0-01 |
| | | |
| 205F | | P0-95 |
| 2100 | P1 group parameters | P1-00 |
| 2101 | | P1-01 |
| | | |
| 214B | | P1-75 |
| 2200 | P2 group parameters | P2-00 |
| 2201 | | P2-01 |
| | | |
| 2263 | | P2-99 |
| 2300 | P3 group parameters | P3-00 |
| 2301 | | P3-01 |
| | | |
| 232D | | P3-45 |
| 2400 | P4 group parameters | P4-00 |
| 2401 | | P4-01 |
| | | |
| 24FE | | P4-254 |
| 2500 | P5 group parameters | P5-00 |
| 2501 | | P5-01 |
| | | |
| 2547 | | P5-71 |
| 2605 | P6 group parameters | P6-05 |
| 2607 | | P6-06 |
| 2608 | | P6-08 |
| 260C | | P6-12 |
| 2700 | P7 group parameters | P7-00 |
| 2701 | | P7-01 |
| | | |
| 271F | | P7-31 |
| 2800 | P8 group parameters | P8-00 |

| Object dictionary index | Corresponding panel parameters | |
|-------------------------|--------------------------------|-------|
| 2801 | | P8-01 |
| | | |
| 2817 | | P8-23 |
| 2E00 | PE group parameters | PE-00 |
| 2E02 | | PE-02 |
| | | |
| 2E62 | | PE-62 |
| 3000 | U0 group parameters | U0-00 |
| 3001 | | U0-01 |
| | | |
| 3063 | | U0-99 |
| 3100 | U1 group parameters | U1-00 |
| 3101 | | U1-01 |
| | | |
| 3159 | | U1-59 |
| 3200 | U2 group parameters | U2-00 |
| 3201 | | U2-01 |
| | | |
| 3230 | | U2-30 |
| 3300 | U3 group parameters | U3-00 |
| 3301 | | U3-01 |
| | | |
| 3370 | | U3-70 |
| 3400 | U4 group parameters | U4-00 |
| 3401 | | U4-01 |
| | | |
| 340A | | U4-10 |
| 4000 | F0 group parameters | F0-00 |
| 4105 | F1 group parameters | F1-05 |
| 4106 | | F1-06 |

5.3 List of object dictionary in sub protocol area of motion control equipment

| Index | Sub-Index | Type | Name/Description | Date Type | Access | PDO | Op-mode |
|-------|-----------|------|---|-----------|--------|-----|---------|
| 6040h | 00h | VAR | Controlword | U16 | rw | YES | All |
| | | | Control word | | | | |
| 6041h | 00h | VAR | Statusword | U16 | ro | YES | All |
| | | | Status word | | | | |
| 605Ah | 00h | VAR | Quickstop Option Code | I16 | rw | NO | All |
| | | | Used to select the action when the servo drive system responds to the emergency stop command. The default value is 2. | | | | |
| 605Bh | 00h | VAR | Shutdown option code | I16 | rw | NO | All |
| | | | Set the motor deceleration stop method when PDS commands "shutdown" and "disable voltage" are received. The default value is 0. | | | | |
| 605Ch | 00h | VAR | Disable operation option code | I16 | rw | NO | All |
| | | | Set the motor deceleration stop method when receiving PDS command "disable operation". The default value is 1. | | | | |
| 605Dh | 00h | VAR | Halt option code | I16 | rw | NO | All |
| | | | Set the motor deceleration stop method when receiving the command "halt". The default value is 1. | | | | |
| 605Eh | 00h | VAR | Fault reaction option code | I16 | rw | NO | All |
| | | | Set the motor stop method when the alarm occurs. The default value is 2. | | | | |
| 6060h | 00h | VAR | Modes of Operation | I8 | rw | YES | All |
| | | | Used to set the control mode of the servo driver. | | | | |
| 6061h | 00h | VAR | Modes of Operation Display | I8 | ro | YES | All |
| | | | Used to indicate the current control mode of servo driver. | | | | |
| 6062h | 00h | VAR | Position Demand Value | I32 | rw | YES | PP, HM |
| | | | The output value of the position track generator. | | | | |
| 6063h | 00h | VAR | Position Actual Internal Value | I32 | ro | YES | All |
| | | | The internal actual position fed back by the servo motor, it is the feedback of the position loop. | | | | |
| 6064h | 00h | VAR | Position Actual Value | I32 | ro | YES | All |
| | | | Actual position fed back by servo motor. | | | | |
| 606Bh | 00h | VAR | Velocity Demand Value | I32 | ro | YES | PV |
| | | | The output value of the velocity trajectory generator, which is the input of the velocity loop. | | | | |
| 606Ch | 00h | VAR | Velocity Actual Value | I32 | ro | YES | All |
| | | | The actual speed fed back by the servo motor which is the feedback of the speed loop. | | | | |
| 6071h | 00h | VAR | Target Torque | I16 | rw | YES | TQ |
| | | | The user target torque input when the servo driver is in TQ mode, the unit is 0.1% of the rated torque, which is only valid in TQ mode. | | | | |
| 6072h | 00h | VAR | Max Torque | U16 | rw | YES | All |
| | | | The maximum torque that the servo drive system can produce, the unit is 0.1% of the rated torque, and the default value is 3000, that is, 300% of the rated torque. | | | | |
| 6073h | 00h | VAR | Max Current | U16 | rw | YES | All |
| | | | The maximum current that the servo motor can withstand, the unit is 0.1% of the rated current, and the default value is 3000, that is, 300% of the rated current. | | | | |
| 6074h | 00h | VAR | Torque Demand Value | I16 | rw | YES | All |
| | | | Torque command, input of torque loop, unit: 0.1% of rated torque. | | | | |
| 6075h | 00h | VAR | Motor Rated Current | U32 | ro | YES | All |
| | | | The rated current of the servo motor is automatically set by the system according to the parameters of the servo motor. Generally, it does not need to be set by the user. The unit is 0.1% of the rated current. | | | | |
| 6076h | 00h | VAR | Motor Rated Torque | U32 | ro | YES | All |
| | | | The rated torque of the servo motor is automatically set by the system according | | | | |

| Index | Sub-Index | Type | Name/Description | Data Type | Access | PDO | Op-mode |
|-------|-----------|--------|---|-------------------|-----------------|----------|----------|
| | | | to the parameters of the servo motor. Generally, it does not need to be set by the user. The unit is 0.1% of the rated torque. | | | | |
| 6077h | 00h | VAR | Torque Actual Value | I16 | ro | YES | All |
| | | | The actual torque of the servo motor, i.e. the feedback of the torque loop, the unit is 0.1% of the rated torque. | | | | |
| 6078h | 00h | VAR | Current Actual Value | I16 | ro | YES | All |
| | | | Actual quadrature axis current of servo motor, unit: 0.1% of rated current. | | | | |
| 6079h | 00h | VAR | DC Link Circuit Voltage | U32 | ro | YES | All |
| | | | DC bus voltage of servo driver, unit: 0.001V. | | | | |
| 607Ah | 00h | VAR | Target Position | I32 | rw | YES | PP |
| | | | The user target position when the servo driver is in PP mode. The unit is the command unit, which is only valid in PP mode. | | | | |
| 607Eh | 00h | VAR | Polarity | U8 | rw | YES | All |
| | | | User instruction polarity, which has 8 bits, as shown in the following table: | | | | |
| | | | Bit7 | Bit6 | Bit5 | Bit0-4 | |
| | | | position polarity | velocity polarity | torque polarity | reserved | |
| | | | When BitX (X = 5, 6, 7) is 0, indicates that the user instruction is a forward instruction. | | | | |
| | | | When BitX (X = 5, 6, 7) is 1, indicates that the user instruction is a reverse instruction. | | | | |
| 607Fh | 00h | VAR | Max Profile Velocity | U32 | rw | YES | PP,PV,HM |
| | | | The maximum speed of servo motor during operation, the unit is command unit/s, is effective in control modes other than TQ. The default value is 1000000 (0xF4240). | | | | |
| 6080h | 00h | VAR | Max Motor Speed | U32 | rw | YES | ALL |
| | | | The maximum speed of servo motor during operation, the unit is R/min. The default value is 6000 (0x1770). | | | | |
| 6081h | 00h | VAR | Profile Velocity | U32 | rw | YES | PP |
| | | | During position trajectory planning, the speed reached when the motor acceleration process is completed, the unit is the command unit/s, which is only valid in PP mode. | | | | |
| 6083h | 00h | VAR | Profile Acceleration | U32 | rw | YES | PP,PV |
| | | | During position trajectory planning or speed trajectory planning, the acceleration during motor acceleration, the unit is command unit/s ² , which is only effective in PP mode and PV mode. The default value is 5000000. | | | | |
| 6084h | 00h | VAR | Profile Deceleration | U32 | rw | YES | PP,PV |
| | | | During position trajectory planning or speed trajectory planning, the deceleration speed during motor deceleration, the unit is the command unit/s ² , which is only effective in PP mode and PV mode. The default value is 5000000. | | | | |
| 6085h | 00h | VAR | Quick Stop Declaration | U32 | rw | YES | PP,PV,HM |
| | | | When the servo drive system responds to the emergency stop command, emergency stop deceleration that can be taken, the unit is the command unit/s ² , which is effective in the control mode other than TQ. The default value is 10000000. | | | | |
| 6087h | 00h | VAR | Torque Slope | U32 | rw | YES | TQ |
| | | | The torque change rate adopted when the torque command of the servo drive system changes, the unit is 0.1%/s of the rated torque, which is only valid in TQ mode. | | | | |
| 6098h | 00h | VAR | Homing Method | I8 | rw | YES | HM |
| | | | It is used to set the homing mode of servo drive system, which is only effective in HM mode. | | | | |
| 6099h | 00h | RECORD | Homing Speeds | - | - | - | HM |
| | | | It has two sub indexes, which are only valid in HM mode. | | | | |
| | 01h | VAR | Speed during Search Switch | U32 | rw | YES | HM |
| | | | The speed of the servo motor when looking for the switch signal. The unit is the command unit/s. The default value is 10000. | | | | |

| Index | Sub-Index | Type | Name/Description | Date Type | Access | PDO | Op-mode |
|-------|-----------|------|---|-----------|--------|------|----------|
| | 02h | VAR | Speed during Search Zero | U32 | rw | YES | HM |
| | | | The speed of servo motor when looking for zero signal. The unit is command unit/s. The default value is 5000. | | | | |
| 609Ah | 00h | VAR | Homing Acceleration | U32 | rw | YES | HM |
| | | | The acceleration and deceleration adopted by the servo motor during homing movement, the unit is command unit/s ² , which is only valid in HM mode. The default value is 20000. | | | | |
| 60C5h | 00h | VAR | Max Acceleration | U32 | rw | YES | PP,PV,HM |
| | | | The maximum allowable acceleration of servo motor during acceleration, unit is command unit/s ² , which is effective in PP, PV and HM modes. The default value is 4294967295. | | | | |
| 60C6h | 00h | VAR | Max Deceleration | U32 | rw | YES | PP,PV,HM |
| | | | The maximum deceleration allowed by the servo motor during deceleration, the unit is the command unit/s ² , which is effective in PP, PV and HM modes. The default value is 4294967295. | | | | |
| 60F4h | 00h | VAR | Following Error Actual Value | I32 | ro | YES | PP,HM |
| | | | The position deviation of servo drive system during position control, i.e. 0x60F4 = 0x6062 – 0x6064, is effective in PP and HM modes. | | | | |
| 60FCh | 00h | VAR | Position Demand Internal Value | I32 | ro | YES | PP,HM |
| | | | The object dictionary 0x6062 is the result of motion polarity processing by the object dictionary 0x607E (polarity), which is the input of the position loop. | | | | |
| 60FDh | 00h | VAR | Digital Inputs | U32 | ro | YES | All |
| | | | The input states of POT, NOT and SPD-D are indicated by the function signals allocated by panel parameters P5-22 (POT), P5-23 (NOT) and P5-27 (SPD-D). It has 32 bits, as shown in the following table: | | | | |
| | | | Bit31~Bit3 | Bit2 | Bit1 | Bit0 | |
| | | | reserved | SPD-D | POT | NOT | |
| 60FFh | 00h | VAR | Target Velocity | I32 | rw | YES | PV |
| | | | The user target speed when the servo driver is in PV mode. The unit is command unit/s, which is only valid in PV mode. | | | | |

| PDS conversion | | Event | Action |
|----------------|-------------------|---|--|
| 1 | Auto skip 1 | Automatic conversion after initialization. | Communication is established. |
| 2 | Shut down | Receive the Shutdown command. | Nothing special. |
| 3 | Switch on | When the power supply is on, the Switch on command is received. | Nothing special. |
| 4 | Enable operation | Receiving the Enable operation command. | The driving function is effective. In addition, all previous set point data are cleared. |
| 5 | Disable operation | Receiving the Disable operation command. | The drive function is invalid. |
| 6 | Shutdown | When the power supply is on, the Shutdown command is received. Check out the condition that the power supply is off. | Nothing special. |
| 7 | Disable voltage | Receiving the Disable voltage command. Receiving the Quick stop command. | Nothing special. |
| 8 | Shutdown | When the power supply is on, the Shutdown command is received. | The drive function is invalid. |
| 9 | Disable voltage | Receiving the Disable voltage command. | The drive function is invalid. |
| 10 | Disable voltage | Receiving the Disable voltage command. Receiving the Quick stop command. | Nothing special. |
| 11 | Quick stop | Receiving the Quick stop command. | Execute Quick stop function. |
| 12 | Disable voltage | When the Quick stop selection code is the set value of 1, 2 and 3, and the quick stop action is completed. When the Quick stop selection code is the set value of 5, 6 and 7, and the disable voltage command is received after the quick stop action is completed. Check out the condition that the power supply is off. | The drive function is invalid. |
| 13 | Error occurs | Abnormal detection. | Execute Fault reaction function. |
| 14 | Auto skip 2 | After the abnormality detection and deceleration processing is completed, it will migrate automatically. | The drive function is invalid. |
| 15 | Fault reset | After the fault factor is removed, the fault reset instruction is received. | If the fault factor does not exist, reset the fault status. |
| 16 | Enable operation | When the quick stop selection code is the set value of 5, 6 and 7, the Enable operation command is received. | The driving function is effective. |

6.2 Control status

6.2.1 Controlword(6040h)

The commands of PDS state migration and control slave station (servo driver) are set through 6040h (control word).

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|-----------|------------------|---------|----------|--------|-------|---------|----|----|----|----|----|----|---|---|---|--|--|--|--|--|--|---|---|---|---|---|---|---|---|---|----|-----|--|--|----|----|----|----|
| 6040h | 00h | Controlword | 0~65535 | U16 | rw | RxPDO | All | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Set the control command of servo driver such as PDS state conversion. Bit information: <table border="1" style="margin: 10px auto; width: 80%;"> <thead> <tr> <th>15</th><th>14</th><th>13</th><th>12</th><th>11</th><th>10</th><th>9</th><th>8</th></tr> </thead> <tbody> <tr> <td colspan="7" style="text-align: center;">r</td> <td style="text-align: center;">h</td> </tr> <tr> <th>7</th><th>6</th><th>5</th><th>4</th><th>3</th><th>2</th><th>1</th><th>0</th></tr> <tr> <td style="text-align: center;">fr</td> <td colspan="3" style="text-align: center;">oms</td> <td style="text-align: center;">eo</td> <td style="text-align: center;">qs</td> <td style="text-align: center;">ev</td> <td style="text-align: center;">so</td> </tr> </tbody> </table> <p> r = reserved (Not correspond) fr = fault reset oms = operation mode specific eo = enable operation (control mode based on bit) qs = quick stop h = halt ev = enable voltage so = switch on </p> | | | | | | | | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | r | | | | | | | h | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | fr | oms | | | eo | qs | ev | so |
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r | | | | | | | h | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| fr | oms | | | eo | qs | ev | so | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Command | bits of the controlword | | | | | PDS conversion |
|------------------------------|-------------------------|------------------|------------|----------------|-----------|----------------|
| | bit7 | bit3 | bit2 | bit1 | bit0 | |
| | fault reset | Enable operation | quick stop | Enable voltage | Switch on | |
| Shutdown | 0 | - | 1 | 1 | 0 | 2, 6, 8 |
| Switch on | 0 | 0 | 1 | 1 | 1 | 3 |
| Switch on + Enable operation | 0 | 1 | 1 | 1 | 1 | 3+4 |
| Enable operation | 0 | 1 | 1 | 1 | 1 | 4, 16 |
| Disable voltage | 0 | - | - | 0 | - | 7, 9, 10, 12 |
| Quick stop | 0 | - | 0 | 1 | - | 7, 10, 11 |
| Disable operation | 0 | 0 | 1 | 1 | 1 | 5 |
| Fault reset | 0->1 | - | - | - | - | 13 |

The bit logic of the Quick stop instruction is valid under 0.

Please note that other bit logic and opposite actions are executed.

When bit8 (HALT): 1, the motor deceleration pause is executed through 605Dh (halt selection code). After pause, return to 0 and start the action. However, if the action is interrupted by 1 in HM control mode, it cannot be opened again even if it returns 0.

Bit6-4 (operation mode specific): the following represents the inherent change of OMS bit in the control mode (OP-mode). (for details, please refer to the chapter of related objects of each control mode)

| Op-mode | Bit6 | Bit5 | Bit4 |
|---------|-------------------|------------------------|---------------|
| pp | absolute /elative | change set immediately | new set-point |
| pv | - | - | - |
| tq | - | - | - |
| hm | - | - | start homing |

6.3 Control mode

6.3.1 Modes of operation (6060h)

The control mode is set through 6060h (Modes of operation).

| Index | Sub-Index | Name/Description | Range | Date Type | Access | PDO | Op-mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|----------------------------------|---|------------|-------------------|--------|------------|----------|----------|---|---|---|----------------------------------|---|---|---|-----------------------|----|-----|---|-----------------------|----|-----|---|---------------------|----|-----|---|-------------|----|-----|-------|----------|---|---|--|--|--|--|
| 6060h | 00h | Mode of operation | -128~127 | I8 | rw | RxPDO | All | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Set the control mode of the servo driver. Non corresponding control mode setting is prohibited. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>bit</th> <th>Mode of operation</th> <th>Abb.</th> <th>Correspond</th> </tr> </thead> <tbody> <tr> <td>-128~ -1</td> <td>Reserved</td> <td>-</td> <td>-</td> </tr> <tr> <td>0</td> <td>No mode changed/No mode assigned</td> <td>-</td> <td>-</td> </tr> <tr> <td>1</td> <td>Profile position mode</td> <td>pp</td> <td>YES</td> </tr> <tr> <td>3</td> <td>Profile velocity mode</td> <td>pv</td> <td>YES</td> </tr> <tr> <td>4</td> <td>Torque profile mode</td> <td>tq</td> <td>YES</td> </tr> <tr> <td>6</td> <td>Homing mode</td> <td>hm</td> <td>YES</td> </tr> <tr> <td>7~127</td> <td>Reserved</td> <td>-</td> <td>-</td> </tr> </tbody> </table> | bit | Mode of operation | Abb. | Correspond | -128~ -1 | Reserved | - | - | 0 | No mode changed/No mode assigned | - | - | 1 | Profile position mode | pp | YES | 3 | Profile velocity mode | pv | YES | 4 | Torque profile mode | tq | YES | 6 | Homing mode | hm | YES | 7~127 | Reserved | - | - | | | | |
| bit | Mode of operation | Abb. | Correspond | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| -128~ -1 | Reserved | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | No mode changed/No mode assigned | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Profile position mode | pp | YES | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Profile velocity mode | pv | YES | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Torque profile mode | tq | YES | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Homing mode | hm | YES | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7~127 | Reserved | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Because 6060h (modes of operation) is default = (no mode change / no mode assigned), please be sure to set the control mode value after the power is put into operation. When the set value of 6060h is 0 and the set value of 6061h is 0, if the PDS state is transferred to operation enabled, E-881 (control mode setting fault protection) occurs. After the initial state 6060h = 0 (no mode assigned) is converted to the supportable control mode (PP, PV, TQ, HM), the condition of 6060h = 0 is set again as "no mode changed", and the switching of control mode cannot be performed. (maintain the previous control mode).

6.3.2 Modes of operation display (6061h)

The confirmation of the control mode inside the servo driver is performed according to 6061h (modes of operation display). After 6060h (modes of operation) is set, confirm whether the action is feasible by detecting and setting this object.

| Index | Sub-Index | Name/Description | Range | Date Type | Access | PDO | Op-mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------------------------------------|----------------------------------|---|------------|-------------------|--------|------------|----------|----------|---|---|---|----------------------------------|---|---|---|-----------------------|----|-----|---|-----------------------|----|-----|---|---------------------|----|-----|---|-------------|----|-----|-------|----------|---|---|--|--|--|--|
| 6061h | 00h | Mode of operation display | -128~127 | I8 | ro | TxPDO | All | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Indicates the current control mode. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>bit</th> <th>Mode of operation</th> <th>Abb.</th> <th>Correspond</th> </tr> </thead> <tbody> <tr> <td>-128~ -1</td> <td>Reserved</td> <td>-</td> <td>-</td> </tr> <tr> <td>0</td> <td>No mode changed/No mode assigned</td> <td>-</td> <td>-</td> </tr> <tr> <td>1</td> <td>Profile position mode</td> <td>pp</td> <td>YES</td> </tr> <tr> <td>3</td> <td>Profile velocity mode</td> <td>pv</td> <td>YES</td> </tr> <tr> <td>4</td> <td>Torque profile mode</td> <td>tq</td> <td>YES</td> </tr> <tr> <td>6</td> <td>Homing mode</td> <td>hm</td> <td>YES</td> </tr> <tr> <td>7~127</td> <td>Reserved</td> <td>-</td> <td>-</td> </tr> </tbody> </table> | bit | Mode of operation | Abb. | Correspond | -128~ -1 | Reserved | - | - | 0 | No mode changed/No mode assigned | - | - | 1 | Profile position mode | pp | YES | 3 | Profile velocity mode | pv | YES | 4 | Torque profile mode | tq | YES | 6 | Homing mode | hm | YES | 7~127 | Reserved | - | - | | | | |
| bit | Mode of operation | Abb. | Correspond | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| -128~ -1 | Reserved | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | No mode changed/No mode assigned | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Profile position mode | pp | YES | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Profile velocity mode | pv | YES | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Torque profile mode | tq | YES | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Homing mode | hm | YES | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7~127 | Reserved | - | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

6.4 Selection of the code (Deceleration stop time setting)

PDS is a motor deceleration stop method for setting the interruption of main power supply or the occurrence of alarm in the operation enabled state (servo enable turned on).

The deceleration mode (dynamic brake stop, free running stop, instant stop) of the deceleration function (selection code) defined by COE (CiA402) is used in combination.

PDS selection code list:

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode |
|-------|-----------|-------------------------------|-------|----------|--------|-----|---------|
| 605Ah | 00h | Quick stop option code | 0-7 | I16 | rw | NO | All |
| 605Bh | 00h | Shutdown option code | 0-1 | I16 | rw | NO | All |
| 605Ch | 00h | Disable operation option code | 0-1 | I16 | rw | NO | All |
| 605Dh | 00h | Halt option code | 1-3 | I16 | rw | NO | All |
| 605Eh | 00h | Fault reaction option code | 0-2 | I16 | rw | NO | All |

Other related object list:

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode |
|-------|-----------|-------------------------|--------------|----------|--------|-------|---------|
| 6084h | 00h | Profile deceleration | 0-4294967295 | U32 | rw | RxPDO | All |
| 6085h | 00h | Quick stop deceleration | 0-4294967295 | U32 | rw | RxPDO | All |
| 6087h | 00h | Torque slope | 0-4294967295 | U32 | rw | RxPDO | All |
| 609Ah | 00h | Homing acceleration | 0-4294967295 | U32 | rw | RxPDO | All |
| 60C6h | 00h | Max deceleration | 0-4294967295 | U32 | rw | RxPDO | All |


6.4.1 Quick stop option code(605Ah)

Set the motor deceleration stop method when PDS command "quick stop" is received.

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode |
|--|-----------|------------------------|---|----------|--------|-----|---------|
| 605Ah | 00h | Quick stop option code | 0-7 | I16 | rw | NO | All |
| Set the timing of quick stop. The definition varies according to the control mode. It is forbidden to set other than the following values. | | | | | | | |
| | | Value | Definition | | | | |
| | | 0 | Stop immediately and the PDS state will be transferred to Switch on disabled | | | | |
| | | 1 | The control mode is PP, PV: after the motor is stopped through 0x6084 (profile decision), the PDS state shifts to Switch on disabled | | | | |
| | | | The control mode is HM: after the motor is stopped through 0x609A (Homing acceleration), the PDS state shifts to Switch on disabled | | | | |
| | | | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state shifts to Switch on disabled | | | | |
| | | 2 | The control modes are PP, PV and HM: after the motor is stopped through 0x6085 (quick stop declaration), the PDS state is transferred to Switch on disabled | | | | |
| | | | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state shifts to Switch on disabled | | | | |
| | | 3 | The control modes are PP, PV and HM: after the motor is stopped through 0x60C6 (max deceleration), the PDS state is transferred to Switch on disabled | | | | |
| | | | The control mode is TQ: after the motor stops through torque 0, the PDS state shifts to Switch on disabled | | | | |
| | | 5 | The control mode is PP, PV: after the motor is stopped through 0x6084 (profile deceleration), the PDS state is transferred to Quick stop active | | | | |
| | | | The control mode is HM: after the motor is stopped through 0x609A (Homing acceleration), the PDS state will be transferred to Quick stop active | | | | |
| | | | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Quick stop active | | | | |
| | | 6 | The control modes are PP, PV and HM: after the motor is stopped | | | | |

| | | | |
|--|--|---|---|
| | | | through 0x6085 (quick stop declaration), the PDS state will be transferred to Quick stop active |
| | | | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Quick stop active |
| | | 7 | The control modes are PP, PV and HM: after the motor is stopped through 0x60C6 (max deceleration), the PDS state will be transferred to Quick stop active |
| | | | The control mode is TQ: after the motor stops through torque 0, the PDS state will be transferred to Quick stop active |

Example of deceleration stop action according to quick stop command: if 6040h: bit2 (controlword: quick stop) changes from 1 to 0, deceleration stop starts. The PDS status in deceleration changes to quick stop active. The PDS status after stopping is switch on disabled, or it changes to quick stop active.




6.4.2 Shutdown on code(605Bh)

Set the motor deceleration stop method when PDS commands "shutdown" and "disable voltage" are received.

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode |
|-------|-----------|----------------------|-------|----------|--------|-----|---------|
| 605Bh | 00h | Shutdown option code | 0-1 | I16 | rw | NO | All |

| | <p>Set the timing of "shutdown" and "disable voltage". The definition varies according to the control mode.</p> <p>It is forbidden to set other than the following values.</p> <p>(1) PDS command 「Shutdown」 receiving</p> <table border="1"> <thead> <tr> <th>Value</th> <th>Definition</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Stop immediately and the PDS status will be transferred to Ready to switch on.</td> </tr> <tr> <td rowspan="3">1</td> <td>The control mode is PP, PV: after the motor is stopped through 0x6084 (profile deceleration), the PDS state is transferred to Ready to switch on.</td> </tr> <tr> <td>The control mode is HM: after the motor is stopped through 0x609Ah (homing acceleration), the PDS state is transferred to Ready to switch on.</td> </tr> <tr> <td>The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Ready to switch on.</td> </tr> </tbody> </table> <p>(2) PDS command 「Disable voltage」 receiving</p> <table border="1"> <thead> <tr> <th>Value</th> <th>Definition</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Stop immediately and the PDS state will be transferred to Switch on disabled.</td> </tr> <tr> <td rowspan="3">1</td> <td>The control mode is PP, PV: after the motor is stopped through 0x6084 (profile deceleration), the PDS state is transferred to Switch on disabled.</td> </tr> <tr> <td>The control mode is HM: after the motor is stopped through 0x609Ah (homing acceleration), the PDS state is transferred to Switch on disabled.</td> </tr> <tr> <td>The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Switch on disabled.</td> </tr> </tbody> </table> | Value | Definition | 0 | Stop immediately and the PDS status will be transferred to Ready to switch on. | 1 | The control mode is PP, PV: after the motor is stopped through 0x6084 (profile deceleration), the PDS state is transferred to Ready to switch on. | The control mode is HM: after the motor is stopped through 0x609Ah (homing acceleration), the PDS state is transferred to Ready to switch on. | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Ready to switch on. | Value | Definition | 0 | Stop immediately and the PDS state will be transferred to Switch on disabled. | 1 | The control mode is PP, PV: after the motor is stopped through 0x6084 (profile deceleration), the PDS state is transferred to Switch on disabled. | The control mode is HM: after the motor is stopped through 0x609Ah (homing acceleration), the PDS state is transferred to Switch on disabled. | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Switch on disabled. |
|-------|--|-------|------------|---|--|---|---|---|---|-------|------------|---|---|---|---|---|---|
| Value | Definition | | | | | | | | | | | | | | | | |
| 0 | Stop immediately and the PDS status will be transferred to Ready to switch on. | | | | | | | | | | | | | | | | |
| 1 | The control mode is PP, PV: after the motor is stopped through 0x6084 (profile deceleration), the PDS state is transferred to Ready to switch on. | | | | | | | | | | | | | | | | |
| | The control mode is HM: after the motor is stopped through 0x609Ah (homing acceleration), the PDS state is transferred to Ready to switch on. | | | | | | | | | | | | | | | | |
| | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Ready to switch on. | | | | | | | | | | | | | | | | |
| Value | Definition | | | | | | | | | | | | | | | | |
| 0 | Stop immediately and the PDS state will be transferred to Switch on disabled. | | | | | | | | | | | | | | | | |
| 1 | The control mode is PP, PV: after the motor is stopped through 0x6084 (profile deceleration), the PDS state is transferred to Switch on disabled. | | | | | | | | | | | | | | | | |
| | The control mode is HM: after the motor is stopped through 0x609Ah (homing acceleration), the PDS state is transferred to Switch on disabled. | | | | | | | | | | | | | | | | |
| | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Switch on disabled. | | | | | | | | | | | | | | | | |

Example of deceleration stop action according to the shutdown command: if received the PDS command "shutdown", starts deceleration stop. PDS status in deceleration remains Operation enabled. The PDS status after stop is Ready to switch on.




Note: 6041h: bit4 (statusword: voltage enabled) is still 1 and does not change.

6.4.3 Disable operation option code(605Ch)

Set the motor deceleration stop method when receiving PDS command "disable operation".

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode | | | | | | | | | |
|-------|--|---|-------|------------|--------|--|---------|--|--|--|--|--|--|--|--|--|
| 605Ch | 00h | Disable operation option code | 0-1 | I16 | rw | NO | All | | | | | | | | | |
| | | Set the timing of "disable operation". The definition varies according to the control mode. It is forbidden to set other than the following values. | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Value</th> <th>Definition</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Stop immediately and the PDS state will be transferred to Switch on.</td> </tr> <tr> <td rowspan="3">1</td> <td>The control mode is PP, PV: after the motor is stopped through 0x6084 (profile deceleration), the PDS state is transferred to Switch on.</td> </tr> <tr> <td>The control mode is HM: after the motor is stopped through 0x609Ah (homing acceleration), the PDS state is transferred to Switch on.</td> </tr> <tr> <td>The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Switch on.</td> </tr> </tbody> </table> | Value | Definition | 0 | Stop immediately and the PDS state will be transferred to Switch on. | 1 | The control mode is PP, PV: after the motor is stopped through 0x6084 (profile deceleration), the PDS state is transferred to Switch on. | The control mode is HM: after the motor is stopped through 0x609Ah (homing acceleration), the PDS state is transferred to Switch on. | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Switch on. | | | | | | |
| Value | Definition | | | | | | | | | | | | | | | |
| 0 | Stop immediately and the PDS state will be transferred to Switch on. | | | | | | | | | | | | | | | |
| 1 | The control mode is PP, PV: after the motor is stopped through 0x6084 (profile deceleration), the PDS state is transferred to Switch on. | | | | | | | | | | | | | | | |
| | The control mode is HM: after the motor is stopped through 0x609Ah (homing acceleration), the PDS state is transferred to Switch on. | | | | | | | | | | | | | | | |
| | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Switch on. | | | | | | | | | | | | | | | |

Example of deceleration stop according to the Disable operation command. If the PDS command "disable operation" is received, the deceleration stop starts. PDS status in deceleration remains operation enabled. PDS status is switched on after stop.




6.4.4 Halt option code(605Dh)

When bit8 (HALT) of 6040h (controlword) is 1, set the motor deceleration stop method.

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode |
|-------|-----------|------------------|-------|----------|--------|-----|---------|
| 605Dh | 00h | Halt option code | 1-3 | I16 | rw | NO | All |

| Set the timing of Halt action. The definition varies according to the control mode. It is forbidden to set other than the following values. | |
|---|--|
| Value | Definition |
| 1 | The control mode is PP, PV: after the motor is stopped through 0x6084 (profile deceleration), the PDS state is transferred to Operation enabled |
| | The control mode is HM: after the motor is stopped through 0x609A (homing acceleration), the PDS state is transferred to Operation enabled |
| | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Operation enabled |
| 2 | The control modes are PP, PV and HM: after the motor is stopped through 0x6085 (quick stop declaration), the PDS state is transferred to Operation enabled |
| | The control mode is CST, TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Operation enabled |
| 3 | The control modes are PP, PV and HM: after the motor is stopped through 0x60C6 (max deceleration), the PDS state will be transferred to Operation enabled |
| | The control mode is TQ: after the motor stops through torque 0, the PDS state will be transferred to Operation enabled |

The example of the deceleration stop action according to the halt function, if 6040h: bit8 (controlword: halt) changes from 0 to 1, the deceleration stop starts. PDS status in deceleration remains Operation enabled. The PDS status after stop remains Operation enabled.




6.4.5 Fault reaction option code(605Eh)

Set the motor stop method when the alarm occurs.

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode |
|--|-----------|----------------------------|--|----------|--------|-----|---------|
| 605Eh | 00h | Fault reaction option code | 0-2 | I16 | rw | NO | All |
| Set the timing when the alarm occurs. The definition varies according to the control mode. It is forbidden to set the value other than below list. | | | | | | | |
| | | Value | Definition | | | | |
| | | 0 | Stop immediately and the PDS status will be transferred to Fault. | | | | |
| | | 1 | The control mode is PP, PV: after the motor is stopped through 0x6084 (profile deceleration), the PDS state is transferred to Fault. | | | | |
| | | | The control mode is HM: after the motor is stopped through 0x609Ah (homing acceleration), the PDS state is transferred to Fault. | | | | |
| | | | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Fault. | | | | |
| | | 2 | The control modes are PP, PV and HM: after the motor stops through 6085h (Quick stop cancellation), it will be transferred to Fault. | | | | |
| | | | The control mode is TQ: after the motor is stopped through 0x6087 (torque slope), the PDS state is transferred to Fault | | | | |

Example of deceleration stop when the alarm occurs, if the alarm occurs, starts deceleration stop. PDS status in deceleration is Fault reaction active. The PDS status after stopping is Fault.



7 DS5N1 motion control mode

DS5N1 supports four bus motion control modes based on CANopen bus, including contour position mode (PP), contour speed mode (PV), contour torque mode (TQ) and homing mode (HM), and does not support external control modes (CSP, CSV, CST).

7.1 PP mode

PP (profile position control mode) is a position control mode that specifies the target position, target speed, acceleration and deceleration, and acts after generating position commands in the servo driver.

7.1.1 Related parameters

PP control mode related object (command • setting):

| Register | Note | Unit |
|---------------|------------------------|------------------------------|
| RXPDO[0x6040] | Control word | - |
| RXPDO[0x6060] | Set to 1 | - |
| RXPDO[0x607A] | Position setting | Command unit |
| RXPDO[0x6072] | Max torque | 0.1% |
| RXPDO[0x607F] | Max internal speed | Command unit /s |
| RXPDO[0x6080] | Max motor speed | r/min |
| RXPDO[0x6081] | Internal speed setting | Command unit /s |
| RXPDO[0x6083] | Internal acceleration | Command unit /s ² |
| RXPDO[0x6084] | Internal deceleration | Command unit /s ² |
| RXPDO[0x60C5] | Max acceleration | Command unit /s ² |
| RXPDO[0x60C6] | Max deceleration | Command unit /s ² |

Note:

- (1) 6081h (profile velocity) is limited by the smaller one of 607Fh (max profile velocity) and 6080h (max motor speed).
- (2) Changing the set value of 607Fh (max profile velocity) or 6080h (max motor speed) in the action is not reflected in the action.

PP control mode related object (command • monitor):


| Register | Note | Unit |
|---------------|---|-----------------|
| TXPDO[0x6041] | Status word | - |
| TXPDO[0x6061] | Mode queries | |
| TXPDO[0x6063] | Internal actual position | Command unit |
| TXPDO[0x6064] | Position feedback (motor actual position) | Command unit |
| TXPDO[0x606C] | Speed feedback | Command unit /s |
| TXPDO[0x6077] | Actual torque | 0.1% |
| TXPDO[0x60F4] | Actual follow error | Command unit |

7.1.2 Control word (6040h) < pp control mode function >

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|-----------|------------------------|---------------|-----------------------|--------|-------|---------|----|----|----|----|----|----|---|---|---|--|--|--|--|--|--|---|---|---|---|---|---|---|---|---|----|-----|--|--|----|----|----|----|----------|------------------------|---------------|
| 6040h | 00h | Controlword | 0~65535 | U16 | rw | RxPDO | All | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Set the control command of servo driver such as PDS state conversion. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Bit information | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="width:100%; border-collapse: collapse;"> <thead> <tr> <th>15</th><th>14</th><th>13</th><th>12</th><th>11</th><th>10</th><th>9</th><th>8</th> </tr> </thead> <tbody> <tr> <td colspan="7" style="text-align: center;">r</td> <td style="text-align: center;">h</td> </tr> <tr> <th>7</th><th>6</th><th>5</th><th>4</th><th>3</th><th>2</th><th>1</th><th>0</th> </tr> <tr> <td rowspan="2" style="text-align: center;">fr</td> <td colspan="3" style="text-align: center;">oms</td> <td rowspan="2" style="text-align: center;">eo</td> <td rowspan="2" style="text-align: center;">qs</td> <td rowspan="2" style="text-align: center;">ev</td> <td rowspan="2" style="text-align: center;">so</td> </tr> <tr> <td style="text-align: center;">Abs /rel</td> <td style="text-align: center;">Change set immediately</td> <td style="text-align: center;">New set point</td> </tr> </tbody> </table> | | | | | | | | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | r | | | | | | | h | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | fr | oms | | | eo | qs | ev | so | Abs /rel | Change set immediately | New set point |
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r | | | | | | | h | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| fr | oms | | | eo | qs | ev | so | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Abs /rel | Change set immediately | New set point | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r = reserved (not correspond) | | | | fr = fault reset | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| oms = operation mode specific (control mode based on bit) | | | | eo = enable operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| h = halt | | | | qs = quick stop | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | ev = enable voltage | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

7.1.4 Action description of PP control mode

The working principle diagram of object dictionary 0x607A, 0x6081, 0x6083 and 0x6084 is as follows:



The relative mode or absolute mode can be determined by bit6 (absolute / relative) of 6040h (control word).

Action 1: basic set-point

① Master station

After setting the value of 607Ah (target position), change the bit4 (new set-point) of 6040h (controlword) from 0 to 1. At this time, please also set 6081h (profile velocity). When 6081h (Profile velocity), the motor does not operate.

② Slave station

Confirm the rising edge (0 → 1) of bit4 (new set-point) of 6040h (controlword) and 607Ah (target position) as the target position to start the positioning action. At this time, the bit12 (set-point acknowledge) of 6041h (status word) changes from 0 to 1.


③ Master station

Confirm that bit12 (set-point acknowledge) of 6041h (statusword) has changed from 0 to 1, bit4 (new set-point) of 6040h (controlword) returns 0.

④ Slave station

Confirm that bit4 (new set-point) of 6040h (control word) is 0, bit12 (set-point acknowledge) of 6041h (status word) has changed to 0.

⑤ When reached target position, bit10 (target reached) of 6041h (Controlword) changes from 0 to 1.



< Set-point example >

Action 2: Action data change without buffer: single set-point

When bit5 (change set immediately) of 6040h (controlword) is 1, if the data used for positioning action in the action has been changed, interrupt the current positioning action and start the next positioning action immediately.

① Master station

Confirm that bit12 (set-point acknowledge) of 6041h (statusword) is 0. After changing the value of 607Ah (target position), change bit4 (new set-point) of 6040h (controlword) from 0 to 1.

Note: please do not change the acceleration and deceleration at this time.

② Slave station


Confirm that the rising edge of 6040h (Controlword) bit4 (new set-point) changes from 0 to 1, 607Ah (target position) and 6081h (profile velocity) are updated immediately as the new target position and the new internal execution speed. At this time, bit12 (set-point acknowledge) of 6041h (statusword) is changed from 0 to 1.

③ Master station

Confirm that bit12 (set-point acknowledge) of 6041h (statusword) has changed from 0 to 1. Bit4 (new set-point) of 6040h (controlword) returns 0.

④ Slave station

Confirm that bit4 (new set-point) of 6040h (Controlword) is 0, bit12 (set-point acknowledge) of 6041h (Statusword) is 0.



< handshaking procedure for the single set-point method >

7.1.5 Operation instance of pp mode

To realize the CANopen function of Xinje DS5N1 servo, Xinje XD-COBOX-ED module can be used as the master station of CANopen network (this module can also be used as a slave station of other master stations). When composing CANopen network, XD-COBOX-ED module needs to cooperate with XD5 / XDM / XD5E / XDME series PLC and connect with XD-COBOX-ED through the left expansion communication port (COM3) of PLC.

1. Wiring


When XD-COBOX-ED is connected to the CAN bus network, it adopts the linear topology structure. It only needs to connect CAN+ (CAN_H) to CAN+ (CAN_H) and CAN- (CAN_L) to CAN- (CAN_L) to establish communication, that is, the orange and white wire at one end of the network cable is connected to the CAN+ of XD-COBOX-ED module, the orange wire is connected to the CAN- of XD-COBOX-ED module, and the other end of the network cable is directly inserted into the IN port of servo. If the field has high requirements for the anti-interference ability of the bus, it needs to be connected to GND. The physical connection is shown in the figure.



In order to enhance the reliability of CAN communication and eliminate the reflection interference of CAN bus terminal signal, the two farthest endpoints of CAN bus network usually need to add terminal resistance. The value of the terminal resistance is determined by the characteristic impedance of the transmission cable. For example, if the characteristic impedance of the twisted pair is 120Ω , the farthest two terminals on the bus need to be installed with 120Ω terminal resistance. If the number of nodes is greater than 2, the intermediate node does not need to install terminal resistance. XD-COBOX-ED is equipped with a 120Ω terminal resistance dial switch (up is on and down is off). If other CANopen devices do not have their own terminal resistance, they need to be installed by the user. The CAN bus network supports up to 64 nodes, and the fastest communication speed can reach 1M. When 1M communication speed is adopted, the longest distance is 25m.



2. Station no. and baud rate settings



Knob switches 1 and 2 are used to set the node address (i.e. station number) of XD-COBOX-ED module in CANopen network.

- Setting range: 1 ~ 64 (0, 65 ~ 79 are not available).
- Knob switch 1: range 0 ~ 7, representing the high position of station number (decimal).
- Knob switch 2: range 0 ~ 9, representing the low position of station number (decimal).

Set parameter P7-30 through the servo software or panel to change the station number of servo in CANopen network. Setting range: 1 ~ 64.

For example: when the user wants to set the communication station number of XD-COBOX-ED module to 37, just turn knob switch 1 to 3, and then turn knob switch 2 to 7. To modify the servo slave station number to 15, modify the P7-30 parameter to 15 through the servo software or servo panel. (the station numbers of the two stations cannot be the same)

Note: after setting, the servo needs to be powered on again.

The dial switch is used to set the baud rate and the master/slave station, and the baud rate of the master/slave station shall be consistent.

- Dial switch 4 is set as master/slave station. On is the master station and off is the slave station.
- Dial switches 1 ~ 3 are used to set baud rate. See the following table for details:

| DIP1 | DIP2 | DIP3 | Communication speed/bps | Max communication distance |
|------|------|------|-------------------------|----------------------------|
| ON | ON | ON | 10K | 5000m |
| OFF | ON | ON | 20K | 2500m |
| ON | OFF | ON | 50K | 1000m |
| OFF | OFF | ON | 100K | 500m |
| ON | ON | OFF | 125K | 500m |
| OFF | ON | OFF | 250K | 250m |
| ON | OFF | OFF | 500K | 100m |
| OFF | OFF | OFF | 1000K | 25m |

Note: the dial switch is only effective when the module is powered off. After setting, power on the module.


For example: realize the CANopen function of the DS5N1 servo of Xinje, use the XD-COBOX-ED module of Xinje as the master station of the CANopen network, cooperate with the XDM series PLC of Xinje, and set the dial switch 4 to on. Set the P7-31 parameter through the upper computer or panel (or modify 271Fh through SDO read-write instruction) and set the DS5N1 servo baud rate to 500kbps, then the baud rate of the corresponding XD-COBOX-ED module should also be set to 500kbps (the baud rate of the master and slave station should be consistent), that is, set the dial switch 1 to on, 2 and 3 to off.

Under normal communication conditions, the COBOX indicator light should be PWR and RUN always on, ERR light is not on, and COM light is flashing. For specific instructions on the indicator light and dial switch, please refer to the user manual of XD series PLC left expansion module and CANopen communication user manual.


3. PP mode setting and control process

① click scan/add to add EDS file in CANopen configuration interface. Set the object binding of TxPDO and RxPDO. Here, some common objects in PP mode can be bound. If there are other requirements, you can add them yourself. After binding, you need to enable the configured PDO. The specific configuration is shown in the figure below.

TxPDO (monitor parameters):



RxPDO (control parameters):



② Download and activate the configurations. The slave station state machine automatically switches from PreOP to OP state. At this time, SDO and PDO can receive and send signals. XDPpro allows you to monitor or modify the mapping of the object dictionary. The specific correspondence is shown in the figure below.

| 寄存器 | 监控值 | 字长 | 进制 | 注释 |
|-------|-----|----|------|-----------------------------|
| D6256 | 0 | 单字 | 10进制 | control word |
| D6257 | 1 | 单字 | 10进制 | control mode |
| D6258 | 0 | 双字 | 10进制 | internal speed setting 6081 |
| D6260 | 0 | 双字 | 10进制 | acceleration 6083 |
| D6262 | 0 | 双字 | 10进制 | deceleration 6084 |
| D6264 | 0 | 双字 | 10进制 | target position |
| D6000 | 624 | 单字 | 10进制 | 6041 status word |
| D6001 | 1 | 单字 | 10进制 | 6061 mode inquire |
| D6002 | 0 | 双字 | 10进制 | 6064 position feedback |
| D6004 | -2 | 双字 | 10进制 | 606C speed feedback |

③ First set P0-00 to 1 to start the motion control function of CiA402, then modify D6257 to PP mode (6060h set to 1), modify D6256 (control word 6040h 0x06 → 0x07 → 0x0f / 0x4F) to enable the slave station, and modify the control word 0x4F → 0x5F to realize the relative position motion and 0x0F → 0x1F to realize the absolute position motion after giving the position, speed, acceleration and deceleration and other parameters by D6258-D6264. Other monitoring parameters are monitored by D6000-D6008.

7.2 PV mode

PV (profile speed control mode) is a speed control mode that specifies the target speed, acceleration and deceleration, and generates position command action in the servo driver.

7.2.1 Related parameters

PV control mode related objects (command · setting)

| Register | Note | Unit |
|---------------|-----------------------|------------------------------|
| RXPDO[0x6040] | Control word | - |
| RXPDO[0x6060] | Set to 3 | - |
| RXPDO[0x60FF] | Speed setting | Command unit/s |
| RXPDO[0x6072] | Max torque | 0.1% |
| RXPDO[0x607F] | Max internal speed | Command unit /s |
| RXPDO[0x6080] | Max motor speed | r/min |
| RXPDO[0x6083] | Internal acceleration | Command unit /s ² |
| RXPDO[0x6084] | Internal deceleration | Command unit /s ² |
| RXPDO[0x60C5] | Max acceleration | Command unit /s ² |
| RXPDO[0x60C6] | Max deceleration | Command unit /s ² |

PV control mode related objects (command · monitor)

| Register | Note | Unit |
|---------------|---|-----------------|
| TXPDO[0x6041] | Status word | - |
| TXPDO[0x6061] | Mode inquires | - |
| TXPDO[0x6063] | Internal actual position | Command unit |
| TXPDO[0x6064] | Position feedback (motor actual position) | Command unit |
| TXPDO[0x606C] | Speed feedback | Command unit /s |
| TXPDO[0x6077] | Actual torque | 0.1% |

7.2.2 Control word (6040h) < pv control mode function >

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|-----------|------------------|---------|-----------------------|--------|-------|---------|----|----|----|----|----|----|---|---|---|--|--|--|--|--|--|---|---|---|---|---|---|---|---|---|----|-----|--|--|----|----|----|----|---|---|---|
| 6040h | 00h | Controlword | 0~65535 | U16 | rw | RxPDO | All | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Set the control command of servo driver such as PDS state conversion. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Bit information | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>15</th><th>14</th><th>13</th><th>12</th><th>11</th><th>10</th><th>9</th><th>8</th> </tr> </thead> <tbody> <tr> <td colspan="7" style="text-align: center;">r</td><td style="text-align: center;">h</td> </tr> <tr> <th>7</th><th>6</th><th>5</th><th>4</th><th>3</th><th>2</th><th>1</th><th>0</th> </tr> <tr> <td rowspan="2" style="text-align: center;">fr</td><td colspan="3" style="text-align: center;">oms</td><td rowspan="2" style="text-align: center;">eo</td><td rowspan="2" style="text-align: center;">qs</td><td rowspan="2" style="text-align: center;">ev</td><td rowspan="2" style="text-align: center;">so</td> </tr> <tr> <td style="text-align: center;">r</td><td style="text-align: center;">r</td><td style="text-align: center;">r</td> </tr> </tbody> </table> | | | | | | | | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | r | | | | | | | h | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | fr | oms | | | eo | qs | ev | so | r | r | r |
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r | | | | | | | h | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| fr | oms | | | eo | qs | ev | so | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | r | r | r | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r = reserved (not correspond) | | | | fr = fault reset | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| oms = operation mode specific (control mode based on bit) | | | | eo = enable operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| h = halt | | | | qs = quick stop | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | ev = enable voltage | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | so = switch on | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

PV mode, not use oms bit.

7.2.3 Control word (6041h) < pv control mode function >

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|-----------|------------------|---------|----------------|--------|-------|---------|----|----|----|----|----|----|---|---|---|-----|--|-----|--|-----|----|---|--|--|---|---|----------------|--|--|--|---|---|---|---|---|---|---|---|---|-----|----|----|---|----|----|------|
| 6041h | 00h | Statusword | 0~65535 | U16 | ro | TxPDO | All | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>Indicates the status of the servo drive.</p> <p>Bit information</p> <table border="1"> <thead> <tr> <th>15</th> <th>14</th> <th>13</th> <th>12</th> <th>11</th> <th>10</th> <th>9</th> <th>8</th> </tr> </thead> <tbody> <tr> <td>r</td> <td colspan="2">oms</td> <td colspan="2">ila</td> <td>oms</td> <td>rm</td> <td>r</td> </tr> <tr> <td colspan="2"></td> <td>r</td> <td>r</td> <td colspan="2">Target reached</td> <td colspan="2"></td> </tr> <tr> <th>7</th> <th>6</th> <th>5</th> <th>4</th> <th>3</th> <th>2</th> <th>1</th> <th>0</th> </tr> <tr> <td>w</td> <td>sod</td> <td>qs</td> <td>ve</td> <td>f</td> <td>oe</td> <td>so</td> <td>rsto</td> </tr> </tbody> </table> <p>r = reserved (not correspond) w = warning sod = switch on disabled oms = operation mode specific qs = quick stop (control mode based on bit) ve = voltage enabled ila = internal limit active f = faultoe = operation enabled rm = remote so = switched on rsto = ready to switch on</p> | | | | | | | | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | r | oms | | ila | | oms | rm | r | | | r | r | Target reached | | | | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | w | sod | qs | ve | f | oe | so | rsto |
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r | oms | | ila | | oms | rm | r | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | r | r | Target reached | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| w | sod | qs | ve | f | oe | so | rsto | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

bit10 (target reached (Velocity reached)):

The difference between the total value of 60FFh (target velocity) and 60B1h (velocity offset) and 606Ch (velocity actual value) is within the range set by 606Dh (velocity window). If the time set by 606Eh (velocity window time) passes, the bit10 of 6041h (status word) becomes 1.

| Bit | Name | Value | Definition |
|-----|----------------|-------|--|
| 10 | Target reached | 0 | halt=0 (general): Speed control not completed halt=1 (when stop according to halt): the shaft is decelerating |
| | | 1 | halt=0 (general): speed control completed halt=1 (when stop according to halt): shaft stop (shaft speed is 0) |


7.2.4 pv control mode action description

The PV control mode generates speed commands based on the following parameters:

Target Velocity (60FFh) Profile acceleration (6083h)

Profile deceleration (6084h)

Turn off the motor enable, set the target word 6060h to 3, set the target speed 60FFh, acceleration and deceleration 6083h and 6084h, speed 6080h and torque limit 6072h. The target speed is 60FFh. The maximum speed is limited by 6080h (max motor speed) and the torque is limited by 6072h (max torque). When the motor is enabled, the motor shall start to act according to the set value.




7.2.5 PV mode operation instance


1. The wiring please refer to chapter 3-1-5.
2. Station no. and baud rate please refer to chapter 3-1-5.
3. PV mode configuration and control process

① click scan/add to add EDS file in the CANopen configuration interface. Configure the object binding of TxPDO and RxPDO. Here, some common objects of PV mode can be bound. If there are other requirements, you can add them yourself. After binding, you need to enable the configured PDO. The specific configuration is shown in the figure below.

TxPDO (monitor parameters):



RxPDO (control parameters)



② Download and activate the configurations. The slave station state machine automatically switches from PreOP to OP state. At this time, SDO and PDO can receive and send signals. The mapping of object dictionary can be monitored or modified through XDPpro. The specific correspondence is shown in the figure below.

| 寄存器 | 监控值 | 字长 | 进制 | 注释 |
|-------|-----|----|------|------------------------|
| D6256 | 0 | 单字 | 10进制 | control word |
| D6257 | 1 | 单字 | 10进制 | control mode |
| D6258 | 0 | 双字 | 10进制 | speed setting 60FF |
| D6260 | 0 | 双字 | 10进制 | acceleration 6083 |
| D6262 | 0 | 双字 | 10进制 | deceleration 6084 |
| D6264 | 0 | 双字 | 10进制 | deceleration stop 6085 |
| D6000 | 624 | 单字 | 10进制 | 6041 status word |
| D6001 | 1 | 单字 | 10进制 | 6061 mode inquires |
| D6002 | 0 | 双字 | 10进制 | 6064 position feedback |
| D6004 | -4 | 双字 | 10进制 | 606C speed feedback |
| | | | | |

③ First set P0-00 to 1 to start the motion control function of CiA402, then set D6257 to PV mode (set 6060h to 3), set the speed, acceleration and deceleration parameters through D6258 (60FFh) and so on, and then modify D6256 (control word 6040h 0x06 → 0x07 → 0x0F) to enable the slave station and start the speed mode. Other monitoring parameters are monitored by D6000-D6008.

7.3 TQ mode

TQ (profile torque control mode) is a torque control mode that specifies the target torque, acceleration and deceleration, and acts after generating position commands in the servo driver.

7.3.1 Related parameters

TQ control mode related object (command · setting)

| Register | Explanation | Unit |
|---------------|-----------------------|--------|
| RXPDO[0x6040] | Control word | - |
| RXPDO[0x6060] | Set to 4 | - |
| RXPDO[0x6071] | Target torque setting | 0.1% |
| RXPDO[0x6072] | Max torque | 0.1% |
| RXPDO[0x6080] | Max motor speed | r/min |
| RXPDO[0x6087] | Set the torque slope | 0.1%/S |

Torque type

| Index | Sub-index | Name | Units | Range | Datatype | Access | PDO | OP-mode |
|-------|-----------|---|-------|--------------|----------|--------|-------|-----------|
| 6087h | 00h | Torque slope | 0.1 % | 0~4294967295 | U32 | rw | RxPDO | tq cst |
| | | Set the parameter value to give the tendency torque command. If set to 0, the internal processing operates with 1. | | | | | | |

TQ control mode related object (command · monitor)

| Register | Explanation | Unit |
|---------------|---|-----------------|
| TXPDO[0x6041] | Status word | - |
| TXPDO[0x6061] | Mode inquires | - |
| TXPDO[0x6064] | Position feedback (motor actual position) | Command unit |
| TXPDO[0x606C] | Speed feedback | Command unit /s |
| TXPDO[0x6077] | Actual torque | 0.1% |

7.3.2 Control word (6040h) < tq control mode function >

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode | | |
|-------|-----------|---|---------|----------|--------|-----------------------|---------|----|----|
| 6040h | 00h | Controlword | 0~65535 | U16 | rw | RxPDO | All | | |
| | | Set the control command of servo driver such as PDS state conversion. | | | | | | | |
| | | Bit information | | | | | | | |
| | | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 |
| | | r | | | | | | | h |
| | | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| | | fr | oms | | | eo | qs | ev | so |
| | | | r | r | r | | | | |
| | | r = reserved (not correspond) | | | | fr = fault reset | | | |
| | | oms = operation mode specific (control mode based on bit) | | | | eo = enable operation | | | |
| | | h = halt | | | | qs = quick stop | | | |
| | | | | | | ev = enable voltage | | | |
| | | | | | | so = switch on | | | |

TQ mode, not use oms bit.

7.3.5 TQ mode operation instance

1. Wiring

Refer to chapter 3-1-5.


2. Baud rate and station no.

Refer to chapter 3-1-5.


3. TQ mode configuration and control process.

① Click [scan] or [add slave] in CANopen configuration interface to add corresponding EDS files, and configure the object binding of TxPDO and RxPDO. Here, some common objects in TQ mode can be bound. If there are other requirements, you can add them yourself. After binding, you need to enable the configured PDO. Some SDO data can be read or written through SDO configuration tool or SDO read-write instruction. The specific configuration is shown in the figure below.

TxPDO (monitor parameters):



RxPDO (control parameters):



② Download the activation configuration, and the slave state machine will automatically switch from PreOP to OP state. At this time, SDO and PDO can receive and send signals. The mapping of object dictionary can be monitored or modified through XDPpro software. The specific correspondence is shown in the figure below.

| 寄存器 | 监控值 | 字长 | 进制 | 注释 |
|-------|-----|----|------|------------------------|
| D6256 | 0 | 单字 | 10进制 | control word |
| D6257 | 1 | 单字 | 10进制 | control mode |
| D6258 | 0 | 双字 | 10进制 | torque acc/dec |
| D6260 | 0 | 单字 | 10进制 | given torque |
| D6000 | 624 | 单字 | 10进制 | 6041 status word |
| D6001 | 1 | 单字 | 10进制 | 6061 mode inquires |
| D6002 | 0 | 双字 | 10进制 | 6064 position feedback |
| D6004 | -2 | 双字 | 10进制 | 606C speed feedback |
| D6006 | 0 | 单字 | 10进制 | actual torque |

③ First set P0-00 to 1 to start the motion control function of CiA402, and then set D6257 (6060h is 4) to TQ mode. After setting torque and torque slope parameters through D6258 (6071h) and so on, modify D6256 (control word 6040h is 0x06 → 0x07 → 0x0F) to enable the slave station and start the torque mode. Other monitoring parameters are monitored by D6000-D6008.

7.4 HM mode

HM mode (i.e. homing mode) is a position control mode that specifies various action speeds, generates position instructions inside the servo driver and performs homing action. In this mode, external signals (POT, NOT, SPD-D) must be used together. If the external signal is not configured correctly, it may lead to partial homing mode failure of normal operation.

7.4.1 Related parameters

HM control mode related object (command · setting)

| Register | Note |
|---------------|---|
| RXPDO[0x6040] | Control word, turn on the homing function by modifying the control word |
| RXPDO[0x6060] | Set to 6 when the motor is not enabled |
| RXPDO[0x607F] | Maximum internal speed |
| RXPDO[0x6080] | Maximum motor speed |
| RXPDO[0x60C5] | Maximum acceleration |
| RXPDO[0x60C6] | Maximum deceleration |
| RXPDO[0x6098] | Homing mode |
| RXPDO[0x6099] | Homing speed |
| RXPDO[0x609A] | Homing acceleration |

PV control mode related object (command · monitor)

| Register | Note |
|---------------|---|
| TXPDO[0x6041] | Status word |
| TXPDO[0x6061] | Mode inquires |
| TXPDO[0x6064] | Position feedback (motor actual position) |
| TXPDO[0x606C] | Speed feedback |
| TXPDO[0x6077] | Actual torque |

7.4.2 Control word (6040h) < hm control mode function >

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|-----------|------------------|---------|----------|--------|-------|---------|----|----|----|----|----|----|---|---|---|--|--|--|--|--|--|---|---|---|---|---|---|---|---|---|----|-----|--|--|----|----|----|----|--|---|---|----|--|--|--|--|
| 6040h | 00h | Controlword | 0~65535 | U16 | rw | RxPDO | All | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Set the control command of servo driver such as PDS state conversion. Bit information <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>15</th><th>14</th><th>13</th><th>12</th><th>11</th><th>10</th><th>9</th><th>8</th></tr> </thead> <tbody> <tr> <td colspan="7">r</td> <td>h</td> </tr> <tr> <th>7</th><th>6</th><th>5</th><th>4</th><th>3</th><th>2</th><th>1</th><th>0</th></tr> <tr> <td>fr</td><td colspan="3">oms</td><td>eo</td><td>qs</td><td>ev</td><td>so</td></tr> <tr> <td></td><td>r</td><td>r</td><td>sh</td><td></td><td></td><td></td><td></td></tr> </tbody> </table> <p> r = reserved (not correspond) fr = fault reset oms = operation mode specific eo = enable operation (control mode based on bit) qs = quick stop h = halt ev = enable voltage sh = start homing so = switch on </p> | | | | | | | | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | r | | | | | | | h | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | fr | oms | | | eo | qs | ev | so | | r | r | sh | | | | |
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r | | | | | | | h | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| fr | oms | | | eo | qs | ev | so | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | r | r | sh | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

bit6-4 (operation mode specific):

| Bit | Name | Value | Definition |
|-----|--------------|-------|---------------------|
| 4 | start homing | 0→1 | Start homing action |
| 5 | reserved | - | Invalid information |
| 6 | reserved | - | Invalid information |

7.4.3 Status word (6041h) < hm control mode function >

| Index | Sub-Index | Name/Description | Range | DateType | Access | PDO | Op-mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|-----------|------------------|---------|----------|----------------|-------|---------|----|----|----|----|----|----|---|---|---|--|-----|--|-----|-----|--|----|---|--|--|---|---|--|----------------|--|--|--|---|---|---|---|---|---|---|---|---|-----|----|----|---|----|----|------|
| 6041h | 00h | Statusword | 0~65535 | U16 | ro | TxPDO | All | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Indicates the status of the servo drive. Bit information <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>15</th><th>14</th><th>13</th><th>12</th><th>11</th><th>10</th><th>9</th><th>8</th></tr> </thead> <tbody> <tr> <td colspan="2">r</td><td colspan="2">oms</td><td>ila</td><td colspan="2">oms</td><td>rm</td><td>r</td></tr> <tr> <td colspan="2"></td><td>r</td><td>r</td><td></td><td colspan="2">Target reached</td><td></td><td></td></tr> <tr> <th>7</th><th>6</th><th>5</th><th>4</th><th>3</th><th>2</th><th>1</th><th>0</th></tr> <tr> <td>w</td><td>sod</td><td>qs</td><td>ve</td><td>f</td><td>oe</td><td>so</td><td>rsto</td></tr> </tbody> </table> <p> r = reserved (not correspond) w = warning oms = operation mode specific sod = switch on disabled (control mode based on bit) qs = quick stop ila = internal limit active ve = voltage enabled f = fault rm = remote oe = operation enabled so = switched on rtso = ready to switch on </p> | | | | | | | | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | r | | oms | | ila | oms | | rm | r | | | r | r | | Target reached | | | | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | w | sod | qs | ve | f | oe | so | rsto |
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| r | | oms | | ila | oms | | rm | r | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | r | r | | Target reached | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| w | sod | qs | ve | f | oe | so | rsto | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

bit10, 12-13 (operation mode specific):

| Bit | Name | Value | Definition |
|-----|-----------------|-------|-------------------------------------|
| 10 | target reached | 0 | Homing action in progress |
| | | 1 | Homing action has been completed |
| 12 | homing attained | 0 | Homing action not completed |
| | | 1 | Homing action is completed normally |
| 13 | homing error | 0 | Homing action is not abnormal |
| | | 1 | Homing action is abnormal |

The homing action has the following states:

| Bit13 | Bit12 | Bit10 | Definition |
|-------|-------|-------|--|
| 0 | 0 | 0 | Homing action in progress |
| 0 | 0 | 1 | The homing action has not started, or the homing action is interrupted |
| 0 | 1 | 0 | The homing action has been completed, but the target position has |


| | | | |
|---|---|---|---|
| | | | not been reached |
| 0 | 1 | 1 | The homing action has been completed and successfully reached the target position |
| 1 | 0 | 0 | Abnormal homing action is detected and it is still operating |
| 1 | 0 | 1 | It is detected that the homing action is abnormal and has stopped |

7.4.4 Homing mode (6098h)

1-14, 17~30, 33, 34, 35, 37. At present, DS5N1 series servo supports the homing mode of 1-14, 17 ~ 30, 33, 34, 35 and 37.


■ Mode 1:

When using homing mode 1, if the reverse limit switch is in the non triggered state, the initial moving direction is left. The origin position is at the first z-phase pulse on the right of the position where the negative limit switch becomes invalid.




■ Mode 2:

When using homing mode 2, if the forward limit switch is not triggered, the initial moving direction is right. The origin position is at the first z-phase pulse on the left of the position where the positive limit switch becomes invalid.




■ Mode 3, 4:

When using homing mode 3 or 4, the initial direction of movement depends on the status of the origin switch. The origin position is on the reverse side of the origin switch or on the initially detected z-phase position in the forward direction.



■ Mode 5, 6:

When using homing mode 5 or 6, the initial direction of movement depends on the status of the origin switch. The origin position is on the reverse side of the origin switch or on the initially detected z-phase position in the forward direction.



■ Mode 7~14:

Mode 7~14 all use origin switch and z-phase signal.



Mode 7, 8 initial direction: if origin switch has been activated when action starts, it is negative direction.

Mode 9, 10 initial direction: if origin switch has been activated when action starts, it is positive direction.

Mode 11, 12 initial direction: if origin switch has been activated when action starts, it is positive direction.

Mode 13, 14 initial direction: if origin switch has been activated when action starts, it is negative direction.

The position of the final return to the origin is the z-phase signal near the rising or falling edge of the origin switch.




■ Mode 17

Mode 7 is similar to Mode 1.

The difference is that the origin detection position is not the Index pulse, but the position where the Limit switch changes. (please refer to the figure below)

When NOT is not distributed, Homing error = 1.




■ Mode 18

Mode 8 is similar to Mode 2.

The difference is that the origin detection position is not the Index pulse, but the position where the Limit switch changes. (please refer to the figure below)

When POT is not distributed, Homing error = 1.




■ Mode 19, 20

Mode 19, 20 are similar to Mode 3, 4.

The difference is that the origin detection position is not the Index pulse, but the position where the Home switch changes. (please refer to the figure below)

When HOME is not distributed, Homing error = 1.




■ Mode 21, 22

Mode 21, 22 are similar to Mode 5, 6.

The difference is that the origin detection position is not the Index pulse, but the position where the Home switch changes. (please refer to the figure below)

When HOME is not distributed, Homing error = 1.




■ Mode 23, 24, 25, 26

Mode 23, 24, 25, 26 are similar to Mode 7, 8, 9, 10.

The difference is that the origin detection position is not the Index pulse, but the position where the Home switch changes. (please refer to the figure below)

When HOME, POT are not distributed, Homing error = 1.




■ Mode 27, 28, 29, 30

Mode 27, 28, 29, 30 are similar to Mode 11, 12, 13, 14.


The difference is that the origin detection position is not the Index pulse, but the position where the Home switch changes. (please refer to the figure below)

When HOME, NOT are not distributed, Homing error = 1.




■ Mode 33, 34:

When using mode 33 or 34, the return to origin direction is negative or positive, respectively. The original position is located at the Z phase near the selected direction.



■ Mode 35, 37

In mode 35 and 37, the position after power on is the origin position.



7.4.5 HM mode operation instance

1. Wiring

Refer to chapter 3-1-5.

2. Station no. and baud rate


Refer to chapter 3-1-5.

3. HM configuration and control process.


① Carry out terminal assignment. Modify P5-22, P5-23, P5-27 through upper computer or configure the P-OT, N-OT, SPD-D signal for the index 2516, 2517, 251B through SDO read write command. If not assigned correctly, then homing error = 1.

② Click [scan] or [add slave] in CANopen configuration interface to add corresponding EDS files, and configure the object binding of TxPDO and RxPDO. Here, some common objects in HM mode can be bound. If there are other requirements, you can add them yourself. After binding, you need to enable the configured PDO. The specific configuration is shown in the figure below.

TxPDO (monitor type parameters):



RxPDO (control type parameters):



③ Download and activate the configuration, and the slave state machine will automatically switch from PreOP to OP state. At this time, SDO and PDO can receive and send data. The mapping of the object dictionary can be monitored or modified through XDPpro software. The specific correspondence is shown in the figure below.

| 寄存器 | 监控值 | 字长 | 进制 | 注释 |
|-------|-----|----|------|--------------------------|
| D6256 | 0 | 单字 | 10进制 | control word |
| D6257 | 0 | 单字 | 10进制 | control mode |
| D6258 | 0 | 双字 | 10进制 | homing speed |
| D6260 | 0 | 双字 | 10进制 | creep speed |
| D6262 | 0 | 双字 | 10进制 | homing acceleration 609A |
| D6264 | 0 | 双字 | 10进制 | homing mode |
| D6000 | 624 | 单字 | 10进制 | status word 6041 |
| D6001 | 1 | 单字 | 10进制 | mode feedback 6061 |
| D6002 | 0 | 双字 | 10进制 | position feedback 6064 |
| D6004 | 1 | 双字 | 10进制 | speed feedback 606C |
| | | | | |


④ First set P0-00 to 1 to start the motion control function of CiA402, then set D6257 to HM mode (set 6060h to 6), set the homing mode through D6258 (6098h), and set the homing speed through D6259-D6263 (6099h, 609Ah). Modify D6256 (control word 6040h is 0x06 → 0x07 → 0x0F) to enable the slave station, and then modify D6256 (control word 6040h is 0x0F → 0x1F) to start the homing mode. Other monitoring parameters are monitored by D6000-D6011. In the homing process, if the origin signal is triggered, it will slow down and stop according to the corresponding homing mode. If you need to homing again, first change 6040h to 0x06h, and then repeat the above operation.

8 Servo gain adjustment

8.1 Overview of servo gain adjustment

8.1.1 Overview and process

The servo driver needs to drive the motor as fast and accurately as possible to track the instructions from the upper computer or internal settings. In order to meet this requirement, the servo gain must be adjusted reasonably. Servo gain factory value is adaptive mode, but different machines have different requirements for servo responsiveness; the following figure is the basic process of gain adjustment, please adjust according to the current machine status and operation conditions.



8.1.2 The difference of these adjustment modes

Adjustment modes are divided into adaptive and auto-tuning, and their control algorithms and parameters are independent. Among them, the auto-tuning mode is divided into three functions: fast adjustment, automatic adjustment and manual adjustment. The three functions are the same in essence but different in implementation. Refer to the corresponding chapters of each function.

| Mode | Type | Parameters | Rigidity | Responsiveness | Related parameters |
|-------------|----------------------|------------|----------|--------------------------|--|
| Adaptive | Automatic adaptation | P2-01.0=1 | middle | 150ms | P2-05 adaptive speed loop gain P2-10 adaptive speed loop integral P2-11 adaptive position loop gain P2-07 adaptive inertia ratio P2-08 adaptive speed observer gain P2-12 adaptive stable max inertia ratio |
| Auto-tuning | Fast adjusting | P2-01.0=0 | high | 10~50ms | P0-07 first inertia ratio P1-00 speed loop gain P1-01 speed loop integral P1-02 position loop gain P2-35 Torque instruction filtering time constant 1 P2-49 Model loop gain |
| | Automatic adjustment | | high | 10ms | |
| | Manual adjusting | | high | Determined by parameters | |

8.2 Rotary inertia presumption

8.2.1 Overview

Rotational inertia estimation is the function of automatic operation (forward and reverse) in the driver and estimate the load inertia in operation.

Rotational inertia ratio (the ratio of load inertia to motor rotor inertia) is a benchmark parameter for gain adjustment, and it must be set to the correct value as far as possible.

| Parameter | Meaning | Default setting | Unit | Setting range | Modification | Effective |
|-----------|---------------------|-----------------|------|---------------|--------------|-----------|
| P0-07 | First inertia ratio | 500 | % | 0~50000 | Anytime | At once |

8.2.2 Notes

Occasions where inertia cannot be presumed

- ◆ Mechanical systems can only operate in one direction

The occasion where inertia presumption is easy to fail

- ◆ Excessive load moment of inertia
- ◆ The running range is narrow and the travel is less than 0.5 circles.
- ◆ The moment of inertia varies greatly during operation.
- ◆ Mechanical rigidity is low and vibration occurs when inertia is presumed.

Notes of Inertia Presumption

- ◆ Since both directions are rotatable within the set range of movement, please confirm the range or direction of movement; and ensure that the load runs in a safe journey.
- ◆ If the presumed inertia under default parameters runs jitter, indicating that the present load inertia is too large, please switch to large inertia mode (P2-03.3=1) and operate again. It is also possible to set the initial inertia to about twice the current one and execute again under larger loads.

- ◆ Driver inertia ratio recognition upper limit is 500 times (parameter upper limit is 50000). If the estimated inertia ratio is exactly 50000, it means that the inertia ratio has reached the upper limit and can not be used, please replace the motor with larger rotor inertia.

8.2.3 Operation tool

The tools that can estimate the moment of inertia of the load include the driver panel and xinjeservo software.

8.2.4 Operation steps

Estimate the inertia through the driver panel

1. Parameter setting

| Parameter | Meaning | Default setting | Unit | Range | Modification | Effective |
|-----------|---|-----------------|-------------|---------|--------------|-----------|
| P2-15 | Inertia configured trip | 100 | 0.01 circle | 1~3000 | Anytime | At once |
| P2-17 | Inertia identification and internal instruction auto-tuning max speed | - | rpm | 0~65535 | Anytime | At once |
| P2-18 | Inertia identification initial inertia ratio | 500 | % | 1~20000 | Anytime | At once |


The recommended parameters of P2-17 are 500 rpm or more. Low instruction speed will lead to inaccurate identification of inertia ratio.

2. Execute the inertia identification


Before inertia identification, please confirm the direction of servo rotation by using F1-00 jog motion function. Initial direction of servo operation is determined by INC or DEC at the beginning of inertia identification.

If the servo jitter is under the adaptive default parameters, please switch to the adaptive large inertia mode (P2-03.3=1) to ensure the basic smooth operation of the servo and then identify the inertia!

Servo entering parameter F0-07 in BB state:



Press ENTER, servo is enabled:



Press INC or DEC to run forward or reverse (select one of them):




At this point, start action, under the condition of P-05 = 0 (initial positive direction), if press INC, then turn forward and then reverse; if press DEC, turn reverse and then forward. If the inertia identification is successful, the load inertia ratio is prompted and written to P0-07 automatically after several forward and reverse operations. If the inertia identification error occurs, the error code will be displayed. Press STA/ESC key to exit the panel inertia identification operation.

■ Alarm for inertia identification of panel


| Error code | Meaning | Reasons and solutions | Reasons |
|------------|---|---|---|
| Err-1 | Motor Torque Saturation | <p>① Initial inertia is too small; in adaptive mode, switch to large inertia mode P2-03.3=1 or the initial inertia of inertia identification P2-18 set to 2 times of the present value.</p> <p>② The maximum speed is too high (P2-17), but it is recommended not to be less than 500 rpm. Low instruction speed will lead to inaccurate identification of inertia ratio.</p> <p>③ torque limit too small (P3-28/29)</p> | Initial inertia too small; Maximum speed too large; Torque limit too small |
| Err-2 | value error is too large when calculating the inertia | <p>① The maximum speed limit is too small (P2-17), but it is recommended not to be less than 500 rpm. Low instruction speed will lead to inaccurate identification of inertia ratio.</p> <p>② The presumed inertia trip is too small. It is suggested that the minimum for P2-15 should no be less than 50 (0.5 cycles). If the trip is too small, the identification of inertia ratio will be inaccurate.</p> <p>③ mechanism friction too large</p> <p>④ overshoot</p> | The maximum speed limit is too small; the travel is too small; the friction of the mechanism is too large; the overrun occurs |
| Err-3 | Driver internal trip calculation error | ① The presumed inertia trip is too small. It is suggested that the minimum for P2-15 should no be less than 50 (0.5 cycles). If the trip is too small, the identification of inertia ratio will be inaccurate. | Contact us |
| Err-5 | Unrestrained Vibration in the Process of Inertia Identification | Unhandled vibration occurs | Unhandled vibration occurs |
| Err-6 | Driver is not currently in BB state | <p>① Enable have been opened. P5-20 can be set to 0 first</p> <p>② When the driver alarms, it will appear. Press ESC key to exit the auto-tuning interface to see if there is an alarm.</p> | Will occur when enable is turned on or driver has alarm |
| Err-7 | The driver alarms in the process of inertia identification | Driver has alarm, press ESC key to exit the auto-tuning interface, check the alarm code, first solve the alarm and then make inertia estimation. | Driver has alarm |

Estimate the inertia through XinJeServo software


1. Click auto-tuning on the main interface of XinJeServo




- select jog setting or manual setting to configure the inertia estimation trip



- Set the auto-tuning interface



4. Click ok to start inertia identification.



Note:

- (1) If the auto-tuning interface is closed directly, the driver only configures inertia ratio parameters.
- (2) The detailed steps of XinJeServo's presumptive inertia refer to XinJeServo's help document.

8.3 Fast adjustment

8.3.1 Overview

Fast adjustment needs to set the moment of inertia of load first, then turn off the adaptive function. If the inertia does not match, it will cause oscillation alarm. Servo firmware version 3640 and later versions support this function, and the version is viewed through U2-07. Fast adjustment of gain parameters belongs to auto-tuning mode.

8.3.2 Fast adjustment steps

1. estimate the load inertia through servo driver panel or XinJeServo software, refer to chapter 8.2
2. shut down adaptive mode, set P2-01.0 to 0
3. set the rigidity level P0-04

Note: P2-01.0 is the first bit of P2-01

P2-01=n. 0 0 1 0



8.3.3 Rigidity level corresponding gain parameters

- 3770 and later firmware

| P0-04 Rigidity level | P1-00 Speed loop gain | P1-01 speed loop integral | P1-02 Position loop gain | P2-35 Torque instruction filter | P2-49 (3700~3720) Model loop gain | P2-49 (3730 and later) Model loop gain |
|----------------------------|-----------------------------|---------------------------------|--------------------------------|--|--|--|
| 1 | 20 | 31831 | 20 | 100 | 50 | 50 |
| 2 | 50 | 12732 | 50 | 100 | 80 | 80 |
| 3 | 70 | 9094 | 70 | 100 | 90 | 90 |
| 4 | 80 | 7957 | 80 | 100 | 100 | 100 |
| 5 | 100 | 6366 | 100 | 100 | 100 | 120 |
| 6 | 120 | 5305 | 120 | 100 | 150 | 150 |
| 7 | 140 | 4547 | 140 | 100 | 150 | 200 |
| 8 | 160 | 3978 | 160 | 100 | 200 | 250 |
| 9 | 180 | 3536 | 180 | 100 | 250 | 310 |
| 10 | 200 | 3183 | 200 | 100 | 300 | 350 |
| 11 | 220 | 2893 | 220 | 100 | 300 | 380 |
| 12 | 240 | 2652 | 240 | 100 | 350 | 410 |
| 13 | 260 | 2448 | 260 | 100 | 350 | 440 |
| 14 | 280 | 2273 | 280 | 100 | 350 | 470 |
| 15 | 300 | 2122 | 300 | 100 | 400 | 500 |
| 16 | 320 | 1989 | 320 | 100 | 400 | 540 |
| 17 | 340 | 1872 | 340 | 100 | 400 | 580 |
| 18 | 360 | 1768 | 360 | 100 | 450 | 620 |
| 19 | 380 | 1675 | 380 | 100 | 450 | 660 |
| 20 | 400 | 1591 | 400 | 100 | 500 | 700 |
| 21 | 450 | 1414 | 400 | 90 | 600 | 800 |
| 22 | 500 | 1273 | 450 | 80 | 700 | 950 |
| 23 | 550 | 1157 | 450 | 70 | 800 | 1100 |
| 24 | 600 | 1061 | 500 | 60 | 900 | 1300 |
| 25 | 650 | 979 | 550 | 50 | 1000 | 1500 |
| 26 | 700 | 909 | 600 | 40 | 1100 | 1800 |
| 27 | 750 | 848 | 650 | 30 | 1200 | 2100 |
| 28 | 800 | 795 | 700 | 20 | 1300 | 2400 |
| 29 | 850 | 748 | 750 | 10 | 1400 | 2700 |
| 30 | 900 | 707 | 800 | 10 | 1500 | 3000 |
| 31 | 950 | 670 | 900 | 10 | 1500 | 3100 |
| 32 | 1000 | 636 | 900 | 10 | 1600 | 3200 |
| 33 | 1050 | 606 | 950 | 10 | 1800 | 3300 |

| P0-04 Rigidity level | P1-00 Speed loop gain | P1-01 speed loop integral | P1-02 Position loop gain | P2-35 Torque instruction filter | P2-49 (3700~3720) Model loop gain | P2-49 (3730 and later) Model loop gain |
|----------------------------|-----------------------------|---------------------------------|--------------------------------|--|--|--|
| 34 | 1100 | 578 | 1000 | 10 | 2000 | 3400 |
| 35 | 1150 | 553 | 1050 | 10 | 2200 | 3500 |
| 36 | 1200 | 530 | 1100 | 10 | 2400 | 3600 |
| 37 | 1250 | 509 | 1100 | 10 | 2500 | 3700 |
| 38 | 1300 | 489 | 1100 | 10 | 2600 | 3800 |
| 39 | 1350 | 471 | 1200 | 10 | 2700 | 3900 |
| 40 | 1400 | 454 | 1200 | 10 | 2800 | 4000 |
| 41 | 1450 | 439 | 1250 | 10 | 2900 | 4100 |
| 42 | 1500 | 424 | 1300 | 10 | 3000 | 4200 |
| 43 | 1550 | 410 | 1350 | 10 | 3200 | 4300 |
| 44 | 1600 | 397 | 1400 | 10 | 3500 | 4400 |
| 45 | 1650 | 385 | 1450 | 10 | 3800 | 4500 |
| 46 | 1700 | 374 | 1500 | 10 | 4000 | 4600 |
| 47 | 1750 | 363 | 1750 | 10 | 4500 | 4800 |
| 48 | 1800 | 353 | 1800 | 10 | 5000 | 5000 |
| 49 | 1850 | 344 | 1850 | 10 | 5000 | 5000 |
| 50 | 1900 | 335 | 1900 | 10 | 5000 | 5000 |
| 51 | 1950 | 326 | 1950 | 10 | 5000 | 5000 |
| 52 | 2000 | 318 | 2000 | 10 | 5000 | 5000 |
| 53 | 2050 | 310 | 2050 | 10 | 6000 | 6000 |
| 54 | 2100 | 303 | 2100 | 10 | 6000 | 6000 |
| 55 | 2150 | 296 | 2150 | 10 | 6000 | 6000 |
| 56 | 2200 | 289 | 2200 | 10 | 6000 | 6000 |
| 57 | 2250 | 282 | 2250 | 10 | 6000 | 6000 |
| 58 | 2300 | 276 | 2300 | 10 | 6000 | 6000 |
| 59 | 2350 | 270 | 2350 | 10 | 6000 | 6000 |
| 60 | 2400 | 265 | 2400 | 10 | 6000 | 6000 |
| 61 | 2450 | 259 | 2450 | 10 | 6000 | 6000 |
| 62 | 2500 | 254 | 2500 | 10 | 6000 | 6000 |
| 63 | 2600 | 244 | 2600 | 10 | 6000 | 6000 |

The rigidity level should be set according to the actual load. The larger the P-04 value, the greater the servo gain. If there is vibration in the process of increasing the rigidity level, it is not suitable to continue to increase. If vibration suppression is used to eliminate vibration, it can try to continue to increase. The following is the recommended rigidity level of the load, for reference only.



Flexible structure large load: refers to the type of synchronous belt structure, large load inertia equipment.

High rigid load: refers to the mechanism of screw rod or direct connection, and equipment with strong mechanical rigidity.

Ultra-high response load under light load: refers to equipment with very small inertia, strong mechanical stiffness and high response.

| Driver power | Default parameters | Firmware 3770 and up corresponding rigidity level |
|--------------|--|---|
| 1.5kw and up | P1-00=200 P1-01=3300 P1-02=200 P2-35=100 P2-49=300 | 10 |
| 200w~750w | P1-00=300 P1-01=2200 P1-02=300 P2-35=100 P2-49=400 | 15 |
| 100w | P1-00=400 P1-01=1650 P1-02=400 P2-35=100 P2-49=500 | 20 |

8.3.4 Notes

- ◆ The gain parameters corresponding to the rigidity level can be independently fine-tuned in the fast adjustment mode.
- ◆ In order to ensure stability, the gain of model loops is small at low rigidity level, which can be added separately when there is high response requirement.
- ◆ When vibration occurs in fast adjustment, the torque instruction filter P2-35 can be modified. If it is ineffective, the mechanical characteristic analysis can be used and the relevant notch parameters can be set (refer to chapter 8.7 vibration suppression).
- ◆ Fast adjustment mode defaults to set a rigidity level. If the gain does not meet the mechanical requirements, please gradually increase or decrease the settings.

8.4 Auto-tuning

8.4.1 Overview

Auto-tuning is divided into internal instruction auto-tuning and external instruction auto-tuning.

Auto-tuning (internal instruction) refers to the function of automatic operation (forward and reverse reciprocating motion) of servo unit without instructions from the upper device and adjusting according to the mechanical characteristics in operation.

Auto-tuning (external instruction) is the function of automatically optimizing the operation according to the instructions from the upper device.

The automatic adjustments are as follows:

- ◆ Load moment of inertia
- ◆ Gain parameters (speed loop, position loop, model loop gain)
- ◆ Filter (notch filter, torque instruction filter)

8.4.2 Notes

Untunable occasions

- ◆ Mechanical systems can only operate in one direction.

Setting occasions that are prone to failure

- ◆ Excessive load moment of inertia;
- ◆ The moment of inertia varies greatly during operation.
- ◆ Low mechanical rigidity, vibration during operation and failure of detection positioning;
- ◆ The running distance is less than 0.5 circles.

Preparations before auto-tuning

- ◆ Use position mode;
- ◆ Driver in bb state;
- ◆ Driver without alarm;
- ◆ The matching of the number of pulses per rotation and the width of positioning completion should be reasonable.


8.4.3 Operation tools

Internal instruction auto-tuning and external instruction auto-tuning can be executed by driver panel and XinJeServo software.

8.4.4 Internal instruction auto-tuning steps


Driver panel auto-tuning steps

1. The inertia identification is carried out, and the inertia estimation steps please refer to chapter 8.2.4 operation steps.
2. Enter F0-09, panel display is iat-;




A rectangular display box containing the text "IAE -" in a digital font.

3. Press ENTER, panel display is iat--, servo is in enabled status right now;



A rectangular display box containing the text "IAE --" in a digital font.

4. Press INC or DEC, panel display is tune and flashing, enter auto-tuning status;



A rectangular display box containing the text "tune" in a digital font.

5. Driver will automatically send pulse instructions, if the auto-tuning is successful, the panel shows done and flashing.



6. Press STA/ESC to exit internal instruction auto-tuning.


Note: In the process of auto-tuning, press STA/ESC will exit the auto-tuning operation and use the gain parameters at the exit time. If auto-tuning fails, it is necessary to initialize the driver before auto-tuning again.

■ Panel alarm in auto-tuning process


| Error code | Meaning | Reasons |
|------------|--|---|
| Err-1 | Failure to search for optimal gain | Too large inertia ratio; too weak rigidity of mechanism |
| Err-2 | Overtrip alarm in auto-tuning process | Please make sure that there is no overrun and alarm before auto-tuning. |
| Err-6 | Driver is not in "bb" state at the time of operation | Please make sure the present status of driver |
| Err-7 | Driver alarmed in auto-tuning process | The driver alarm occurs |

XinJeServo software auto-tuning steps


1. click auto-tuning on the XinJeServo software main interface
2. set the auto-tuning trip in jog mode or manually




3. set the auto-tuning interface



4. click ok to estimate the inertia.




5. set the auto-tuning parameters




| Load type | Description |
|------------------|---|
| Synchronous belt | Fit for the adjustment of lower rigidity mechanism such as synchronous belt mechanism. |
| Screw rod | It is suitable for adjustment of higher rigidity mechanism such as ball screw mechanism. If there is no corresponding mechanism, please choose this type. |
| Rigid connection | It is suitable for the adjustment of rigid body system and other mechanisms with higher rigidity. |

| Auto-tuning mode | Description |
|--------------------------------------|--|
| Soft | Make a soft gain adjustment. Besides gain adjustment, notch filter is automatically adjusted. |
| Fast positioning | Make special adjustment for positioning purpose. Besides gain adjustment, the model loop gain and notch filter are automatically adjusted. |
| Fast positioning (control overshoot) | In the use of positioning, we should pay attention to adjusting without overshoot. Besides gain adjustment, the model loop gain and notch filter are automatically adjusted. |

6. Start auto-tuning



7. Wait for the end of the auto-tuning



8.4.5 External instruction auto-tuning steps

Driver panel auto-tuning steps

1. The inertia identification is carried out and the step of inertia estimation please refers to the driver panel inertia estimation (8.2.4 operation step)
2. Shut down adaptive function (P2-01.0 sets to 0), power on again
3. Enter parameter F0-08, it will show Eat- (External Refrence Auto-tuning)

Eat-

4. Press ENTER, if the enabler is not open, the panel displays Son and flickers, waiting for the enabler to open, if the enabler has been opened, skip this step;

Son

5. Turn on the servo enabler, the panel displays tune and flickers, enter auto-tuning status.

tune

6. The upper device starts to send pulse, if the auto-tuning is successful, it displays done and flickers.

done

7. Press STA/ESC to exit the external instruction auto-tuning.

Note: in the auto-tuning process, press STA/ESC will exit the auto-tuning, and use the gain parameters at the exit moment.


■ Panel error alarm in auto-tuning process

| Error code | Meaning | Reasons |
|------------|--|---|
| Err-1 | Failure to search for optimal gain | Too large inertia ratio; too weak rigidity of mechanism |
| Err-2 | ①Overrun/alarm occurs during auto-tuning ②External instruction auto-tuning/Vibration suppression mode: servo shut down the enabler during auto-tuning | Please make sure that there is no overrun and alarm before auto-tuning. Make sure that the enable is not closed during auto-tuning |
| Err-3 | Current non-position control mode | Please auto-tune in position mode |

| | | |
|-------|---|-------------------------------------|
| Err-4 | Unclosed adaptive function | Set P2-01.0 to 0 before auto-tuning |
| Err-7 | Driver alarm during auto-tuning | Driver alarmed |
| Err-8 | Positioning completion signal instability | Short instruction interval |


XinJeServo software auto-tuning steps

1. Click auto-tuning on the main interface of XinJeServo software




2. Select jog or manual setting to configure the trip of inertia identification.


3. Set the auto-tuning interface



4. Click ok to start the inertia identification.




5. Configure the auto-tuning parameters




| Auto-tuning mode | Description |
|---------------------------------------|--|
| Soft | Make a soft gain adjustment. Besides gain adjustment, notch filter is automatically adjusted. |
| Rapid positioning | Make special adjustment for positioning purpose. Besides gain adjustment, the model loop gain and notch filter are automatically adjusted. |
| Rapid positioning (control overshoot) | In the use of positioning, we should pay attention to adjusting without overshoot. Besides gain adjustment, the model loop gain and notch filter are automatically adjusted. |

| Load type | Description |
|------------------|---|
| Synchronous belt | Adjustment of lower rigidity mechanism such as synchronous belt |
| Screw | It is suitable for adjusting higher rigidity mechanism such as ball screw mechanism. If there is no corresponding mechanism, please choose this type. |
| Rigid connection | It is suitable for the adjustment of rigid body system and other mechanisms with higher rigidity. |

6. Start auto-tune




7. Open the servo enable, then click ok.



8. The upper device starts to send pulses, wait the completion of auto-tuning.

9. Auto-tuning is finished, click ok.



8.4.6 Related parameters

The following parameters may be modified during auto-tuning. Do not change them manually during auto-tuning.


| Parameter | Name | Property | The influence of numerical value on gain after auto-tuning |
|-----------|---|-----------------------------|--|
| P0-07 | First inertia ratio | Gain performance parameters | Yes |
| P1-00 | First speed loop gain | | |
| P1-01 | Integral time constant of the first speed loop | | |
| P1-02 | First position loop gain | | |
| P2-00.0 | Disturbance observer switch | | |
| P2-01.0 | Adaptive mode switch | | |
| P2-35 | Torque command filter time constant 1 | | |
| P2-41 | Disturbance observer gain | | |
| P2-47.0 | model loop switch | | |
| P2-49 | model loop gain | | |
| P2-55 | model speed feedforward gain | | |
| P2-60.0 | Active vibration suppression switch | | |
| P2-61 | Active vibration suppression frequency | | |
| P2-62 | Active vibration suppression gain | | |
| P2-63 | Active vibration suppression damping | | |
| P2-64 | Active vibration suppression filter time 1 | | |
| P2-65 | Active vibration suppression filter time 2 | | |
| P2-66 | The second group of active vibration damping | | |
| P2-67 | Second group active vibration suppression frequency | | |
| P2-69.0 | First notch switch | | |
| P2-69.1 | Second notch switch | | |
| P2-71 | First notch frequency | | |

| | | | |
|-------|---|--------------------------------|----|
| P2-72 | First notch attenuation | | |
| P2-73 | First notch band width | | |
| P2-74 | Second notch frequency | | |
| P2-75 | Second notch attenuation | | |
| P2-76 | Second notch band width | | |
| P2-17 | Inertia identification and internal instruction auto-tuning max speed | Auto-tuning setting parameters | No |
| P2-86 | auto-tuning jog mode | | |
| P2-87 | auto-tuning min limit position | | |
| P2-88 | auto-tuning max limit position | | |
| P2-89 | auto-tuning max speed | | |
| P2-90 | auto-tuning acceleration/deceleration time | | |


Note: P2-60~P2-67 are automatically modified in auto-tuning process. Users are not allowed to modify them manually. Manual modification may lead to the risk of system runaway.

8.5 Manual adjustment

8.5.1 Overview



Position control loop diagram (turn off the model loop)



Position control loop diagram (turn on the model loop)

Servo unit consists of three feedback loops (current loop, speed loop and position loop) from inside to outside. The more inner loop, the more responsive it is. Failure to comply with this principle will result in poor response or vibration. Among them, the current loop parameters are fixed values to ensure adequate responsiveness, and users do not need to adjust.

Please use manual adjustment in the following occasions:

- When the expected effect can not be achieved by fast adjusting the gain
- When the expected effect is not achieved by automatically adjusting the gain

8.5.2 Adjustment steps

In position mode, if the soft mode (P2-02.0=1) is selected by auto-tuning, the function of model loop will be turned off; in speed mode, the gain of position loop will be invalid.

Increasing response time

1. Reducing the filter time constant of torque instruction (P2-35)
2. Increasing Speed Loop Gain (P1-00)

3. Reducing Integral Time Parameter of Speed Loop (P1-01)
4. Increasing the gain of position loop (P1-02)
5. Improving Model Loop Gain (P2-49)

Reduce response, prevent vibration and overshoot

1. Reducing the Speed Loop Gain (P1-00)
2. Increasing Integral Time Constant of Speed Loop (P1-01)
3. Reducing the gain of position loop (P1-02)
4. Increase the filter time constant of the torque instruction (P2-35)
5. Reducing Model Loop Gain (P2-49)

8.5.3 Gain parameters for adjustment

The gain parameters that need to be adjusted:

P1-00 Speed Loop Gain

P1-01 Integral Time Constant of Speed Loop

P1-02 position loop gain

P2-35 Torque Instruction Filtering Time Constant

P2-49 Model Loop Gain

■ **Speed loop gain**

Because the response of the speed loop is low, it will become the delay factor of the outer position loop, so overshoot or vibration of the speed command will occur. Therefore, in the range of no vibration of mechanical system, the larger the setting value, the more stable the servo system and the better the responsiveness.

| Parameter | Name | Default setting | Unit | Range | Modification | Effective |
|-----------|-----------------|-----------------|-------|----------|--------------|-----------|
| P1-00 | Speed loop gain | 200 | 0.1Hz | 10~20000 | Anytime | At once |

■ **Integral time constant of speed loop**

In order to respond to small inputs, the speed loop contains integral elements. Because this integral factor is a delay factor for servo system, when the time constant is too large, it will overshoot or prolong the positioning time, which will make the response worse.

The relationship between the gain of the speed loop and the integral time constant of the speed loop is approximately as follows:

$$P1-00 \times P1-01 = 636620$$

| Parameter | Name | Default setting | Unit | Range | Modification | Effective |
|-----------|--------------------------------------|-----------------|--------|----------|--------------|-----------|
| P1-01 | integral time constant of speed loop | 3300 | 0.01ms | 15~51200 | Anytime | At once |

■ **Position loop gain**

When the model loop is invalid (P2-47.0=0), the responsiveness of the position loop of the servo unit is determined by the gain of the position loop. The higher the position loop gain is, the higher the responsiveness is and the shorter the positioning time is. Generally speaking, the gain of position loop cannot be increased beyond the natural vibration number of mechanical system. Therefore, in order to set the position loop gain to a larger value, it is necessary to improve the rigidity of the machine and increase the number of inherent vibration of the machine.

| Parameter | Name | Default setting | Unit | Range | Modify | Effective |
|-----------|--------------------|-----------------|-------|----------|---------|-----------|
| P1-02 | Position loop gain | 200 | 0.1/s | 10~20000 | Anytime | At once |

■ Filter time constant of torque instruction

When machine vibration may be caused by servo drive, it is possible to eliminate vibration by adjusting the filtering time parameters of the following torque instructions. The smaller the numerical value, the better the response control can be, but it is restricted by the machine conditions. When vibration occurs, the parameter is generally reduced, and the adjustment range is suggested to be 10-150.

| Parameter | Name | Default setting | Unit | Range | Modify | Effective |
|-----------|--|-----------------|--------|---------|---------|-----------|
| P2-35 | Filter time constant of torque instruction 1 | 100 | 0.01ms | 0~65535 | Anytime | At once |

■ Model loop gain

When the model loop is valid (P2-47.0=1), the response of the servo system is determined by the gain of the model loop. If the gain of the model loop is increased, the responsiveness is increased and the positioning time is shortened. At this time, the response of the servo system depends on this parameter, not P1-02 (position loop gain). The gain of the model loop is only valid in position mode.

| Parameter | Name | Default setting | Unit | Range | Modify | Effective |
|-----------|-----------------|-----------------|-------|----------|---------|-----------|
| P2-49 | Model loop gain | 500 | 0.1Hz | 10~20000 | Anytime | At once |

8.6 Adaptive

8.6.1 Overview

Adaptive function means that no matter what kind of machine and load fluctuation, it can obtain stable response through automatic adjustment. It starts to automatically adjust when servo is ON.

8.6.2 Notes

- ◆ When the servo unit is installed on the machine, it may produce instantaneous sound when the servo is ON. This is the sound when the automatic notch filter is set, not the fault. For the next time the servo is ON, no sound will be emitted.
- ◆ When the inertia of the motor exceeds the allowable load, the motor may produce vibration. At this time, please modify the adaptive parameters to match the present load inertia.
- ◆ In adaptive operation, in order to ensure safety, the adaptive function should be executed at any time when the servo enablement can be stopped or turned off urgently.

8.6.3 Operation steps

The factory settings are self-adaptive effective without modifying other parameters. The effectiveness of self-adaptation is controlled by the following parameters.

| Parameter | Meaning | Default setting | Modification | Effective |
|-----------|---------|-------------------|--------------|-----------|
| P2-01 | n.□□□0 | Adaptive turn off | n.□□□1 | Servo bb |
| | n.□□□1 | Adaptive turn on | | |

8.6.4 Inertia mode and related parameters

The adaptive default parameter is defined as small inertia mode. If the load inertia far exceeds the allowable load inertia of the motor (such as 60 times inertia of the 60 motor), the adaptive large inertia mode can be turned on.

| Parameter | | Meaning | Default setting | Modification | Effective |
|-----------|--------|-----------------------------|-----------------|--------------|-------------|
| P2-03 | n.0□□□ | Adaptive small inertia mode | n.0□□□ | Servo bb | Re-power on |
| | n.1□□□ | Adaptive large inertia mode | | | |

| Parameter | Meaning | Default setting | Modification | Effective |
|-----------|---|----------------------|--------------|------------|
| P2-05 | Adaptive speed loop gain | 400 ^{Note1} | Servo bb | Repower on |
| P2-10 | Adaptive speed loop integral | 500 | Servo bb | Repower on |
| P2-11 | Adaptive position loop gain | 100 | Servo bb | Repower on |
| P2-07 | Adaptive inertia ratio | 0 | Servo bb | Repower on |
| P2-08 | Adaptive speed observer gain | 60 | Servo bb | Repower on |
| P2-12 | Adaptive stable max inertia ratio | 30 | Servo bb | Repower on |
| P2-16 | Adaptive motor rotor inertia coefficient | 100 | Servo bb | Repower on |
| P2-19 | Adaptive bandwidth | 50 ^{Note2} | Anytime | At once |
| P6-05 | Adaptive large inertia mode speed loop gain | 200 | Servo bb | Repower on |
| P6-07 | Adaptive large inertia mode inertia ratio | 50 | Servo bb | Repower on |
| P6-08 | Adaptive large inertia mode speed observer gain | 40 | Servo bb | Repower on |
| P6-12 | Adaptive large inertia mode max inertia ratio | 50 | Servo bb | Repower on |

Note 1: DS5 series servo 750W and below driver default value is 400; other power section default value is 200.

Note 2: DS5 series servo 400W and below driver default value is 70; other power section default value is 50.

8.6.5 Recommended inertia ratio parameters

Under the adaptive default parameters, the load can only run steadily under a certain moment of inertia. If the load inertia is large, some parameters need to be adjusted. The recommended parameters are as follows (the parameters are modified under the default parameters).

| Motor flange | Inertia | Parameters |
|--------------|-------------------------|---|
| 40~90 | Within 20 times inertia | Adaptive small inertia mode (default parameters) |
| | 20-30 times inertia | Set P2-08=50, P2-12=40 |
| | 30-40 times inertia | Set P2-08=50, P2-12=40, P2-07=10 |
| | 40-50 times inertia | Set P2-08=50, P2-12=40, P2-07=30 |
| | 50-80 times inertia | Switch to adaptive large inertia mode or set P2-08=40, P2-12=50, P2-07=50 |
| 130 | Within 10 times inertia | Adaptive small inertia mode (default parameters) |
| | 10~15 times inertia | Set P2-08=50, P2-12=40 |
| | 15~20 times inertia | Switch to adaptive large inertia mode or set P2-08=40, P2-12=50, P2-07=50 |

Note: The large inertia parameters can still drive a smaller inertia load. For example, when the parameters of 50 times inertia are used in the mechanism of 20 times inertia, only the response will become worse.

8.6.6 Adaptive parameters effect

| Parameter Small inertia/large inertia | Name | Default value | Range | Effect |
|--|---|------------------|------------|--|
| P2-05/P6-05 | Adaptive speed loop gain | 400/200 | 200-400 | Reduction can improve the inertia capability, but it will reduce the responsiveness, which has a greater impact on the responsiveness. |
| P2-07/P6-07 | Adaptive load inertia ratio | 0/50 | 0-200 | Increase can greatly improve the inertia capacity without affecting the responsiveness. Too large will produce vibration. |
| P2-08/P6-08 | Speed observer gain | 60/40 | 30-60 | Reducing P2-08 and increasing P2-12 can greatly improve the inertia capability, but it will reduce the responsiveness, which has a great impact on responsiveness. |
| P2-12/P6-12 | Adaptive stable max inertia ratio | 30/50 | 30-60 | |
| P2-10 | Adaptive speed loop integral time coefficient | 500 | 200-larger | Adjust according to need, generally increase |
| P2-11 | Adaptive position loop gain coefficient | 100 | 50-200 | Adjust according to the need, increasing will make the response fast, reducing will make the response slow |
| P2-16 | Adaptive motor rotor inertia coefficient | 100 | 100-200 | Increasing will improve the servo rigidity and enhance anti-disturbance ability, can solve operation jitter. |
| P2-19 | Adaptive bandwidth | 50~70 | 40-80 | Increasing will improve the inertia capacity slightly, and has little effect on the responsiveness, to be an auxiliary parameter. |

8.6.7 Invalid parameters when adaptive effective

When the adaptive function is effective (P2-01.0=1), the invalid parameters are shown as below:

| Item | Parameters | Descriptions |
|-------|----------------------|--|
| Gain | P1-00 | First speed loop gain |
| | P1-05 | Second speed loop gain |
| | P1-01 | First speed loop integral time constant |
| | P1-06 | Second speed loop integral time constant |
| | P1-02 | First position loop gain |
| | P1-07 | Second position loop gain |
| | P2-49 | Model loop gain |
| | P0-07 | First inertia ratio |
| P0-08 | Second inertia ratio | |
| | P5-36 | /I-SEL inertia ratio switch |

8.7 Vibration suppression

8.7.1 Overview

The mechanical system has a certain resonance frequency. When the servo gain is increased, the continuous vibration may occur near the resonance frequency of the mechanical system. Generally in the range of 400Hz to 1000Hz, it caused the gain can not continue to increase. Vibration can be eliminated by automatically detecting or manually setting the vibration frequency. After the vibration is eliminated, if the responsiveness needs to be improved, the gain can be further improved.

Note:

- (1) Servo responsiveness will change after vibration suppression operation.
- (2) Before performing the vibration suppression operation, please set the inertia ratio and gain parameters correctly, otherwise it can not be controlled properly.

8.7.2 Operation tools

| Adjustment mode | Operation tools | Control mode | Operation steps | Version |
|---------------------------|---|---------------|---|---|
| Adaptive mode | XinJeServo Mechanical Characteristic Analysis | Position mode | 8.7.4 Vibration Suppression (PC Software) | All versions of upper computer software support |
| Auto-tuning mode | Panel vibration suppression | | 8.7.3 Vibration Suppression (Panel) | All versions of firmware support |
| | XinJeServo Mechanical Characteristic Analysis | | 8.7.4 Vibration Suppression (PC Software) | All versions of upper computer software support |
| Auto-tuning/adaptive mode | Panel vibration suppression | | 8.7.6 vibration suppression (easyFFT) | All versions of firmware support |

8.7.3 Vibration suppression (panel)

There are two modes of panel vibration suppression, mode 1(vib-1) and mode 2(vib-2).

■ Difference between Two Kinds of Vibration Suppression


| Mode | Display | Changed parameters |
|--------|---------|--|
| Mode 1 | vib-1 | Only the parameters related to vibration suppression will be changed. |
| Mode 2 | Vib-2 | It will change the parameters of vibration suppression and the gain of speed loop. |

The operation steps:

1. Enter F0-10 in auto-tuning mode, the panel shows vib-1 or enter F0-11, the panel shows vib-2;


 or
 

2. Press ENTER, panel shows Son and flashes, turn on the enabler by manual;



3. After turn on the enabler, panel shows tune and flickers, enter auto-tuning process;



4. The upper device starts to send pulses, then it will show done and flicker




5. Press STA/ESC to exit
6. Vibration suppression parameters are automatically written into the second and first notches (the second notches are preferred when there is only one vibration point). The related parameters are detailed in 8.7.7 notch filter.

■ Fault alarm of panel in vibration suppression process


| Error code | Meaning | Reasons |
|------------|--|--|
| Err-1 | Failure to search for optimal gain | Too large inertia ratio; too weak rigidity of mechanism |
| Err-2 | (1) Overrun/alarm occurs during auto-tuning (2) External instruction auto-tuning/Vibration Suppression Mode: Servo turns off the Enabler in auto-tuning process | Please make sure that there is no overrun and alarm before auto-tuning. Make sure that the enabler is not turned off when auto-tuning |
| Err-3 | Non-position control mode | please auto-tune in position mode |
| Err-4 | Not turn off the adaptive function | please set P2-01.0 to 0, then auto-tune |
| Err-7 | Driver alarm in auto-tuning process | driver alarmed |
| Err-8 | Positioning Completion Signal Instability | Short instruction interval |

8.7.4 Vibration suppression (PC software)

1. open XinJeServo software, click mechanical properties;
2. click measure;



3. set the measure conditions, then click execute;
4. select amplitude and phase;



5. set the filter width (to see resonance frequencies clearly), find the resonance frequency;
6. Notch parameters need to be set manually. Refer to 8.7.7 notch filter for details.

As an example, through the analysis of mechanical characteristics, the resonance frequency is 328 Hz, and the third notch filter can be used. The parameters are as follows:

$$P2-69 = n.1000 \quad P2-77 = 328$$

Note: In both adaptive and auto-tuning modes, if mechanical characteristic analysis is used, the notch can be set manually. If there are multiple resonance points, the third to fifth notch can be configured in turn.


8.7.5 Vibration suppression (manual setting)

If the resonance frequency of the mechanical system is known, the vibration can be eliminated by setting the vibration frequency manually. Please configure the third to fifth notches. The related parameters are detailed in 8.7.7 notch filter.

8.7.6 Vibration suppression (quick FFT)


This function can analyze the mechanical characteristics through the parameter F0-12 on the servo operate panel, find out the mechanical resonance frequency and realize the vibration suppression.

The complete operation process is shown in the figure below:



The operation steps are described as follows:

1. F0-12, long press **【ENTER】** to enter quick FFT function, it will show “E_FFt”.



2. Press **【ENTER】** to enter torque setting interface, it will show the current setting torque, which is the value of P6-89. Press **【INC】**, **【DEC】** to increase or decrease torque command. When increasing the torque command, it is recommended to increase it a little bit to avoid severe vibration of the equipment.

015

3. After setting the torque command, long press **【ENTER】** , enter “read to enable” status, it will show ‘F’.

F.

4. Press **【ENTER】** , enable, it will show “..run”.

..run

5. Press **【INC】** , **【DEC】** to run forward or reverse and find the resonance frequency. “E_FFt” will shining on the panel when operation. If the resonance frequency is found, it will show “Fxxxx”, “xxxx” is the resonance frequency. If failed, it will show “F----”.

F8888

6. Whatever it shown “Fxxxx” or “F----”, press **【INC】** , **【DEC】** can find the resonance frequency again. If the resonance frequency is found, long press **【ENTER】** to set the resonance frequency in the notch filter of servo driver.


11

Note: for above each step, press STA/ESC can return to the last step or exit.


8.7.7 Notch filter

Notch filter can suppress mechanical resonance by reducing the gain at a specific frequency. After the notch filter is set correctly, the vibration can be effectively suppressed and the servo gain can be continuously increased.

The principle diagram of notch filter is as follows:



The servo driver has five sets of notch filters, each with three parameters, notch frequency, notch attenuation and notch bandwidth. The first and second notches are set automatically, and the third, fourth and fifth are set manually. The torque instruction filter and notch filter are in series in the system. As shown in the figure below, the switch of the notch filter is controlled by P2-69 and P2-70.



| Parameter | | Meaning | Default setting | Change | Effective |
|-----------|--------|------------------|-----------------|---------|-----------|
| P2-69 | n.□□□0 | First notch off | n.□□□0 | Anytime | At once |
| | n.□□□1 | First notch on | | | |
| | n.□□0□ | Second notch off | n.□□0□ | Anytime | At once |
| | n.□□1□ | Second notch on | | | |
| | n.0□□□ | Third notch off | n.0□□□ | Anytime | At once |
| | n.1□□□ | Third notch on | | | |
| P2-70 | n.□□□0 | Fourth notch off | n.□□□0 | Anytime | At once |
| | n.□□□1 | Fourth notch on | | | |
| | n.□□0□ | Fifth notch off | n.□□0□ | Anytime | At once |
| | n.□□1□ | Fifth notch on | | | |

| Parameter | Meaning | Default setting | Unit | Range | Change | Effective |
|-----------|--------------------------|-----------------|-------|---------|---------|-----------|
| P2-71 | First notch frequency | 5000 | Hz | 50~5000 | Anytime | At once |
| P2-72 | First notch attenuation | 70 | 0.1dB | 50~1000 | Anytime | At once |
| P2-73 | First notch bandwidth | 0 | Hz | 0~1000 | Anytime | At once |
| P2-74 | Second notch frequency | 5000 | Hz | 50~5000 | Anytime | At once |
| P2-75 | Second notch attenuation | 70 | 0.1dB | 50~1000 | Anytime | At once |
| P2-76 | Second notch bandwidth | 0 | Hz | 0~1000 | Anytime | At once |
| P2-77 | Third notch frequency | 5000 | Hz | 50~5000 | Anytime | At once |
| P2-78 | Third notch attenuation | 70 | 0.1dB | 50~1000 | Anytime | At once |
| P2-79 | Third notch bandwidth | 0 | Hz | 0~1000 | Anytime | At once |
| P2-80 | Fourth notch frequency | 5000 | Hz | 50~5000 | Anytime | At once |
| P2-81 | Fourth notch attenuation | 70 | 0.1dB | 50~1000 | Anytime | At once |
| P2-82 | Fourth notch bandwidth | 0 | Hz | 0~1000 | Anytime | At once |
| P2-83 | Fifth notch frequency | 5000 | Hz | 50~5000 | Anytime | At once |
| P2-84 | Fifth notch attenuation | 70 | 0.1dB | 50~1000 | Anytime | At once |
| P2-85 | Fifth notch bandwidth | 0 | Hz | 0~1000 | Anytime | At once |

Note:

1. In the adaptive mode, if the vibration is detected, the second notch filter will be automatically configured.
2. In the auto-tuning mode, the second and first notches will be automatically configured if the vibration is detected (the second notches will be preferentially opened when there is only one vibration point).
3. Whether in self-adaptive or auto-tuning mode, if the mechanical characteristic analysis is sued, it belongs to manual setting of notches, please configure the third to fifth notches.

8.8 Gain adjustment

8.8.1 Model loop control

In the self-tuning mode, in addition to the gain of speed loop and position loop, there is also the gain of model loop, which has a great influence on the servo response. When the model loop is not open, the servo responsiveness is determined by the position loop gain. When the model ring is open, the servo responsiveness is determined by the model loop gain. The model loop is equivalent to the feedforward function in the driver control loop. Refer to 8.5 manual adjustment for its specific function.

When the self-tuning mode is soft, the model loop function will be automatically off. When the self-tuning mode selects fast positioning or fast positioning (control overshoot), the model loop function will be automatically turned on.

Self-tuning mode:

| Parameter | | Meaning | Default setting | Modify | Effective |
|-----------|--------|---------------------------------------|-----------------|----------|-----------|
| P2-02 | n.□□□1 | Soft | n.□□□3 | Any time | At once |
| | n.□□□2 | Fast positioning | | | |
| | n.□□□3 | Quick positioning (control overshoot) | | | |

Selection of self-tuning mode:

(1) Soft (P2-02.0 = 1):

This mode does not turn on the gain of the model loop, and the operation is soft. It is suitable for occasions with insufficient mechanical rigidity and low response requirements.

(2) Quick positioning (P2-02.0 = 2):

This method has the fastest response to setting parameters, but has no special suppression on overshoot.

(3) Quick positioning (control overshoot) (P2-02.0 = 3):

In this way, the setting parameter response is fast, which will inhibit the overshoot.

| Load type | Explanation |
|------------------|--|
| Synchronous belt | The adjustment is suitable for the mechanism with lower rigidity such as synchronous belt mechanism. |
| Lead screw | It is suitable for the adjustment of high rigidity mechanism such as ball screw mechanism. Please select this type when there is no corresponding structure. |
| Rigid connection | The adjustment is suitable for rigid body system and other mechanisms with high rigidity. |

| Self-tuning mode | Explanation |
|--------------------------------------|--|
| Soft | Soft gain adjustment. In addition to gain adjustment, the notch filter is also adjusted automatically |
| Fast positioning | Make special adjustment for positioning purpose. In addition to gain adjustment, the model loop gain and notch filter are also adjusted automatically |
| fast positioning (control overshoot) | Pay attention to the adjustment of no overshoot in the positioning purpose. In addition to gain adjustment, the model loop gain and notch filter are also adjusted automatically |



| Parameter | | Meaning | Default setting | Modification | Effective |
|-----------|--------|--------------------------------------|-----------------|--------------|-----------|
| P2-02 | n.□□□1 | Soft | n.□□□3 | At anytime | at once |
| | n.□□□2 | Fast positioning | | | |
| | n.□□□3 | fast positioning (control overshoot) | | | |

Model loop function




| Parameter | | Meaning | Default setting | Modification | Effective |
|-----------|--------|---------------------|-----------------|--------------|-----------|
| P2-47 | n.□□□0 | Model loop turn off | n.□□□0 | At anytime | At once |
| | n.□□□1 | Model loop turn on | | | |

Taking DS5 series servo auto-tuning mode and using 750W servo 5 times load inertia as an example:

■ Model loop function turns off (soft mode)

| Low Rigidity and Low Response | High Rigidity and Medium Response |
|---|--|
|  |  |
| Load inertia ratio P0-07: 500% | |
| speed loop gain P1-00: 200 | speed loop gain P1-00: 800 |
| speed loop integral P1-01: 3300 | speed loop integral P1-01: 825 |
| position loop gain P1-02: 200 | position loop gain P1-02: 700 |
| Phenomenon: Running jitter, slow response | Phenomenon: smooth operation and fast response |

■ Model loop function turns on (fast positioning or fast position(control overshoot))

| Low Rigidity and Low Response | High Rigidity and Low Response | High Rigidity and High Response |
|--|--|---|
|  |  |  |
| Load inertia ratio P0-07: 500% | | |
| speed loop gain P1-00: 200 | speed loop gain P1-00: 800 | speed loop gain P1-00: 800 |
| speed loop integral P1-01: 3300 | speed loop integral P1-01: 825 | speed loop integral P1-01: 825 |
| position loop gain P1-02: 200 | position loop gain P1-02: 700 | position loop gain P1-02: 700 |
| Model loop gain P2-49: 300 | Model loop gain P2-49: 300 | Model loop gain P2-49: 4000 |
| Phenomenon: Running jitter, slow response | Phenomenon: smooth operation and slow response | Phenomenon: smooth operation and fast response |

Note: The above curves only show the effect of the parameters, not the real running curves.

8.8.2 Torque disturbance observation

Disturbance observer can reduce the influence of external disturbance on servo system and improve the anti-disturbance ability by detecting and estimating the external disturbance torque of the system and compensating the torque command.

If the soft mode is selected in the auto-tuning mode, the disturbance observer will be closed automatically, and the gain of the disturbance observer will not change. If the fast positioning or fast positioning (control overshoot) is selected, the disturbance observer will be opened automatically, and the gain of the disturbance observer will be modified to 85. The relevant parameters of this function no need to be set manually by users.

| Parameter | | Meaning | Default setting | Modification | Effective |
|-----------|--------|----------------------------------|-----------------|--------------|-----------|
| P2-00 | n.□□□0 | Turn-off of disturbance observer | n.□□□0 | Servo bb | At once |
| | n.□□□1 | Turn-on of disturbance observer | | | |

| Parameter | Meaning | Default setting | Unit | Setting range | Modify | Effective |
|-----------|-------------|-----------------|------|---------------|---------|-----------|
| P2-41 | Disturbance | 85 | % | 0~100 | Anytime | At once |

| | | | | | | |
|--|---------------|--|--|--|--|--|
| | observer gain | | | | | |
|--|---------------|--|--|--|--|--|

8.8.3 Gain adjustment parameters

| Parameter | Meaning | Default setting | Unit | Range | Modify | Effective |
|-----------|---|----------------------------|--------|----------|-------------|-----------|
| P1-00 | First speed loop gain | 20P1: 400 Others: 200 | 0.1Hz | 10~20000 | Servo bb | At once |
| P1-01 | Integral time constant of the first velocity loop | 20P1: 1650 Others: 3300 | 0.01ms | 15~51200 | Servo bb | At once |
| P1-02 | First position loop gain | 20P1: 400 Others: 200 | 0.1/s | 10~20000 | Servo bb | At once |
| P1-05 | Second speed loop gain | 20P1: 400 Others: 200 | 0.1Hz | 10~20000 | Servo bb | At once |
| P1-06 | Second velocity loop integral constant | 20P1: 1650 Others: 3300 | 0.01ms | 15~51200 | Servo bb | At once |
| P1-07 | Second position loop gain | 20P1: 400 Others: 200 | 0.1/s | 10~20000 | Servo bb | At once |


Note: Version 3770 and later added a second set of gain adjustments.

8.8.4 Gain switch


| Parameter | Meaning | Default setting | Modify | Effective | |
|-----------|--|--|----------|-----------|---------|
| P1-14 | n.□□□0 | 0-SI terminal switching gain is valid (the gain switching condition parameter is not valid) 1 - perform gain switching according to gain switching conditions 2 - reserved | 0 | Servo bb | At once |
| | n.□□□1 | n.□□X□: Gain switching condition selection 0 - first gain fixed 1 - switching by external SI terminals 2 - large torque command 3 - large speed command 4 - speed command changes greatly 5 - [reserved] - fixed as the first gain 6 - large position deviation 7 - position command 8 - positioning completed 9 - large actual speed A - position command + actual speed | | | |
| P1-15 | Gain switching waiting time | 5 | Servo bb | At once | |
| P1-16 | Gain switching level threshold | 50 | Servo bb | At once | |
| P1-17 | Hysteresis of gain switching level threshold | 30 | Servo bb | At once | |
| P1-18 | Position loop gain switching time | 2 | Servo bb | At once | |

Note:

- (1) The gain switching waiting time is effective only when the second gain is switched back to the first gain
- (2) The definition of gain switching level threshold hysteresis:



(3) The definition of position gain switching time:



(4) Gain switching conditions:

| Gain switching condition | | | | Parameter | | |
|--------------------------|----------------------|---------|---|-----------|-----------|-----------|
| P1-14.1 | Condition | Diagram | Notes | P1-15 | P1-16 | P1-17 |
| 0 | The first gain fixed | - | - | invalid | invalid | invalid |
| 1 | Terminal switching | | Switch the gain through G-SEL signal: G-SEL invalid, first group of gain, G-SEL valid, second group of gain | Valid | invalid | invalid |
| 2 | Torque command | | When the absolute value of torque command exceeds (level + hysteresis) [%] at the last first gain, switch to the second gain. At the last second gain, the absolute value of the torque command is less than (level - hysteresis) [%], and then wait until P1-15 remain in this state, return to the first gain. | Valid | Valid (%) | Valid (%) |
| 3 | Speed command | | When the absolute value of the speed command exceeds (level + hysteresis) [RPM] at the last first gain, switch to the second gain. At the last second gain, when the absolute value of the speed command is less than (level - hysteresis) [RPM], wait until P1-15 remain in this state, and return to the first gain. | Valid | Valid | Valid |

| Gain switching condition | | | Parameter | | | |
|--------------------------|--|--|---|---------|----------------------|----------------------|
| 4 | Speed command change rate | | <p>At the last first gain, when the absolute value of the speed command change rate exceeds $(\text{level} + \text{hysteresis})$ [10rpm/s], switch to the second gain.</p> <p>At the last second gain, when the absolute value of the speed command change rate is less than $(\text{level} - \text{hysteresis})$ [10rpm/s], wait until P1-15 remain in this state, and return to the first gain.</p> | valid | valid (10rpm/s) | valid (10rpm/s) |
| 5 | Speed command high and low speed threshold [not supported temporarily] | | <p>At the last first gain, when the absolute value of the speed command exceeds $(\text{level} - \text{hysteresis})$ [RPM], switch to the second gain, and the gain gradually changes. When the absolute value of the speed command reaches $(\text{level} + \text{hysteresis})$ [RPM], the gain completely changes to the second gain.</p> <p>At the last second gain, when the absolute value of the speed command is lower than $(\text{level} + \text{hysteresis})$ [RPM], it starts to return to the first gain, and the gain changes gradually. When the absolute value of the speed command reaches $(\text{level} - \text{hysteresis})$ [RPM], the gain completely returns to the first gain.</p> | invalid | valid (rpm) | valid (rpm) |
| 6 | Position offset | | <p>Valid only in position mode (other modes are fixed as the first gain)</p> <p>When the absolute value of position deviation exceeds $(\text{level} + \text{hysteresis})$ [encoder unit] at the last first gain, switch to the second gain.</p> <p>When the absolute value of the position deviation is less than $(\text{level} - \text{hysteresis})$ [encoder unit] at the last second gain, wait until P1-15 remain in this state, and return to the first gain.</p> | valid | valid (encoder unit) | valid (encoder unit) |
| 7 | Position command | | <p>Valid only in position mode (other modes are fixed as the first gain)</p> <p>At the last first gain, if the position command is not 0, switch to the second gain.</p> <p>At the last second gain, if the position command is in the state of 0 which remains in the waiting time P1-15, it returns to the first gain.</p> | valid | invalid | invalid |

| Gain switching condition | | | Parameter | | | |
|--------------------------|--------------------------------|--|--|-------|-------------|-------------|
| 8 | Positioning completion | | <p>Valid only in position mode (other modes are fixed as the first gain)</p> <p>At the last first gain, if the positioning is not completed, switch to the second gain.</p> <p>At the last second gain, if the state of positioning completion remains in this state for the waiting time P1-15, the first gain is returned.</p> <p>Note: it is necessary to set the positioning completion detection mode according to P5-01.</p> | valid | invalid | invalid |
| 9 | Actual speed | | <p>Valid only in position mode (other modes are fixed as the first gain):</p> <p>At the last first gain, the absolute value of the actual speed exceeds (level + hysteresis) [RPM], switching to the second gain.</p> <p>At the last second gain, when the absolute value of the inter speed is less than (level-hysteresis) [RPM], wait until P1-15 remain in this state, and return to the first gain.</p> | valid | valid (rpm) | valid (rpm) |
| A | Position command+ actual speed | | <p>Valid only in position mode (other modes are fixed as the first gain):</p> <p>At the last first gain, if the position command is not 0, switch to the second gain.</p> <p>At the last second gain, the state in which the position command is 0 within the waiting time P1-15, maintains the second gain.</p> <p>When the position command is 0 and the waiting time P1-15 reached, if the absolute value of the actual speed is less than (level) [RPM], the speed integral time constant is fixed at the second speed loop integral time constant (P1-07), and the others return to the first gain. If the absolute value of the actual speed is less than (level-hysteresis) [RPM], the speed integral also returns to the integral time constant of the first speed loop (P1-02).</p> | valid | valid (rpm) | valid (rpm) |

8.9 Gain adjustment

8.9.1 Load shaking

The following causes cause load wobble:

1. The instruction is not smooth enough when the load inertia is too large.

Countermeasure:

- (1) Use position instruction smoothing filter P1-25;
- (2) Optimizing the instructions of the upper device to reduce the acceleration of the instructions;
- (3) Replace the motor with greater inertia.

2. Servo gain is too small, resulting in insufficient rigidity

Countermeasure:

- (1) Increase the gain parameters and rigidity to enhance the anti-disturbance ability.

3. Insufficient rigidity of mechanism and equipment sloshing

Countermeasure:

- (1) Reducing gain parameters;
- (2) Optimize the instructions of the upper device and reduce the acceleration of the instructions.

8.9.2 Vibration

The following causes cause machine vibration:

- (1) Vibration due to inappropriate servo gain

Countermeasure: Reduce gain

- (2) Mechanical resonance point

Countermeasure: Setting notch parameters manually or through mechanical characteristic analysis

8.9.3 Noise

In adaptive mode:

- (1) Inappropriate servo gain

Countermeasure: Reduce the adaptive control bandwidth (P2-19).

In auto-tuning mode:

- (1) Inappropriate servo gain

Countermeasure: Under the mode of rapid adjustment, reduce the rigidity level.

Automatic Adjustment Mode: Reducing Model Loop Gain P2-49

- (1) Noise due to mechanical resonance

Countermeasure: Refer to 8.8.2 vibration.

9 Alarm

9.1 CANopen communication association abnormal alarm

| Alarm | Error reason | | Solution |
|-------|-----------------------------|--|--|
| E-852 | Communication disconnection | Interruption of data interaction with CANopen master station | 1. Check whether the wiring of CAN network is dropped or damaged 2. Check whether CANopen master station is powered off 3. After ensuring that there is no problem with the wiring, first power off and restart the CANopen slave station, and then power off and restart the CANopen master station |

9.2 CANopen communication non associated abnormal alarm

| Type | Code | Description | Reasons | Solutions | |
|----------|------|-------------|---|---|--|
| EEE E | 1 | EEEE1 | Communication error between panel and CPU | (1) Voltage fluctuation of power supply is large, and low voltage leads to failure of panel refresh; (2) Damage of panel program | |
| | 2 | EEEE2 | | | |
| | 3 | EEEE3 | | | |
| | 4 | EEEE4 | | | |
| 01 | 0 | E-010 | Firmware version mismatch | Downloaded firmware version error | Please contact the agent or the manufacturer |
| | 3 | E-013 | FPGA loading error | ①program damaged ②device damaged | Please contact the agent or the manufacturer |
| | 4 | E-014 | FPGA Access error | (1) Program damage (2) Device damage (3) serious external interference | Please contact the agent or the manufacturer |
| | 5 | E-015 | Program running error | Program damage | Please contact the agent or the manufacturer |
| | 7 | E-017 | Processor Running Timeout | Program damage | Please contact the agent or the manufacturer |
| | 9 | E-019 | System password error | Program damage | Please contact the agent or the manufacturer |
| 02 | 0 | E-020 | Parameter loading error | Failure of parameter self-checking | Re-energizing can restore default parameters, if there are repeated problems, please contact the agent or manufacturer. |
| | 1 | E-021 | Parameter range beyond limit | Setting values are not within the prescribed range | Check parameters and reset them |
| | 2 | E-022 | Parameter conflict | Conflict of TREF or VREF Function Settings | P0-01=4, P3-00 set to 1 will alarm |
| | 3 | E-023 | Sampling channel setting error | Error setting of custom output trigger channel or data monitoring channel | Check that the settings are correct |
| | 4 | E-024 | parameter lost | Low voltage of power grid | (1) If it is single-phase 220V power supply, please connect L1 and L3. (2) show E-024 immediately after power failure (3) Resetting parameters |
| | 5 | E-025 | Erase FLASH error | Abnormal parameter preservation during | please contact the agent or the manufacturer |

| Type | Code | Description | Reasons | Solutions | |
|------|------|-------------|--|---|---|
| | | | power failure | | |
| | 6 | E-026 | Initialization FLASH error | Power supply instability of FLASH chip please contact the agent or the manufacturer | |
| | 8 | E-028 | EEPROM write in error | Voltage instability or chip abnormality Please contact the agent or the manufacturer | |
| 03 | 0 | E-030 | Bus voltage U0-05 is higher than the actual preset threshold, 220V Power Supply Machine (U0-05≥402V) 380V Power Supply Machine (U0-05≥780V) | High voltage of power grid | Check the fluctuation of power grid, 220V driver normal voltage range 200V ~ 240V, 380V driver normal voltage range 360V ~ 420V. If the voltage fluctuation is large, it is recommended to use the correct voltage source and regulator. |
| | | | | Excessive load moment of inertia (insufficient regeneration capacity) | (1) connect external regenerative resistor, (220V: bus voltage U0-05 = 392 discharge starts, U-05 = 377 discharge ends; 380V: U-05 = 750 discharge starts, U-05 = 720 discharge ends;) (2) Increasing Acceleration and Deceleration Time (3) Reducing load inertia (4) Reduce start-stop frequency (5) Replacement of larger power drivers and motors |
| | | | | Brake resistance damage or excessive resistance value | Check the regenerative resistor and replace the external resistor with the appropriate resistance value. See chapter 1.4.1 for the selection of the external resistor. |
| | | | | Acceleration and deceleration time is too short | Extending Acceleration and Deceleration Time |
| | | | | Hardware Fault of Driver Internal Sampling Circuit | The AC gear of the multimeter measures the input value of the servo LN (R/S/T), which is $220V \pm 10\%$ of the normal value. If the power supply voltage is more than $220V+10\%$ ($380V+10\%$), check the power supply voltage; if the power supply voltage is normal, then the servo BB state, monitor U0-05, the voltage measured by the multimeter * 1.414 < U0-05 (within 10V error), then the servo driver is faulty and needs to be sent back for repair. |
| 04 | 0 | E-040 | Bus voltage U0-05 is lower than the actual preset threshold. 220V power supply machine (U0-05 ≤ 150V) 380V power supply machine (U0-05 ≤ 300V) | low voltage of power grid when normal power on | (1) Check the fluctuation of power grid. The normal voltage range of 220V driver is 200V~240V. If the voltage fluctuation is large, the voltage regulator is recommended. (2) Replacement of larger capacity transformers |
| | | | | Instantaneous power failure | Re-energize after voltage stabilization |
| | | | | Hardware Fault of Driver Internal Sampling Circuit | The AC gear of the multimeter measures the input value of the servo LN (R/S/T), which is $220V \pm 10\%$ of the normal value. If < $220V + 10\%$ |

| Type | Code | Description | Reasons | Solutions | |
|------|------|-------------|--|--|---|
| | | | | (380V + 10%), then check the supply voltage; if the supply voltage is normal, then servo BB state, monitoring U0-05, multimeter measurement voltage * 1.414 > U0-05 (error within 10V), then the servo driver is faulty and needs to be sent back for repair | |
| | 1 | E-041 | Driver power down | Driver power off Check the power supply | |
| | 3 | E-043 | Bus Voltage Charging Failure | low voltage of power grid when normal power on Hardware damage low voltage of power grid when normal power on When the driver is on, please pay attention to whether there is relay actuation sound | |
| | 4 | E-044 | Three phase voltage input phase loss | Three phase input power supply is lack of phase Check the power supply | |
| 06 | 0 | E-060 | Module temperature is too high (Module temperature U-06 $\geq 90^{\circ}\text{C}$ alarm, U-06 $\geq 70^{\circ}\text{C}$ Warning) | Running under heavy load for a long time | Re-consider the capacity of the motor, monitor the U0-02 torque during operation, whether it is in the value of more than 100 for a long time, if yes, please chose the large-capacity motor or load reduction. |
| | | | | Excessive ambient temperature | (1) Enhance ventilation measures to reduce ambient temperature; (2) Check whether the fan rotates when the servo is enabled; when the module temperature U-06 $\geq 45^{\circ}\text{C}$, the fan opens. |
| | | | | Fan damage | Replace the fan |
| | 1 | E-061 | Motor overheat | Alarm when motor temperature is higher than 95°C | ① Check whether the motor fan is abnormal ② Contact the manufacturer for technical support |
| | 3 | E-063 | Thermocouple disconnection alarm | ① The motor thermocouple of 11kw and above power is disconnected ② False opening detection and disconnection alarm of motor below 11kw | Check the external thermocouple connection; Shield thermocouple disconnection alarm: P0-69.1 = 1 |
| 08 | 0 | E-080 | Overspeed (actual speed \geq P3-21/P3-22) The maximum forward speed is P3-21 and the maximum reverse speed is P3-22. | Motor code not match | Check if the driver P0-33 is identical with the motor code of the motor label (the number after MOTOR CODE), if not, please change to the same one, then power on again. |
| | | | | UVW wiring error | Inspection of motor UVW wiring, need to be connected in phase sequence. |
| | | | | Motor speed too fast | (1) The maximum speed limit value P3-21/P3-22 was reduced. (2) To confirm whether the external force makes the motor rotate too fast, whether the pulse input frequency is too high, and whether the electronic gear ratio is too large. |
| | | | | Encoder fault | (1) Check the encoder cable or change a new one |

| Type | Code | Description | Reasons | Solutions | |
|------|------|-------------|--|--|---|
| | | | | (2) Set the servo driver to BB state and the driver to U-10. Rotate the motor shaft slowly by hand to see if the value of U-10 changes normally, increasing in one direction and decreasing in one direction (0-9999 cycle display). | |
| | | | Parameter setting | When the actual speed > P3-21/P3-22, it will alarm | |
| 09 | 2 | E-092 | Analog Tref Zero-Calibration Over limit | Analog Zero Calibration Operation Error | Please correct zero without analog voltage |
| | 3 | E-093 | Analog Vref Zero-Calibration Over limit | Analog Zero Calibration Operation Error | Please correct zero without analog voltage |
| 10 | 0 | E-100 | Position offset too large | In position control, the difference between the given position and the actual position exceeds the limit value. | (1) Observe whether the motor is blocked or not. (2) Reducing the given speed of position; (3) Increase the deviation pulse limit P0-23. |
| | 1 | E-101 | Position command mutation | The position difference of every 6K cycle exceeds the command difference alarm value set by P0-70 | (1) Check and modify program (2) Set the appropriate p0-70 value |
| 11 | 0 | E-110 | External UVW Short Circuit Discovered in Self-Inspection | Not match the motor code | Check if the driver P0-33 is identical with the motor code of the motor label (the number after MOTOR CODE), if not, please change to the same one, then power on again. |
| | | | | UVW wiring error | Inspection of motor UVW wiring, need to be in phase sequence (brown U, black V, blue W) |
| | | | | Driver UVW Output Short Circuit or Motor Failure | (1) Measure whether the UVW phase resistance of the motor is balanced. If the phase resistance is unbalanced, replace the motor. (2) Measure whether there is short circuit between UVW and PE of the motor. If there is short circuit, replace the motor. (3) Measure the driver side UVW output through multimeter (diode gear), black pen P+, red pen to measure UVW; red pen P-, black pen to measure UVW; if anyone is 0 in 6 groups of value, replace the driver. |
| | | | | Load part is blocked | It is suggested that the motor should be operated on an empty shaft to eliminate the load problem. |
| | | | | High-speed start-stop instantaneous alarm | Increasing Acceleration and Deceleration Time |
| | | | | Encoder problem | (1) Check the encoder cable or change a new one (2) Set the servo driver to BB state and the driver to U-10. Rotate the motor shaft slowly by hand to see if the value of U-10 changes normally, increasing in one direction and decreasing in one direction (0-9999 cycle display). |

| Type | | Code | Description | Reasons | Solutions |
|--|---|-------|-------------------------------|---|---|
| 13 | 0 | E-150 | Power cable disconnection | Any phase in UVW of driver, cable or motor broken | Disconnect the power supply of the driver and check the connection of the power cable. It is suggested that the multimeter be used to test the condition. After eliminating the errors, the driver should be re-energized. |
| 16 | 1 | E-161 | Driver thermal power overload | Not match the motor code | Check if the driver U3-00 is identical with the motor code of the motor label (the number after MOTOR CODE), if not, please change to the same one, then power on again. |
| | | | | Overload, the actual operating torque exceeds the rated torque, and continuous operation for a long time. (Monitor U0-02 to check the actual operating torque. If the motor is in normal operation, it will not jam or jitter. If the U0-02 is longer than 100, it will be considered improper selection of the motor.) | Increase the capacity of drivers and motors. Extend the acceleration and deceleration time and reduce the load. Monitor the U-00, whether it is running over speed. |
| | | | | Mechanisms are impacted, suddenly weighted and distorted. | Eliminate mechanical distortion. Reduce load |
| | | | | Motor action when motor brake is not opened | Measure the voltage of the brake terminal and decide to open the brake. It is suggested to use servo BK signal to control the brake lock. If it is not servo control, attention must be paid to the timing of brake opening and motor action. |
| | | | | Wrong wiring of encoder cable, power cable or broken wire or loose pin of connector plug | Check the UVW connection of power cable to see if there is any phase sequence error. The multimeter is used to measure whether all the encoder cable are on. Check whether the plug is loose, for machine vibration, whether the plug has shrinkage pin, virtual welding, damage. |
| In multiple mechanical wirings, incorrect connection of motor cable to other shafts leads to incorrect wiring. | Detection of servo wiring, the motor cable, encoder cable are correctly connected to the corresponding shaft. | | | | |
| 16 | 1 | E-161 | Driver thermal power overload | Poor gain adjustment results in motor vibration, back and forth swing and abnormal noise. | Readjustment of gain parameters |
| | | | | Driver or motor hardware failure; | There are servo cross test or motor empty shaft on site, F1-01 trial operation, F1-00 jog run can not rotate uniformly; Replace the new driver or motor and |

| Type | Code | Description | Reasons | Solutions | |
|------|------|-------------|--|---|--|
| | | | | send the malfunction machine back to the manufacturer for repair. | |
| | 5 | E-165 | Anti-blocking alarm Judging that the current motor output torque is greater than P3-28/P3-29 (internal forward/reverse torque limit), and the time reaches P0-74 (unit ms), and the speed is lower than P0-75 (unit 1 rpm). | (1) Machinery is impacted, suddenly becomes heavier and distorted; (2) When the brake of the motor is not opened, the motor moves; (3) The parameter setting is unreasonable. (1) Eliminate the factors of mechanical distortion. Reduce load (2) Measure the voltage of the brake terminal and determine the opening of the brake; It is suggested to use servo BK brake signal to control the brake lock. If it is not servo control, attention must be paid to the timing of brake opening and motor action. (3) Monitor the actual output torque range of U0-02 and check whether the setting of P3-28/29 torque limit is reasonable. (After version 3760, the output torque limit setting parameters of anti locked rotor alarm are P3-38 and P3-39) | |
| 20 | 0 | E-200 | Regenerative resistance overload | High Voltage Fluctuation in Power Grid | Stable the input voltage |
| | | | | Selection of regenerative resistance is too small | Replacement of higher power regenerative resistors (refer to chapter 1.4.1) |
| | | | | Acceleration and deceleration time is too short | Extending Acceleration and Deceleration Time |
| | | | | Hardware damage | The AC gear of the multimeter measures the input value of the servo LN (R/S/T), which is $220V \pm 10\%$ of the normal value. If the power supply voltage is more than $220V+10\%$ ($380V+10\%$), check the power supply voltage; if the power supply voltage is normal, then in servo BB state, monitor U0-05, the voltage measured by the multimeter * $1.414 < U0-05$ (within 10V error), then the servo driver is faulty and needs to be sent back for repair. |
| 22 | 0 | E-220 | Communication error of absolute servo encoder | Motor matching error | Check if the motor matches correctly |
| | | | | Unconnected encoder cable or poor contact | Check whether the value of U0-54 increases rapidly. If yes, the encoder circuit is disconnected. Disconnect the power supply of the driver, check the connection of the encoder cable, if there is cable loosening, it is recommended to use the multimeter to test the conduction condition; after eliminating errors, power on again Hot plugging is strictly prohibited, and special cables are required for tank chains. |
| | | | | Received encoder data errors, and the number of errors exceeds the number of error retries of encoder registers P0-56 | Check whether the value of U0-79 and U0-54 increase. If yes, the encoder is interfered. Encoder wire and strong power do not have the same pipeline wiring; install filter on servo driver power input side; encoder wire sleeves |

| Type | Code | Description | Reasons | Solutions | |
|------|------|-------------|--|---|--|
| | | | | magnetic ring; shut down welding machine type of equipment with large interference | |
| | 1 | E-221 | Too many CRC errors in encoder communication | The received encoder data is wrong and the number of errors exceeds the value in encoder error retry number register P0-56 Encoder interfered, isolate interference source | |
| 22 | 2 | E-222 | Absolute value servo encoder battery low voltage alarm (can shield this alarm) | Battery Voltage in Battery Box of Encoder cable is less than 2.75V Power on alarm for new machine | Please replace the battery while keeping the power supply ON of the servo driver in order to avoid the error of encoder position information. Battery specification: No.5 battery, 3.6V (model CP-B-BATT, CPT-B-BATT) (1) When the absolute value motor is powered off, the memory position depends on the battery on the encoder cable. Once the encoder cable and the motor are disconnected, the power supply can not be carried out, which will lead to the loss of the current position of the motor, it will alarm 222. Please set F0-00=1 to clear the alarm, it can be used normally. (2) The alarm can be shielded by using F0-79. When P0-79 is set to 1, it will be used as a single-loop absolute value motor, and the current position will not be remembered when power off. |
| | | | Data access alarm of absolute value servo encoder | Encoder cable with battery box is not used for multi-turn absolute motor Generally, it is the problem of the encoder itself, or the power supply of the encoder is unstable Abnormal power on of main control chip of multi-turn absolute value servo encoder ADC sampling is out of range, some resistance and capacitance devices have problems or the signal consistency of magnetic sensor is poor | ① Please use encoder cable with battery box; ② Power off and power on again (the driver panel shall be completely off). If the alarm cannot be removed, please contact the agent or manufacturer |
| | 7 | E-227 | Power on encoder multi turn signal data error | Generally, it is the problem of the encoder itself, or the power supply of the encoder is unstable | In the case of no battery, unplugging the encoder cable may cause this alarm. |
| | 8 | E-228 | Absolute value servo encoder value overflow | The motor runs in one direction continuously, the encoder data value is too large, overflow | ① Set F1-06 = 1, clear the absolute encoder's multiple turns; ② Set P0-79 = 2, the alarm can be shielded. |
| | 24 | 0 | E-240 | Timing error in | ① The number of ① Restart driver |

| Type | Code | Description | Reasons | Solutions | |
|------|-------|------------------------------------|--|---|---|
| | | fetching encoder position data | consecutive errors in encoder data update sequence is greater than the value in P0-68 ② CPU timer fluctuates | ② Check the arrangement of transmission cables to ensure that the strong and weak current are wired separately. ③ High current equipment is supplied separately. ④ The grounding is good. | |
| 1 | E-241 | Encoder responding data scrambling | The received encoder data is wrong and the number of errors exceeds the value in encoder error retry number register P0-56 | ① Check the arrangement of transmission cables to ensure that the strong and weak current are wired separately. ② High current equipment is supplied separately. ③ The grounding is good. | |
| 26 | 0 | E-260 | Over range alarm | Overrun signal was detected and the overrun processing mode was configured to alarm | If you do not want to alarm immediately when the overrun occurs, you can change the overrun signal processing mode. |
| | 1 | E-261 | Overrun signal connection error | (1) When the motor is in forward rotation, it encounters reverse overrun signal. (2) When the motor is in reverse rotation, it encounters forward overrun signal. | Check over-run signal connection and over-run terminal allocation. |
| | 2 | E-262 | Control stop timeout | (1) Excessive inertia (2) Stop timeouts too short (3) The setting of braking torque is too small. | (1) Reduce inertia or use brake motor; (2) Increase the stop timeout time P0-30; (3) Increase braking torque P3-32. |

| Type | Code | Explanation | Reason | Solution | |
|------|------|-------------|---------------------------|--|--|
| 26 | 4 | E-264 | Excessive vibration | (1) Oscillation caused by external forces (2) Load inertia is large and the setting of load inertia ratio is wrong or the gain is too small, which leads to the oscillation of positioning. | (1) Check the source of external force to see if there are any problems in mechanical installation; (2) Increase the servo gain to improve the anti-disturbance ability; (3) Acquisition speed curve analysis; When the first three peaks are converged after pulse instruction completed ($0.8 * \text{first peak} > \text{second peak} $ and $0.8 * \text{second peak} > \text{third peak} $), the driver should not alarm, which can adjust the relevant threshold. When the first three peaks speed are not less than 300 rpm for three consecutive times after the completion of the pulse instruction, the driver will alarm. (4) Contact manufacturers for technical support |
| | 5 | E-265 | Excessive motor vibration | Mechanical vibration | Check the motor installation |
| 28 | 0 | E-280 | Failed to read | Request to read | On the premise that the driver and motor |

| | | | | | |
|----|---|-------|--|---|--|
| | | | motor parameters | EEPROM failed | are matched and can be used together, read the alarm shielding position of motor parameters through P0-53, and set the motor code of P0-33 correctly |
| | 1 | E-281 | Error writing data to encoder EEPROM | Request to write EEPROM failed | On the premise that the driver and motor are matched and can be used together, read the alarm shielding position of motor parameters through P0-53, and set the motor code of P0-33 correctly |
| 31 | 0 | E-310 | Power mismatch between driver and motor | Such as 750W driver with 200W motor | Match the correct motor and driver, and use it after setting the P0-33 motor code correctly |
| | 1 | E-311 | When the motor code is read automatically, the motor parameter is 0, and the driver P0-33 = 0 | Motor code not set | On the premise that the driver and motor are matched and can be used together, read the alarm shielding position of motor parameters through P0-53, and set the motor code of P0-33 correctly |
| | 2 | E-312 | Reading motor parameter is damaged | Parameter verification failed CRC | On the premise that the driver and motor are matched and can be used together, read the alarm shielding position of motor parameters through P0-53, and set the motor code of P0-33 correctly |
| | 3 | E-313 | Encoder software version mismatch | Encoder software version mismatch | ① Update driver firmware to maximize current motor parameter performance ② Read the alarm shielding position of motor parameters through p0-53, and set the motor code of P0-33 correctly. At this time, the motor parameters are in the driver, which can work normally, but may affect some performance |
| | 4 | E-314 | Motor code does not match software version | Encoder hardware version is higher than driver firmware version | Contact the manufacturer's technical support to update the driver firmware |
| | 5 | E-315 | When the motor code is read automatically, the motor parameter is 0, and the driver P0-33 \neq 0 | Read the motor code is 0 | On the premise that the driver and motor are matched and can be used together, read the alarm shielding position of motor parameters through P0-53, and set the motor code of P0-33 correctly |
| | 6 | E-316 | Auto-read code error | The auto read motor code is inconsistent with the motor code set in P0-33 | Check U3-00 and motor label. ① If the two values are the same, change P0-33 motor code or set P0-33 to 0 to read motor code automatically; ② If the two values are different, contact the manufacturer for technical support |

Appendix

Appendix 1. Parameter list

Appendix 1.1 Group P parameter list

Modification and effective:

“○” means modifying when servo OFF and take effect at once.

“√” means modifying anytime and take effect at once.


“●” means modifying when servo OFF and take effect when power on again.

“△” means modifying anytime and take effect when the motor doesn't rotate.

“▲” means modifying anytime and take effect when power on again.

For parameters set in hexadecimal system, the prefix "n." is added to the setting value to indicate that the current setting value is hexadecimal number.

Composition of parameters:



P0 parameters

| Parameter | Function | Unit | Default value | Range | Effective | Suitable mode |
|-----------|---|------|--|-------|-----------|---------------|
| P0-00 | Drive type 0 - General Type 1- Canopen type | - | 1 | 0~1 | ○ | All |
| P0-01 | P0-00=0: general type 1-Internal Torque Mode 2-External Analog Torque Mode 3-Internal speed Model 4-External Analog speed Mode 5-Internal Location Mode 6-External Pulse Position Mode 7-External Pulse speed Mode | - | 1 | 1~7 | ○ | All |
| P0-02 | Control mode 2 (the description is the same as above) When the /C-SEL signal is valid, the servo system will switch to the mode selected by P0-02 for operation | - | 0 | 1~7 | ○ | All |
| P0-03 | Enable mode: 0 - not enabled, 1- IO/Son input signal, 2 - software enable (panel / MODBUS) panel F1-05 write 1; Modbus writes 1 to 0x2105 register. Write 0 cancel enable 3- bus enable | - | 1 | 0~3 | ○ | All |
| P0-04 | Rigidity grade | - | 20P1: 0 20P2/20P4 /20P7: 15 >=21P5: 10 | 0~63 | △ | All |
| P0-05 | Rotation direction selection | - | 0 | 0~1 | ● | All |

| Parameter | Function | Unit | Default value | Range | Effective | Suitable mode |
|----------------|--|-----------|-----------------------------|----------------|-------------------------------------|---------------|
| P0-07 | First inertia ratio | 1% | 500 | 0~50000 | √ | All |
| P0-09.0 | Forward Direction of Input Pulse Instruction 0-Forward Pulse Counting 1-Reverse Pulse Counting | - | 0 | 0~1 | ● | 6, 7 |
| P0-09.2 | Input pulse command filter time | - | F | 0~F | ● | 6, 7 |
| P0-09.3 | Predistribution of input pulse command filter | - | 0 | 0~7 | ● | 6, 7 |
| P-10.0 xxx□ | 0-CW/CCW 1-AB 2-P+D | - | 2 | 0~2 | ○ | 6, 7 |
| P0-11 | Pulse per rotation low bit ×1 | - | 0 | 0~9999 | ○ | 5, 6 |
| P0-12 | Pulse per rotation high bit ×10000 | - | 1 | 0~65535 | ○ | 5, 6 |
| P0-13 | Electronic Gear Numerator | - | 1 | 1~65535 | ○(before 3770) √(3770 and later) | 5, 6 |
| P0-14 | Denominator of Electronic Gear | - | 1 | 1~65535 | ○ | 5, 6 |
| P0-15 | Pulse frequency corresponding to rated speed in speed mode | 100Hz | 1000 | 0~10000 | ○ | 7 |
| P0-16 | Speed command pulse filter time | 0.01ms | 100 | 0~10000 | ○ | 7 |
| P0-23 | pulse offset limit | 0.01 turn | 2000 | 0~65535 | √ | 5, 6 |
| P0-24 | 0 - cumulative discharge time 1 - average power mode 1 2-average power mode 2 | - | 0 | 0~1 | ○ | All |
| P0-25 | Power Value of Discharge Resistance | W | Related to the driver power | 0~65535 | ○ | All |
| P0-26 | Discharge resistance value | Ω | | 1~500 | ○ | All |
| P0-27 | Servo shutdown the enable stop mode 0-Inertial Operation Stop 2-deceleration stop | - | 0 | 0, 2 | ○ | All |
| P0-28 | Servo Overrun Stop Mode (P0-28.0) 0-deceleration stop 1 1-Inertial Stop 2-deceleration stop 2 3-Alarm Stop Overtravel alarm shield switch (P0-28.1) 0-not shield the alarm 1-shield the alarm | - | 0 | 0~3 | ○ | All |
| P0-29 | Servo Alarm Stop Mode 0-Inertial Operation Stop 2-deceleration stop | - | 0 | 0、2 | ○ | All |
| P0-30 | stop timeout time | 1ms | 20000 | 0~65535 | ○ | All |
| P0-31 | Deceleration stop time | 1ms | 25 | 0~5000 | ○ | All |
| P0-33 | Set the motor code | - | | 0~65535 | ● | All |
| P0-53 | Read motor parameter alarm shield bit 0-not shield alarm shield alarm 1- Shield the alarm of not read valid motor parameter | - | 0 | 0/1 | ● | All |
| P0-55 | Open loop rotation speed | - | 0 | - 6000~6000 | | All |

| Parameter | Function | Unit | Default value | Range | Effective | Suitable mode |
|-----------------------------|---|------|---------------|-----------|-----------|---------------|
| P0-56 | Number of encoder communication attempts | - | 10 | 1~65535 | | All |
| P0-68.0~ P0-68.1 xx□□ | Number of continuous error alarms in the update sequence of coded data | | 0x05 | 0x01~0xFF | | All |
| P0-68.2~ P0-68.3 □□xx | E-241 alarm filter times | - | 0 | 0~0xFF | | All |
| P0-69 | Fan switch (P0-69.0) 0- Turn on the fan when the temperature greater than 45°C and turn off the fan when less than 42°C (hysteresis 3°C) 1 - Turn on the fan after enabling, turn off the fan when not enabling Large motor thermocouple break alarm shield switch (P0-69.1) 0-not shield thermocouple disconnection alarm 1-shield thermocouple disconnection alarm | - | 1 | 0/1 | √ | All |
| P0-74 | Blocking alarm time | 1ms | 0 | 0-65535 | √ | All |
| P0-75 | Blocking alarm speed | 1rpm | 50 | 5~9999 | √ | All |
| P0-79 | Absolute Encoder Battery Undervoltage Alarm Switch 0-used as absolute value encoder 1-used as incremental encoder used as absolute value encoder, ignoring multi turn overflow alarm | - | 1 | 0~2 | ● | All |
| P0-80 | Thermal Power Protection of Motor 0-current protection 1-Average Thermal Power Protection 2-Analog Thermal Power Protection | - | 2 | 0~2 | ● | All |
| P0-92~ P0-93 | 32-bit electronic gear ratio numerator. take effect when P0-11~P0-14 is 0. P0-92*1 + P0-93 *10000 | - | 1 | 1~9999 | ○ | 5, 6 |
| | | | 1 | 1~65535 | | |
| P0-94~ P0-95 | 32-bit electronic gear ratio denominator. take effect when P0-11~P0-14 is 0. P0-94*1 + P0-95 *10000 | - | 1 | 1~9999 | ○ | 5, 6 |
| | | | 1 | 1~65535 | | |

P1 parameters

| Parameter | Function | Unit | Default value | Range | Effective | Suitable mode |
|-----------|--|--------|----------------------------|----------|-----------|---------------|
| P1-00 | First speed loop gain | 0.1Hz | 20P1: 400 Others: 200 | 10~20000 | √ | All |
| P1-01 | Integral Time Constant of the First Speed Loop | 0.01ms | 20P1: 1650 Others: 3300 | 15~51200 | √ | All |
| P1-02 | First position loop gain | 0.1/s | 20P1: 400 Others: 200 | 10~20000 | √ | All |
| P1-10 | Speed feedforward gain | 1% | 0 | 0~300 | √ | 5 6 7 |
| P1-11 | Speed feedforward filter time | 0.01ms | 50 | 0~10000 | √ | 5 6 7 |
| P1-14 | Gain switching mode setting | - | 0 | 0~0x00A2 | √ | All |
| P1-15 | Gain switching waiting time | - | 5 | 0~1000 | √ | All |

| Parameter | Function | Unit | Default value | Range | Effective | Suitable mode |
|-----------|--|-------|---------------|---------|-----------|---------------|
| P1-16 | Gain switching level threshold | - | 50 | 0~20000 | √ | All |
| P1-17 | Gain switching level hysteresis | - | 30 | 0~20000 | √ | All |
| P1-18 | Position loop gain switching time | - | 3 | 0~1000 | √ | All |
| P1-22 | Speed Instruction Filter Selection 0-first order low pass filter 1-Smooth Average Filter | - | 0 | 0~1 | ○ | 3 4 7 |
| P1-23 | speed instruction filter time | 0.1ms | 0 | 0~65535 | ○ | 3 4 7 |
| P1-24 | Position command acceleration and deceleration filtering time | 0.1ms | 0 | 0~65535 | △ | 5 6 |
| P1-25 | position instruction smooth filter time | 0.1ms | 0 | 0~65535 | △ | 5 6 |
| P1-74 | Encoder zero offset detection cycle | - | 1000 | 0~65535 | √ | All |
| P1-75 | Encoder zero offset detection threshold | - | 10 | 0~500 | √ | All |

P2 parameters

| P2-XX | Function | Unit | Default value | Range | Effective | Suitable mode |
|---------|--|-------|--|---------|-----------|---------------|
| P2-00.0 | Disturbance observer switch 0- OFF 1- ON | - | 0 | 0~1 | ○ | All |
| P2-01.0 | Adaptive mode switch 0-OFF 1-ON | - | 0 | 0~1 | ● | All |
| P2-01.1 | Adaptive level 0-high response 1-low noise | - | According to the model | 0~1 | ● | All |
| P2-02.0 | Auto-tuning mode 1-soft 2-fast positioning 3-fast positioning, control the overshoot | - | 3 | 1~3 | √ | All |
| P2-02.2 | Load type (valid only during auto-tuning) 1- synchronous belt 2- screw rod 3-Rigid Connection | - | 2 | 1~3 | √ | All |
| P2-03.3 | Adaptive load type 0-Small Inertia Mode 1-Large Inertia Mode | - | 0 | 0~1 | ● | All |
| P2-05 | Adaptive mode speed loop gain (standard) | 0.1Hz | 20P1/20P2/ 20P4/20P7: 400 ≥21P5: 200 | 1~65535 | ○ | All |
| P2-07 | Adaptive mode inertia ratio (standard) | % | 0 | 0~10000 | ○ | All |
| P2-08 | Gain of adaptive mode speed observer (standard) | Hz | 20P1/20P2/ 20P4/20P7: 60 ≥21P5: 40 | 10~1000 | ○ | All |
| P2-12 | Maximum Inertia Ratio of Adaptive Mode (Standard) | - | 30 | 1~10000 | ○ | All |
| P2-15 | Inertia Identification and Internal Instruction Auto-tuning Maximum Travel | 0.01r | 100 | 1~3000 | √ | All |
| P2-17 | Maximum Speed of Inertia Identification and Internal Instruction Auto-tuning | - | 0 | 0~65535 | √ | All |

| P2-XX | Function | Unit | Default value | Range | Effective | Suitable mode |
|---------|--|--------|---|--------------|-----------|---------------|
| P2-18 | Initial inertia ratio of inertia identification | % | 500 | 1~20000 | √ | All |
| P2-19 | Adaptive mode bandwidth | % | 20P1: 100 20P2/20P4: 70 ≥20P7: 50 | 1~100 | ○ | All |
| P2-35 | Torque Instruction Filtering Time Constant 1 | 0.01ms | 100 | 0~65535 | √ | All |
| P2-36 | Torque Instruction Filtering Time Constant 2 | 0.01ms | 100 | 0~65535 | √ | All |
| P2-41 | Disturbance Torque Compensation Coefficient (Non-adaptive Mode Effective) | % | 85 | 0~100 | √ | All |
| P2-47.0 | Model Loop Switch 0-OFF 1-ON | - | 1 | 0~f | √ | All |
| P2-49 | Model loop gain | 0.1Hz | 500 | 10~20000 | √ | 3 4 5 6 7 |
| P2-60.0 | Active Vibration Suppression Switch 0-OFF 1-ON | - | 0 | 0~1 | √ | 3 4 5 6 7 |
| P2-60.1 | Active Suppression Auto-tuning Switch 0-Active Vibration Suppression is not Configured in auto-tuning 1- configure the Active Vibration Suppression when auto-tuning | - | 1 | 0~1 | √ | 3 4 5 6 7 |
| P2-61 | Active Vibration Suppression frequency | 0.1Hz | 10000 | 10~20000 | √ | All |
| P2-62 | Active Vibration Suppression gain | % | 100 | 1~1000 | √ | All |
| P2-63 | Active Vibration Suppression damping | % | 100 | 0~300 | √ | All |
| P2-64 | Active vibration suppression frequency 1 | - | 0 | -10000~10000 | √ | All |
| P2-65 | Active vibration suppression frequency 2 | - | 0 | -10000~10000 | √ | All |
| P2-69.0 | Notch filter 1 switch | - | 0 | 0~1 | √ | All |
| P2-69.1 | Notch filter 2 switch | - | 0 | 0~1 | √ | All |
| P2-69.3 | Notch filter 3 switch | - | 0 | 0~1 | √ | All |
| P2-70.0 | Notch filter 4 switch | - | 0 | 0~1 | √ | All |
| P2-70.1 | Notch filter 5 switch | - | 0 | 0~1 | √ | All |
| P2-71 | First notch frequency | Hz | 5000 | 50~5000 | √ | All |
| P2-72 | First notch attenuation | 0.1dB | 70 | 50~1000 | √ | All |
| P2-73 | First notch band width | Hz | 0 | 0~1000 | √ | All |
| P2-74 | Second notch frequency | Hz | 5000 | 50~5000 | √ | All |
| P2-75 | Second notch attenuation | 0.1dB | 70 | 50~1000 | √ | All |
| P2-76 | Second notch band width | Hz | 0 | 0~1000 | √ | All |
| P2-77 | Third notch frequency | Hz | 5000 | 50~5000 | √ | All |
| P2-78 | Third notch attenuation | 0.1dB | 70 | 50~1000 | √ | All |
| P2-79 | Third notch band width | Hz | 0 | 0~1000 | √ | All |
| P2-80 | Fourth notch frequency | Hz | 5000 | 50~5000 | √ | All |
| P2-81 | Fourth notch attenuation | 0.1dB | 70 | 50~1000 | √ | All |
| P2-82 | Fourth notch band width | Hz | 0 | 0~1000 | √ | All |
| P2-83 | Fifth notch frequency | Hz | 5000 | 50~5000 | √ | All |
| P2-84 | Fifth notch attenuation | 0.1dB | 70 | 50~1000 | √ | All |
| P2-85 | Fifth notch band width | Hz | 0 | 0~1000 | √ | All |

P3 parameters

| P3-XX | Function | Unit | Default value | Range | Effective | Suitable mode |
|-------|---|------|---------------|------------|-----------|---------------|
| P3-05 | Preset speed 1 | rpm | 0 | -9999~9999 | √ | 3 |
| P3-06 | Preset speed 2 | rpm | 0 | -9999~9999 | √ | 3 |
| P3-07 | Preset speed 3 | rpm | 0 | -9999~9999 | √ | 3 |
| P3-09 | Acceleration time | ms | 0 | 0~65535 | ○ | 3 4 7 |
| P3-10 | Deceleration time | ms | 0 | 0~65535 | ○ | 3 4 7 |
| P3-12 | Zero-speed clamping mode | - | 0 | 0~3 | ○ | 3 4 7 |
| P3-13 | Zero-speed clamping speed | rpm | 10 | 0~300 | ○ | 3 4 7 |
| P3-14 | Forward Maximum Speed Instruction Limit | rpm | 4000 | 0~10000 | ○ | All |
| P3-15 | Reverse Maximum Speed Instruction Limit | rpm | 4000 | 0~10000 | ○ | All |
| P3-16 | Internal Forward Speed Limitation in Torque Control | rpm | 2000 | 5~10000 | √ | 1 2 |
| P3-17 | Internal Reverse Speed Limitation in Torque Control | rpm | 2000 | 5~10000 | √ | 1 2 |
| P3-18 | Jogging speed | rpm | 100 | 0~1000 | ○ | All |
| P3-19 | forward warning speed | rpm | 3000 | 0~10000 | ○ | All |
| P3-20 | reverse warning speed | rpm | 3000 | 0~10000 | ○ | All |
| P3-21 | forward alarming speed | rpm | 4000 | 0~10000 | ○ | All |
| P3-22 | reverse alarming speed | rpm | 4000 | 0~10000 | ○ | All |
| P3-28 | Internal forward torque limit | % | 300 | 0~1000 | √ | All |
| P3-29 | Internal reverse torque limit | % | 300 | 0~1000 | √ | All |
| P3-30 | external forward torque limit | % | 300 | 0~1000 | √ | All |
| P3-31 | external reverse torque limit | % | 300 | 0~1000 | √ | All |
| P3-32 | Brake torque | 1% | 300 | 0~1000 | √ | All |
| P3-33 | Preset torque | % | 0 | -1000~1000 | √ | 1 |
| P3-45 | Torque mode switching delay | ms | 40 | 0~9999 | √ | 1 2 |

P4 parameters

| P4-XX | Function | Unit | Default value | Range | Effective | Suitable mode |
|---------|---|------|---------------|---------|-----------|---------------|
| P4-00.0 | Z phase signal numbers The Z phase signal numbers after leaving the limit switch (note: stop when N+1 Z phase signal reached) | ↑ | 2 | 0~f | ○ | 5 6 |
| P4-00.1 | Search the origin function 0-OFF 1-ON | - | 0 | 0~1 | ○ | 5 6 |
| P4-00.2 | homing overrun prohibition 0-not prohibit 1-prohibit | - | 0 | 0~1 | ○ | 5 6 |
| P4-01 | Speed of hitting the proximity switch | rpm | 600 | 0~65535 | ○ | 5 6 |
| P4-02 | Speed of leaving proximity switch | rpm | 100 | 0~65535 | ○ | 5 6 |
| P4-03.0 | Internal Location Given Mode Sets Location Mode 0-relative positioning 1-Absolute positioning | - | 0 | 0~1 | ○ | 5 |
| P4-03.1 | Internal Position-Given Mode Sets Step Change Mode 0-step-changing when signal is ON, recyclable 1-change step at signal rising edge, single step execution | - | 0 | 0~5 | ○ | 5 |

| P4-XX | Function | Unit | Default value | Range | Effective | Suitable mode |
|--|--|--------|---------------|--------------------------|-----------|---------------|
| | 2-starting at Signal rising edge, sequential execution of all, no cycle 3-set segment no. through communication 4-/CHSTP dual edge triggerring 5-Terminal/PREFA(P5-57), /PREFB(P5-58), /PREFC (P5-59) select the segment no., range 1~3 | | | | | |
| P4-03.2 | Internal position mode sets waiting mode 0-wait positioning completion 1-not wait positioning completion | - | 0 | 0~1 | ○ | 5 |
| P4-04 | Valid segment number | - | 0 | 0~35 | ○ | 5 |
| P4-10~ P4-11 | Internal position mode start segment No | 1pul | 0 | -327689999~ 327679999 | √ | 5 |
| P4-12 | First segment pulse | 0.1rpm | 0 | 0~65535 | √ | 5 |
| P4-13 | First segment speed | 1ms | 0 | 0~65535 | √ | 5 |
| P4-14 | First segment acceleration time | 1ms | 0 | 0~65535 | √ | 5 |
| P4-16 | First segment deceleration time | 1ms | 0 | 0~65535 | √ | 5 |
| P4-10+ (n-1)*7 ~ P4-16+ (n-1)*7 | Adjusting time | - | - | - | √ | 5 |

Note:
(1) setting pulse number=pulse number (high bit)×10000 + pulse number (low bit)
(2) 35 sections in total; The parameters of sections 1 ~ 12 can be set through the panel, and the parameters of sections 13 ~ 35 need to be written through communication (RS232 and RS485).

P5 parameters

| P5-XX | Function | Unit | Default value | Range | Effective | Suitable mode |
|-------|---|-------------------------------|---------------|------------|-----------|---------------|
| P5-00 | Positioning completion width/COIN | Command unit | 11 | 1~65535 | √ | 5 6 |
| P5-01 | Location Completion Detection Mode | - | 0 | 0~3 | √ | 5 6 |
| P5-02 | Location completion retention time | ms | 0 | 0~65535 | √ | 5 6 |
| P5-03 | Rotation Detection Speed | rpm | 50 | 0~10000 | √ | All |
| P5-04 | Same speed detection speed | rpm | 50 | 0~10000 | √ | All |
| P5-05 | Reached detection speed | rpm | 1000 | 0~10000 | √ | All |
| P5-06 | Positioning near output width | Command unit | 50 | 0~65535 | √ | 5 6 |
| P5-07 | Servo OFF delay time | ms | 500 | 0~65535 | ○ | All |
| P5-08 | Brake instruction output speed | rpm | 30 | 20~10000 | ○ | All |
| P5-09 | Brake instruction waiting time | ms | 500 | 0~65535 | ○ | All |
| P5-10 | user-defined output 1 trigger condition | - | 0 | 0~ffff | √ | All |
| P5-11 | Set a value that compares with the trigger condition of custom output 1 | Relating to trigger condition | 0 | -9999~9999 | √ | All |
| P5-12 | Select custom output 1 mode | - | 0 | 0~3 | √ | All |
| P5-13 | Setting custom output 1 hysteresis | Relating to trigger condition | 0 | 0~65535 | √ | All |
| P5-14 | Custom Output 2 Trigger Condition | - | 0 | 0~ffff | √ | All |
| P5-15 | Set a value that compares with the trigger condition of custom output 2 | Relating to trigger condition | 0 | -9999~9999 | √ | All |
| P5-16 | Select custom output 2 mode | - | 0 | 0~3 | √ | All |
| P5-17 | Setting custom output 2 hysteresis | Relating to trigger condition | 0 | 0~65535 | √ | All |
| P5-18 | IO filter time multiple | - | 1 | 0~10000 | √ | All |
| P5-19 | Z phase output maintain time | ms | 2 | 1~65535 | √ | All |

| P5-XX | Function | Unit | Default value | Range | Effective | Suitable mode |
|-----------|---|------|---------------|-------|-----------|---------------|
| P5-20.0~1 | /S-ON: servo signal 00: Set the signal to be invalid all the time. 01: Input positive signal from SI1 terminal. 02: Input positive signal from SI2 terminal. 03: Input positive signal from SI3 terminal. 04: Input positive signal from SI4 terminal. 10: Set the signal to always be "valid". 11: Inverse signal is input from SI1 terminal. 12: Inverse signal is input from SI2 terminal. 13: Inverse signal is input from SI3 terminal. 14: Inverse signal is input from SI4 terminal. | - | 01 | 0~ff | √ | All |
| P5-20.2 | SI terminal filtering time | ms | 0 | 0~f | √ | All |
| P5-21.0~1 | /P-CON proportion action instruction | - | 00 | 0~ff | √ | All |
| P5-21.2 | SI terminal filtering time | ms | 0 | 0~f | √ | All |
| P5-22.0~1 | /P-OT: Forbidden forward driving | - | 01 | 0~ff | √ | All |
| P5-22.2 | SI terminal filtering time | ms | 0 | 0~f | √ | All |
| P5-23.0~1 | /N-OT: forbidden reverse driving | - | 02 | 0~ff | √ | All |
| P5-23.2 | SI terminal filtering time | ms | 0 | 0~f | √ | All |
| P5-24.0~1 | /ALM-RST: alarm clear | - | 00 | 0~ff | √ | All |
| P5-24.2 | SI terminal filtering time | ms | 0 | 0~f | √ | All |
| P5-25.0~1 | /P-CL: External Torque Limitation at Forward Rotation Side | - | 00 | 0~ff | √ | All |
| P5-25.2 | SI terminal filtering time | ms | 0 | 0~f | √ | All |
| P5-26.0~1 | /N-CL: External Torque Limitation at Reverse Rotation Side | - | 00 | 0~ff | √ | All |
| P5-26.2 | SI terminal filtering time | ms | 0 | 0~f | √ | All |
| P5-27.0~1 | /SPD-D: Internal Speed Direction Selection | - | 03 | 0~ff | √ | 1 2 3 4 7 |
| P5-27.2 | SI terminal filtering time | ms | 0 | 0~f | √ | 1 2 3 4 7 |
| P5-28.0~1 | /SPD-A: Internal Setting Speed Selection | - | 00 | 0~ff | √ | 3 5 |
| P5-28.2 | SI terminal filtering time | ms | 0 | 0~f | √ | 3 5 |
| P5-29.0~1 | /SPD-B: Internal Setting Speed Selection | - | 00 | 0~ff | √ | 3 5 |
| P5-29.2 | SI terminal filtering time | ms | 0 | 0~f | √ | 3 5 |
| P5-30.0~1 | /C-SEL: control mode selection | - | 00 | 0~ff | √ | All |
| P5-30.2 | SI terminal filtering time | ms | 0 | 0~f | √ | All |
| P5-31.0~1 | /ZCLAMP: zero position clamping | - | 00 | 0~ff | √ | 3 4 7 |
| P5-31.2 | SI terminal filtering time | ms | 0 | 0~f | √ | 3 4 7 |
| P5-32.0~1 | /INHIBIT: Instruction pulse prohibition | - | 00 | 0~ff | √ | 5 6 7 |
| P5-32.2 | SI terminal filtering time | ms | 0 | 0~f | √ | 5 6 7 |
| P5-33.0~1 | /CLR: pulse offset clear | - | 00 | 0~ff | √ | All |
| P5-33.2 | SI terminal filtering time | ms | 0 | 0~f | √ | All |
| P5-34.0~1 | /ZCLAMP: zero position clamping | - | 00 | 0~ff | √ | 5 6 |

| P5-XX | Function | Unit | Default value | Range | Effective | Suitable mode |
|-----------|--|------|---------------|--------|-----------|---------------|
| P5-34.2 | SI terminal filtering time | ms | 0 | 0~f | √ | 5 6 |
| P5-35.0~1 | /CHGSTP: internal position mode change step signal | - | 00 | 0~ff | √ | 5 |
| P5-35.2 | SI terminal filtering time | ms | 0 | 0~f | √ | 5 |
| P5-36.0~1 | /I-SEL: inertia ratio switching | - | 00 | 0~ff | √ | All |
| P5-36.2 | SI terminal filtering time | ms | 0 | 0~f | √ | All |
| P5-37 | /COIN_HD: Location Completion Maintenance 00: No output to terminal 01: Output positive signal from SO1 terminal 02: Output positive signal from SO2 terminal 03: Output positive signal from SO3 terminal 11: Output reverse signal from SO1 terminal 12: Output reverse signal from SO2 terminal. 13: Output reverse Signal from SO3 terminal | - | 0000 | 0~ffff | √ | 5 6 |
| P5-38 | /COIN: positioning completion | - | 0001 | 0~ffff | √ | 5 6 |
| P5-39 | /V-CMP: same speed detection | - | 0000 | 0~ffff | √ | 3 4 7 |
| P5-40 | /TGON: rotation detection | - | 0000 | 0~ffff | √ | All |
| P5-41 | /S-RDY: ready | - | 0000 | 0~ffff | √ | All |
| P5-42 | /CLT: torque limit | - | 0000 | 0~ffff | √ | All |
| P5-43 | /VLT: speed limit detection | - | 0000 | 0~ffff | √ | 1 2 |
| P5-44 | /BK: brake locking | - | 0000 | 0~ffff | ○ | All |
| P5-45 | /WARN: warning | - | 0000 | 0~ffff | √ | All |
| P5-46 | /NEAR: near | - | 0000 | 0~ffff | √ | 5 6 |
| P5-47 | /ALM: alarm | - | 0002 | 0~ffff | √ | All |
| P5-48 | /Z: encoder Z phase signal output | - | 0000 | 0~ffff | √ | All |
| P5-50 | /MRUN: internal position mode motion starting signal | - | 0000 | 0~ffff | √ | 5 |
| P5-51 | /V-RDY: speed reached | - | 0000 | 0~ffff | √ | 3 4 7 |
| P5-52 | /USER1: user-defined output 1 | - | 0000 | 0~ffff | √ | All |
| P5-53 | /USER2: user-defined output 2 | - | 0000 | 0~ffff | √ | All |
| P5-57 | /PREFA: internal position selection signal A | - | 0 | ※1 | √ | 5 |
| P5-58 | /PREFB: internal position selection signal B | — | 0 | ※1 | √ | 5 |
| P5-59 | /PREFC: internal position selection signal C | — | 0 | ※1 | √ | 5 |
| P5-61.0~1 | /TRAJ-START: Motion start trigger signal | - | 00 | 0~ff | √ | 5 |
| P5-70 | /SRDY: Output Conditions Selection 0: This terminal is turned on after initialization of the driver is completed 1: This terminal will not turn on until enabled. | - | 0 | 0~1 | √ | All |
| P5-71 | Function Selection of Directional Terminal of Pulse Speed Mode | - | 0 | 0~1 | √ | 7 |

P6 signal parameters (Some parameters are reserved)

| P6-XX | Function | Unit | Default value | Range | Effective | Suitable mode |
|-------|--|-------|---------------|---------|-----------|---------------|
| P6-05 | Adaptive Mode Speed Loop Gain (Large Inertia) | 0.1Hz | 200 | 1~65535 | ○ | 1 2 3 4 5 6 7 |
| P6-07 | Adaptive mode inertia ratio (Large inertia) | % | 50 | 0~10000 | ○ | 1 2 3 4 5 6 7 |
| P6-08 | Gain of adaptive mode speed observer (large inertia) | Hz | 40 | 10~1000 | ○ | 1 2 3 4 5 6 7 |
| P6-12 | Maximum Inertia Ratio of Adaptive Mode (Large Inertia) | - | 50 | 1~10000 | ○ | 1 2 3 4 5 6 7 |

Communication parameters Group P7

| P7-XX | Name | Unit | Default | Range | Effective |
|-----------|--|------------|---------|-------|-----------|
| P7-10 | RS232 station no. | - | 1 | 0~100 | ○ |
| P7-11.0~1 | RS232 baud rate 00: 300 01: 600 02: 1200 03: 2400 04: 4800 05: 9600 06: 19200 07: 38400 08: 57600 09: 115200 0A: 192000 0B: 256000 0C: 288000 0D: 384000 0E: 512000 0F: 576000 10: 768000 11: 1M 12: 2M 13: 3M 14: 4M 15: 5M 16: 6M | Baud rate | 06 | 0~16 | ○ |
| P7-11.2 | RS232 stop bit 0: 2 bits 2: 1 bit | Stop bit | 2 | 0~2 | ○ |
| P7-11.3 | RS232 parity bit 0: no parity 1: odd parity 2: even parity | Parity bit | 2 | 0~2 | ○ |
| P7-30 | CAN bus communication station no. | - | 1 | 1~64 | ● |
| P7-31 | CAN bus baud rate 00: 100000 01: 125000 02: 250000 03: 500000 04: 750000 05: 1000000 | bps | 5 | 0~5 | ● |

| P8-XX | Name | Unit | Default value | Range | Effective | Suitable mode |
|-------|--|------|---------------|-------|-----------|---------------|
| P8-25 | Panel display selection (3770 and later version support) | - | 0 | 0~2 | ▲ | All |

Table 1 input signal distribution

| Input terminal parameter | Servo model | Range |
|----------------------------|--------------|--------------------------------|
| P5-20~P5-36 P5-57~P5-59 | DS5N1 series | n.0000~n.0003 n.0010~n.0013 |

Table 2 output signal distribution

| Output terminal parameter | Servo model | Range |
|---------------------------|--------------|--------------------------------|
| P5-37~P5-53 | DS5N1 series | n.0000~n.0003 n.0010~n.0013 |

Appendix 1.2 Group F parameters

| Function code | Explanation |
|---------------|-----------------------------------|
| F0-00 | Clear alarm |
| F0-01 | Factory reset |
| F0-02 | Clear position offset |
| F1-00 | Jog run |
| F1-01 | Test run |
| F1-02 | Current sampling zero calibration |
| F1-05 | Panel enable |
| F1-06 | Absolute encoder turns reset |

Appendix 1.3 Group U monitor parameters

U0-XX:

| Code | Contents | Unit |
|-------|---------------------------------|---------------------|
| U0-00 | servo motor speed | Rpm |
| U0-01 | Input speed instruction | Rpm |
| U0-02 | Torque instruction | % rated |
| U0-03 | Mechanical angle | 1° |
| U0-04 | Electric angle | 1° |
| U0-05 | Bus voltage | V |
| U0-06 | IPM temperature | 0.1°C |
| U0-07 | Torque feedback | % rated |
| U0-08 | pulse offset | (0000~9999) *1 |
| U0-09 | | (0000~9999) *10000 |
| U0-10 | Encoder feedback | (0000~9999) *1 |
| U0-11 | Encoder feedback | (0000~65535) *10000 |
| U0-12 | input instruction pulse numbers | (0000~9999) *1 |
| U0-13 | | (0000~9999) *10000 |
| U0-14 | position feedback | (0000~9999) *1 |
| U0-15 | | (0000~9999) *10000 |
| U0-16 | encoder accumulated position | (0000~9999) *1 |
| U0-17 | | (0000~9999) *10000 |
| U0-18 | Torque current | 0.01A |
| U0-19 | Analog input V-REF value | 0.001V |
| U0-20 | Analog input T-REF value | 0.001V |
| U0-21 | Input signal status 1 | |
| U0-22 | Input signal status 2 | |
| U0-23 | output signal status 1 | |
| U0-24 | output signal status 2 | |
| U0-25 | Input pulse frequency | (0000~9999) *1 |
| U0-26 | | (0000~9999) *10000 |
| U0-41 | Instantaneous output power | 1W |

| Code | Contents | Unit |
|-------|--|----------------|
| U0-42 | Average output power | 1W |
| U0-43 | Instantaneous thermal power | 1W |
| U0-44 | average thermal power | 1W |
| U0-49 | position feedforward | 1 command unit |
| U0-50 | speed feedforward | rpm |
| U0-51 | torque feedforward | % rated |
| U0-52 | Instantaneous Bus Capacitor Power | 1W |
| U0-53 | Average Bus Capacitor Power | 1W |
| U0-55 | Discharge power of instantaneous regenerative braking | 1W |
| U0-56 | Average regenerative brake discharge power | 1W |
| U0-57 | Absolute encoder present position feedback low 32-bit | Encoder pulse |
| U0-58 | | |
| U0-59 | Absolute encoder present position feedback high 32-bit | Encoder pulse |
| U0-60 | | |
| U0-89 | Position command end flag | |
| U0-91 | Multi-turn absolute motor circles | |
| U0-98 | High power motor temperature | 0.1°C |

U1-XX:

| Code | Contents | Unit |
|-------|--|-------------------|
| U1-00 | present alarm code | |
| U1-01 | present warning code | |
| U1-02 | U phase current when alarming | 0.01A |
| U1-03 | V phase current when alarming | 0.01A |
| U1-04 | bus voltage when alarming | V |
| U1-05 | IGBT temperature when alarming | 0.1°C |
| U1-06 | torque current when alarming | 0.01A |
| U1-07 | excitation current when alarming | A |
| U1-08 | position offset when alarming | Instruction pulse |
| U1-09 | speed when alarming | rpm |
| U1-10 | Seconds(low 16-bit) when alarming, cumulated seconds from the first time power-on | s |
| U1-11 | Seconds(high 16-bit) when alarming, cumulated seconds from the first time power-on | s |
| U1-12 | this time running error numbers, counting after power on this time | |
| U1-13 | this time operation warning numbers, counting after power on this time | |
| U1-14 | historical alarm amounts | |
| U1-15 | historical warning amounts | |
| U1-16 | Recent 2nd alarm code | |
| U1-17 | Recent 3rd alarm code | |
| U1-18 | Recent 4th alarm code | |
| U1-19 | Recent 5th alarm code | |
| U1-20 | Recent 6th alarm code | |
| U1-21 | Recent 2nd warning code | |
| U1-22 | Recent 3rd warning code | |
| U1-23 | Recent 4th warning code | |
| U1-24 | Recent 5th warning code | |
| U1-25 | Recent 6th warning code | |

U2-XX:

| Code | Contents | Unit |
|-------|----------------------------|------|
| U2-00 | Power on times | - |
| U2-01 | series | - |
| U2-02 | Model (low 16-bit) | - |
| U2-03 | Model (high 16-bit) | - |
| U2-04 | out of factory date: year | - |
| U2-05 | out of factory date: month | - |

| | | |
|-------|---|--------------------|
| U2-06 | out of factory date: day | - |
| U2-07 | Firmware version | - |
| U2-08 | Hardware version | - |
| U2-09 | Total running time (from the first time power on) | hour |
| U2-10 | Total running time (from the first time power on) | minute |
| U2-11 | Total running time (from the first time power on) | second |
| U2-12 | This time running time (from this time power on) | hour |
| U2-13 | This time running time (from this time power on) | minute |
| U2-14 | This time running time (from this time power on) | second |
| U2-15 | Average output power (from the first time enabled, average power in the process of enabling) | 1W |
| U2-16 | Average thermal power (from the first time enabled, average power in the process of enabling) | 1W |
| U2-17 | Average bus capacitor filter power (from the first time power on, average power in the process of power on) | 1W |
| U2-18 | Cumulative turns of motor | (0000~9999) *1 |
| U2-19 | | (0000~9999) *10000 |
| U2-20 | Device serial no.: low 16-bit | |
| U2-21 | Device serial no.: high 16-bit | |
| U2-22 | Firmware generation date: year | |
| U2-23 | Firmware generation date: month/day | |
| U2-24 | Firmware generation date: hour/minute | |

U3-XX:

| Code | Contents | Unit |
|-------|---|------|
| U3-00 | Motor code (including thermal power parameters) read automatically by driver | - |
| U3-01 | Motor version | - |
| U3-02 | Encoder version | - |
| U3-70 | Automatically read the motor code of the encoder in the motor parameters (only related to the motor code) | - |

U4-XX:

| Code | Contents | Unit |
|-------|--|------|
| U4-10 | Resonance frequency detected by fast FFT | Hz |
| U4-16 | Cumulative value of continuous overload operation of thermal power protection | - |
| U4-17 | Cumulative value of instantaneous overload operation of thermal power protection | - |

Appendix 2. Term set

| Abbreviation | Full name | Description |
|--------------|---|---|
| CANopen | Controller Area Network,CAN | High level communication protocol based on control local area network |
| pp | Profile position | Internal position control mode |
| pv | Profile velocity | Internal speed control mode |
| tq | Torque profile | Internal torque control mode |
| csp | Cyclic synchronous position mode | Cyclic position control mode |
| hm | Homing mode | Zero reset position control mode |
| csv | Cyclic synchronous velocity mode | Cyclic speed control mode |
| cst | Cyclic synchronous torque mode | Cyclic torque control mode |
| DC | Distributed Clock | Distributed clock |
| SDO | Service Data Object | The service data object is used to transmit aperiodic communication data |
| PDO | Process Data Object | The process data object is used to transmit periodic communication data |
| TxPDO | - | PDO transmitted from slave station to master station |
| RxPDO | - | PDO transmitted from master station to slave station |
| PHY | Physical layer device that converts data from the Ethernet controller to electric or optical signals. | Physical layer device that converts data from the Ethernet controller to electric or optical signals. |
| PDI | Process Data Interface or Physical Device Interface | Process Data Interface or Physical Device Interface |
| EEPROM | Electrically Erasable Programmable Read Only Memory | Programmable read only memory, which is used to store the non-volatile memory of ESC configuration and device description. Connect to ESI interface |

XINJE



Wechat ID

WUXI XINJE ELECTRIC CO., LTD.

No.816, Jianzhu West Road, Binhu District,

Wuxi City, Jiangsu Province, China

214072

Tel: (510) 85134136

Fax: (510) 85111290

www.xinje.com